



YAMAHA

PARTS LIST

MODEL DT175E

NOTICE

ALL PART NUMBERS CONTAINED IN THIS CATALOGUE ARE COMPRISED OF TEN DIGITS. WHEN ORDERING, PLEASE ADD TWO ZEROS TO THE END OF EACH PART NUMBER REQUIRED TO CONVERT THE TEN DIGITS INTO THE NEW TWELVE DIGIT NUMBERS.

YAMAHA MOTOR CO., LTD.

COPY RIGHT: ALL RIGHTS RESERVED

NO PART OF THIS PUBLICATION MAY BE REPRODUCED WITHOUT PERMISSION.

YAMAHA

PARTS LIST


MODEL DT175E

FOREWORD

This Parts List relates to the parts in use for the YAMAHA DT175E.
When you are ordering replacement parts for the YAMAHA DT175E, refer to this Parts List and quote both part numbers and part names correctly.

1. Structure of Part No.

Yamaha parts are divided largely into two categories; general parts and standard parts, and each part No. has the following structure:



Note: Every standard No. begins with 9.

2. How to Use this Parts List

- (1) Except for steel balls (whose size is indicated in inches), the size of all parts is indicated in millimeters in the following manner.

Hose (rubber or vinyl) Inside diameter - length

O-ring Section area - inside diameter

Washer, shim, collar Inside diameter - outside diameter - thickness (length)

- (2) Parts, which are to be supplied in the form of assemblies, are listed with an indention of one letter's space, and a dot (.) is put

against the name of each part. If any two different assemblies (e.g., right and left side components) consist of almost the same type components, these two assemblies are listed in two lines, and then the names of component parts are listed in the subsequent lines with an indentation as mentioned earlier. The quantity of parts is given in the following manner; that is, in the case of parts being the same in type between the right and left, a total quantity of parts is given. On the other hand, if the right and left side parts are different in type, the quantity of part(s) on each side is given.

Example

Description	Q'ty
CARBURETOR ASS'Y, left	1
CARBURETOR ASS'Y, right	1
. JET, pilot	2
. NOZZLE, main	2
. LEVER, starter, left	1
. LEVER, starter, right	1

(3) Key to Symbols

U.R.	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD	"SD" type oil seal
SO	"SO" type oil seal
SW	"SW" type oil seal
E	"E" type circlip
R	"R" type circlip
F/No.	Frame No. (Applicable machine No.)

- (4) The right and left in relation to parts are determined on the basis of the rider facing toward the front.
- (5) This Parts List is based on the model in the production line on Feb., 20, 1977. Accordingly, if any modification which have been made to parts will be announced in the Yamaha Parts News. It is advisable that according to the Yamaha Parts News, You will make necessary corrections to the Parts List on hand to keep it up-to dated.

CONTENTS

ENGINE

Fig. 1	Crankcase · Cylinder	1
Fig. 2	Crankcase Cover	5
Fig. 3	Crank · Piston	7
Fig. 4	Clutch	11
Fig. 5	Transmission	13
Fig. 6	Shifter 1	17
Fig. 7	Shifter 2	19
Fig. 8	Kick Starter	21
Fig. 9	Tachometer Gear	23
Fig. 10	Intake	25
Fig. 11	Carburetor	27
Fig. 12	Exhaust	31
Fig. 13	Oil Pump	33
Fig. 14	C. D. I. Magneto	37

CHASSIS

Fig. 15	Frame · Side Cover	41
Fig. 16	Rear Arm · Chain Case	43
Fig. 17	Rear Cushion	45
Fig. 18	Stand · Footrest · Brake Pedal	47
Fig. 19	Front Fender · Rear Fender	49
Fig. 20	Front Fork	51
Fig. 21	Steering	55
Fig. 22	Handle · Wire	57
Fig. 23	Fuel Tank	61
Fig. 24	Oil Tank	63
Fig. 25	Seat	65
Fig. 26	Front Wheel	67
Fig. 27	Rear Wheel	71

Fig. 28	Head Lamp	75
Fig. 29	Speedometer · Tachometer	77
Fig. 30	Tail Lamp	79
Fig. 31	Flasher Lamp	83
Fig. 32	Electrical	85

REPAIR KIT


Fig. 33	Repair Kit	91
---------	------------------	----

NUMERICAL INDEX

ENGINE




Fig. 1 CRANKCASE · CYLINDER



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
1- 1	2A6-15111-01 ⁴⁶²	CASE, crank left	1	4MC77067	有
2	2A6-15121-00 ⁴⁶¹	CASE, crank right	1	4MC77067	有
3	91810-19020	PIN, dowel (16.5-20-20)	1		
4	91830-21014	PIN, dowel (6.4-10-14)	1		
5	92501-06050	SCREW, panhead	5		
6	92501-06060	SCREW, panhead	3		
7	92501-06070	SCREW, panhead	3		
8	92501-06075	SCREW, panhead	1		
9	90430-12036	GASKET (132-15353-00)	1		
10	90340-12005	PLUG, straight screw (132-15351-00) ..	1		
11	95611-10630	BOLT, stud	2		
12	95611-10640	BOLT, stud	2		
13	90179-10201	NUT	4		
14	91810-16016	PIN, dowel (10.5-14-16)	2		
15	304-15128-00	HOLDER, right	1		
16	92501-08010	SCREW, panhead	1		
17	90116-08104	BOLT, stud (363-11179-00)	6		
18	1W1-11351-00	GASKET, cylinder	1		
19	2A7-11311-00	CYLINDER	1		
20	1W2-11181-00	GASKET, cylinder head	1		
21	2A7-11111-00	HEAD, cylinder	1		
22	90201-08100	WASHER, plate	6		
23	95301-08600	NUT, hexagon	6		
24	94701-00135	PLUG, spark (CHAMPION N-7Y)	1		
25	496-15371-00	BREATHER	1		
26	90445-07340	HOSE (4.2-310)	1		
27	328-15316-00	DAMPER	2		
28	401-15317-00	SPACER, engine mount	1		
29	93210-11073	O-RING (2.4-10.8)	2		
30	2A6-11161-00	ABSORBER 1	1		
31	2A6-11162-00	ABSORBER 2	1		
32	579-11162-00	ABSORBER 2	2		


Fig.1 CRANKCASE · CYLINDER



FWD


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
1-33	2A6-11127-00	ABSORBER 3	2		
34	2A6-11128-00	ABSORBER 4	2		
35	2A6-11129-00	ABSORBER 5	1		
36	90116-06016	BOLT, stud (306-11179-00)	2		

Fig. 2 CRANKCASE COVER




Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
2- 1	2A7-15411-00	COVER, crankcase left 1	1		
2	2A6-15455-00	GASKET, generator cover	1		
3	92501-06030	SCREW, panhead	6		
4	2A6-15484-00	CLAMP 2	1		
5	2A6-15431-00	COVER, crankcase right	1		
6	1W1-15451-00	GASKET, crankcase cover right	1		
7	91830-21014	PIN, dowel (6.4-10-14)	2		
8	92501-06030	SCREW, panhead	3		
9	92501-06040	SCREW, panhead	6		
10	2A6-15416-00	COVER, oil pump	1		
11	2A6-15456-00	GASKET, oil pump cover	1		
12	92501-06020	SCREW, panhead	4		
13	401-15362-00	PLUG, oil level	1		
14	93210-19123	O-RING (2.4-19)	1		

Fig. 3 CRANK · PISTON



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
3- 1	2A6-11400-01	CRANK ASS'Y	1		
2	1W1-11412-01	. CRANK, left	1		
3	1W1-11422-01	. CRANK, right	1		
4	2A6-11651-01	. ROD, connecting	1		
5	248-11681-01	. PIN, crank	1		
6	93310-42231	. BEARING, con-rod big end	1		
7	90209-22071	. WASHER (164-11685-00)	2		
8	2A7-11631-00-96	PISTON (55.96mm STD)	1	U.R	
	2A7-11631-00-98	PISTON (55.98mm STD)			
	2A7-11635-00	PISTON (56.25mm 1st O.S)	1		Alternate Parts
	2A7-11636-00	PISTON (56.50mm 2nd O.S)	1		Alternate Parts
	2A7-11637-00	PISTON (56.75mm 3rd O.S)	1		Alternate Parts
	2A7-11638-00	PISTON (57.00mm 4th O.S)	1		Alternate Parts
9	2A7-11610-00	PISTON RING SET (STD)	1		
	2A7-11610-10	PISTON RING SET (1st O.S)	1		Alternate Parts
	2A7-11610-20	PISTON RING SET (2nd O.S)	1		Alternate Parts
	2A7-11610-30	PISTON RING SET (3rd O.S)	1		Alternate Parts
	2A7-11610-40	PISTON RING SET (4th O.S)	1		Alternate Parts
10	93310-216E1	BEARING, con-rod small end	1		
11	251-11633-00	PIN, piston	1		
12	93450-17044	CIRCLIP	2		
13	93306-20517	BEARING (B6205)	1		
14	93102-25061	OIL SEAL (SD-25-40-8)	1		
15	90201-12593	WASHER, plate	1		
16	92901-12100	WASHER, spring	1		
17	90170-12067	NUT, hexagon (214-11555-01)	1		
18	93306-30405	BEARING (B6304)	1		
19	93103-28011	OIL SEAL (SW-28-40-8)	1		
20	93210-18023	O-RING (1.2-17.6)	1		
21	90387-20488	COLLAR, distance (20-28-18.5)	1		
22	2A6-16111-00	GEAR, primary drive (22T)	1		
23	90282-05005	KEY, straight (353-11546-00)	1		


Fig. 3 CRANK · PISTON



FWD

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
3-24	90204-12007	WASHER, spring	1		
25	90179-12044	NUT (353-16144-00)	1		
26	90280-03017	KEY, woodruff (146-11545-00)	1		


Fig. 4 CLUTCH



FWD


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
4- 1	2A7-16301-00	CLUTCH ASS'Y	1		
2	2A7-16150-00	. PRIMARY DRIVEN GEAR COMP. (71T)	1		
3	90201-17543	. WASHER, plate	1		
4	1G8-16371-00	. BOSS, clutch	1		
5	307-16367-00	. RING, cushion	6		
6	559-16321-01	. PLATE, friction	6		
7	137-16325-70	. PLATE, clutch 2	5		
8	1W1-16351-00	. PLATE, pressure	1		
9	90501-20474	. SPRING, compression	5		
10	90159-05011	. SCREW, with washer	5		
11	1W1-16358-00	PLATE, push	1		
12	92901-06200	WASHER, plain	1		
13	95301-06600	NUT, hexagon	1		
14	1W1-16356-00	ROD, push 1	1		
15	90170-14171	NUT, hexagon	1		
16	90215-14122	WASHER, lock	1		
17	90560-17147	SPACER	1		
18	90201-17550	WASHER, plate	1		
19	1W1-16357-00	ROD, push 2	1		
20	1W1-16380-00	PUSH LEVER ASS'Y	1		
21	90508-20345	SPRING, torsion	1		
22	90201-14217	WASHER, plate (150-25153-00)	1		
23	93104-14004	OIL SEAL (SO-14-25-5)	1		
24	90149-08108	SCREW	1		
25	90430-08069	GASKET (452-16387-00)	1		
26	93503-16010	BALL (3/16 inch)	1		

Fig. 5 TRANSMISSION




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
5- 1	2A6-17411-00	AXLE, main (10T)	1		
2	1W2-17151-00	GEAR, 5th pinion (23T)	1		
3	90201-20266	WASHER, plate (132-17216-00)	2		
4	93410-20038	CIRCLIP (S-20)	3		
5	2A6-17131-00	GEAR, 3rd/4th pinion (18T, 21T)	1		
6	1W2-17161-00	GEAR, 6th pinion (25T)	1		
7	2A6-17121-00	GEAR, 2nd pinion (14T)	1		
8	90201-15563	WASHER, thrust (642-45576-00-10) ...	1		
9	93311-41530	BEARING	1		
10	93306-30304	BEARING (B6303Z)	1		
11	1W1-17471-01	PLATE, bearing cover	1		
12	97321-06012	BOLT, hexagon	2		
13	2A6-17421-00	AXLE, drive	1		
14	2A6-17221-00 ^{Δ 9/}	GEAR, 2nd wheel (31T)	1	Δ H 677048 ②有	
15	90201-22555	WASHER, plate	1		
16	93410-22039	CIRCLIP (S-22)	4		
17	2A6-17261-00	GEAR, 6th wheel (20T)	1		
18	90201-18135	WASHER	2		
19	1W2-17241-00	GEAR, 4th wheel (25T)	1		
20	2A6-17231-00	GEAR, 3rd wheel (28T)	1		
21	2A6-17251-00	GEAR, 5th wheel (22T)	1		
22	2A6-17211-00 ^{Δ 9/}	GEAR, 1st wheel (35T)	1	Δ H 677048 ②有	
23	90201-15563	WASHER, thrust (642-45576-00-10)	1		
24	93440-15012	CIRCLIP (15φ special)	1		
25	93311-31515	BEARING	1		
26	525-15651-00	GEAR, kick idle (25T)	1		
27	137-17417-00-05	SHIM, main axle (15.5-22-0.5)	2		
28	93440-15012	CIRCLIP (15φ special)	2		
29	93306-30411	BEARING (B6304)	1		
30	93102-26042	OIL SEAL (SD-26-38-5)	1		
31	90387-20503	COLLAR (20-26-11.3)	1		
32	174-17461-60	SPROCKET, drive (16T)	1		

Fig. 5 TRANSMISSION



Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
5-33	90215-16127	WASHER, lock	1		
34	90179-16226	NUT	1		
35	1W1-15381-00	PLATE, bearing cover	1		
36	92701-06012	SCREW, flathead	2		


Fig. 6 SHIFTER 1.



FWD


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
6- 1	1W1-18541-00	CAM, shift	1		
2	93315-21813	BEARING	1		
3	1W1-18185-00	SEGMENT	1		
4	93604-12037	PIN, dowel (4-11.8)	6		
5	1W1-18561-00	PLATE, side	1		
6	93430-08006	CIRCLIP (E-8)	1		
7	2A6-18531-00	BAR, shift fork guide 1	1		
8	2A6-18535-00	BAR, shift fork guide 2	1		
9	2A6-18511-00	FORK, shift 1	2		
10	2A6-18512-00	FORK, shift 2	1		
11	1W1-18140-00	STOPPER LEVER ASS'Y	1		
12	1W1-18177-00	BOLT, stopper 2	1		
13	90506-09156	SPRING, tension	1		
14	93604-30018	PIN, dowel (4-29.8)	1		
15	136-18542-00	POINT, neutral	1		

Fig. 7 SHIFTER 2




Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
7- 1	2A6-18111-00	PEDAL, change	1		
2	132-18113-01	COVER, change pedal	1		
3	97321-06020	BOLT	1		
4	93101-12060	OIL SEAL (S-12-21-4)	1		
5	1W1-18101-01	CHANGE SHAFT ASS'Y	1	Δ K.C. 77096 7-62 E-1-12 (E) 1/2	
6	Δ 93430-10016 1W1-18136-00	CIRCLIP	1	Δ K.C. 77096 7-52 E-1-12 (E) 1/2	
7	401-18178-00	ROLLER, change lever	1		
8	2A6-18120-00	CHANGE LEVER ASS'Y	1		
9	90506-08155	. SPRING, tension	1		
10	1W1-18197-01	SHAFT	1		
11	90508-32349	SPRING, torsion	1		
12	102-18137-00-10	WASHER	1		
13	93430-10016	CIRCLIP (E-10)	2		
14	90149-08111	SCREW	1		
15	90170-08029	NUT, hexagon (248-18134-00)	1		
16	90215-08014	WASHER, lock (248-18139-00)	1		

Fig. 8 KICK STARTER




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
8- 1	2A6-15611-00 ⁴⁸¹	CRANK, kick	1	4H177096 (E) 1/3	
2	156-15618-01	COVER, kick lever	1		
3	1W1-15621-00 ⁴⁰¹	BOSS, kick crank	1	4H177096 (E) 1/3	
4	90201-12541	WASHER, plate	1		
5	93430-08007	CIRCLIP (E-8)	1		
6	90501-10459	SPRING, compression	1		
7	93503-16010	BALL (3/16 inch)	1		
8	91316-08025	BOLT, hexagon socket head	1		
9	2A6-15660-00	KICK AXLE ASS'Y	1		
10	90468-26048	CLIP (315-15687-00)	1		
11	1W1-15641-00	GEAR, kick (27T)	1		
12	248-15654-00	HOLDER, kick gear	2		
13	93410-30012	CIRCLIP (S-30)	1		
14	401-15676-00	COVER, spring	1		
15	90508-26346	SPRING, torsion	1		
16	1W1-15666-00	SPACER	1		
17	90201-17327	WASHER, plate	1		
18	90560-17032	SPACER (401-15683-00)	1		
19	93101-17062	OIL SEAL (S-17-25-4)	1		
20	1W1-15618-01	COVER, kick crank boss	1		

Fig. 9 TACHOMETER GEAR




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
9- 1	248-17861-00	AXLE, drive gear	1		
2	2A6-17831-00	GEAR, drive (16T, 2T)	1		
3	90201-10123	WASHER, plate (256-21715-01)	2		
4	90381-08002	BUSHING (214-17843-00)	1		
5	92901-08200	WASHER, plain	1		
6	2A6-17841-00	GEAR, driven (13T)	1		
7	93210-14104	O-RING (2.4-13.8)	1		
8	93109-08017	OIL SEAL (SDO-8-18-5)	1		
9	92601-06032 98001-00030	SCREW, ovalhead	1		AKC77067 H16PRINT

Fig. 10 INTAKE




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine &c.	Remarks
10- 1	314-13621-02	PACKING, valve seat	1		
2	345-13610-70	REED VALVE ASS'Y	1		
3	345-13613-70	. VALVE, reed	2		
4	345-13616-70	. STOPPER, reed valve	2		
5	92901-03100	. WASHER, spring	4		
6	98512-03008	. SCREW, panhead	4		
7	401-13565-00	JOINT, carburetor	1		
8	97301-06025	BOLT	4		
9	92901-06600	WASHER, plate	4		
10	90462-05005	CLAMP (363-15485-01)	1		
11	90460-43053	CLAMP, hose (304-14455-70)	1		
12	90460-49058	CLAMP, hose (278-14455-00)	1		
13	2A7-14453-00	JOINT, air cleaner	1		
14	90460-64065	CLAMP, hose	1		
15	2A6-14411-00 ⁴⁰¹	CASE, air cleaner	1	Δ 401 77048 有	
16	2A6-14450-00	ELEMENT ASS'Y	1		
17	2A6-14412-00	CAP, case	1		
18	2A6-14452-00	. SEAL	1		
19	98501-05012	SCREW, panhead	5		
20	92901-05100	WASHER, spring	5		
21	92901-05600	WASHER, plate	5		
22	Δ 509-14457-00	SEAL	1	Δ 401 77048 DISUSED)	
23	Δ 90467-15012	CLIP (806-24358-00)	1	Δ " ")	
24	2A6-14417-00	COVER	1		
25	2A6-14433-00	PIPE, suction	1		
26	90460-45040	CLAMP, hose	1		
27	90480-18171	GROMMET	1		
28	90480-14101	GROMMET (214-21638-00)	2		
29	90387-07391	COLLAR, fender (437-21633-00)	2		
30	92901-06600	WASHER, plate	2		
31	92901-06100	WASHER, spring	2		
32	97301-06025	BOLT, hexagon	2		

Fig. 11 CARBURETOR




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
11- 1	2A7-14101-00	CARBURETOR ASS'Y	1		
2	260-14142-22	. JET, pilot (#22.5)	1		
3	558-14141-32	. NOZZLE, main (O-2)	1		
4	137-14143-27	. JET, main (⁰¹³⁵ #115)	} U.R. 1	AK77048 (E)	STD
	137-14143-28	. JET, main (¹⁴⁰ #126)			
	137-14143-30	. JET, main (¹⁵⁰ #125)			
5	^{Δ170} 168-14190-25	. VALVE SEAT ASS'Y (#2.5)	1	AK77048 (S) TL.	
6	214-14195-00	. WASHER, valve seat	1		
7	314-14185-00	. FLOAT	1		
8	137-14186-01	. PIN, float	1		
9	304-14184-00	. GASKET, float chamber	1		
10	539-14181-04-33	. BODY, float chamber	1		Yamaha Black
11	98502-04014	. SCREW, panhead	4		
12	92901-04100	. WASHER, spring	4		
13	558-14147-00	. O-RING	1		
14	500-14115-00	. PLUG, screw	1		
15	493-14122-00	. SCREW, throttle	1		
16	493-14133-00	. SPRING, throttle stop	1		
17	174-14123-00	. SCREW, air adjusting	1		
18	174-14134-00	. SPRING, air adjusting	1		
19	^{Δ25} 314-14112-20	. VALVE, throttle (¹⁵ #2.0)	1	AK77048 (E) TL..	
20	166-14116-13	. NEEDLE (4J13-3)	1		
21	^{Δ162} 558 -14137-00	. CLIP	1	AK77009	
22	246-14132-00	. STOPPER, cable	1		
23	248-14131-00	. SPRING, throttle valve	1		
24	^{Δ162} 558 -14137-00	. CLIP	1	AK778009	
25	^{Δ246} 246-14126-00	. PACKING	1	AK77067 (E) TL	
26	^{Δ246} 401-14158-00-33	. TOP, mixing chamber	1	AK77067 (E) TL	Yamaha Black
27	^{Δ507} 363-14198-00	. PACKING	1	AK77067 (E) TL	
28	^{Δ177} 363-14155-00	. TUBE, guide wire	1	AK77067 (E) TL	
29	127-14161-00	. NUT, wire adjusting	1		
30	156-14135-00	. SPRING, plunger	1		

Fig. 11 CARBURETOR




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
11-31	304-14171-00	. PLUNGER, starter	1		
32	152-14174-00	. CAP, plunger	1		
33	353-14138-00	. CLIP, plunger	1		
34	132-14173-00	. COVER, plunger cap	1		
35	304-14261-00	. HOLDER	1		
36	91401-16015	. PIN, cotter	1		
37	183-14196-00	. PIPE, over flow (5-160)	1		
38	183-14197-01	. PIPE, air vent (3-220)	1		
	39 & 141-14169-00	. CAP			1 ΔKCT7067 @. APP.



[illegible]

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
12- 1	2A6-14610-00	EXHAUST PIPE ASS'Y	1		
2	152-14613-00	GASKET, exhaust pipe	1		
3	92901-06100	WASHER, spring	2		
4	95301-06600	NUT, hexagon	2		
5	2A6-14772-00	STAY, muffler 1-2	1		
6	97301-08016	BOLT, hexagon	2		
7	92901-08100	WASHER, spring	2		
8	92901-08600	WASHER, plate	2		
9	1W2-14771-00	STAY, muffler 1-1	1		
10	90480-14101	GROMMET (214-21638-00)	2		
11	90387-06388	COLLAR (322-21544-00)	2		
12	92901-06100	WASHER, spring	2		
13	97301-06025	BOLT, hexagon	2		
14	97301-08016	BOLT, hexagon	1		
15	92901-08100	WASHER, spring	1		
16	92901-08600	WASHER, plate	1		
17	1W2-14714-00	GASKET, muffler joint	1		
18	90460-37026	CLAMP, hose (396-14456-00)	2		
19	2A6-14753-00	SILENCER	1		
20	1M1-14752-01	PIPE, outlet	1		
21	92501-06012	SCREW, panhead	1		
22	92901-06100	WASHER, spring	1		
23	92901-06600	WASHER, plate	1		
24	565-14747-00	DAMPER, muffler	1		
25	90387-08258	COLLAR (8.3-15-15)	1		
26	90201-08113	WASHER, plate (611-48556-30)	1		
27	92901-08100	WASHER, spring	1		
28	97301-08030	BOLT, hexagon	1		
29	2A6-83596-00	CLAMP	1		


Fig. 13 OIL PUMP



FWD

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
13- 1	126-13116-00	GASKET, pump case	1		
2	90201-08624	WASHER, plate	1		
3	558-13175-00	SHAFT, worm	1		
4	93603-22028	PIN, dowel (3-21.8)	1		
5	1E7-13176-00	METAL, worm shaft outer	1		
6	93101-10002	OIL SEAL (S-10-22-7)	1		
7	90201-10135	WASHER, plate (102-18138-00)	1		
8	2A6-13178-00	GEAR, drive (24T)	1		
9	93430-08006	CIRCLIP (E-8)	1		
10	98501-05016	SCREW, panhead	2		
11	2A6-13101-00	OIL PUMP ASS'Y	1		
12	137-13137-00-03	. SHIM, plunger (5.8-10-0.3)		} U.R. 1	
	137-13137-00-05	. SHIM, plunger (5.8-10-0.5)			
	137-13137-00-10	. SHIM, plunger (5.8-10-1.0)			
13	137-13138-01	. PLATE, adjusting	1		
14	92901-05100	. WASHER, spring	1		
15	95301-05600	. NUT, hexagon	1		
16	90430-04004	. GASKET (137-13187-00)	1		
17	98901-04008	. SCREW, bind	1		
18	93505-32002	. BALL (5/32 inch)	1		
19	90501-02018	. SPRING (278-13169-00)	1		
20	402-13552-00	. NOZZLE	1		
21	363-13133-01	CLIP, plunger	1		
22	90467-08003	CLIP (101-23560-00)	2		
23	90445-07036	HOSE (4.2-100)	1		
24	90468-02025	CLIP	1		
25	2A6-13115-00 ^{Δ 01}	CONNECTOR, suction pipe	1	Δ MC77048 13-00.3/25+	
26	90468-02078	CLIP	1	⑤有.	
27	90445-09100	HOSE (5-260)	1		
28	90468-02033	CLIP (214-13164-00)	4		
29	90445-05018	HOSE (3-65)	1		


Fig. 13 OIL PUMP



FWD

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
13-30	2A6-13164-00 ⁴⁰¹	CONNECTOR, delivery pipe	1	Δ MC77078	13-25.31) 20.14
31	90445-05021 ⁴⁰⁵⁰²³	HOSE (3-110)	1	Δ 9	P-25.30 (E) 14

Fig. 14 C. D. I. MAGNETO




FWD

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
14- 1	2A7-85500-20	C.D.I. MAGNETO ASS'Y	1		
2	2A7-85550-20	. ROTOR ASS'Y	1		
3	1W2-85509-20	. BASE, magneto	1		
4	2A7-85511-20	. COIL, source 1	1		
5	2A7-85512-20	. COIL, source 2	1		
6	2A7-85513-20	. COIL, lighting	1		
7	98501-04032	. SCREW, panhead	4		
8	98501-04014	. SCREW, panhead	2		
9	92901-04100	. WASHER, spring	6		
10	2A7-85580-20	. PULSER ASS'Y	1		
11	^{Δ81328} 445-85528 -20	. CLAMP	1		ΔK577048 MISPRINT
12	110-81345-21	. SCREW	1		
13	1W2-85519-20	. SPACER	2		
14	2A7-85515-20	. LEAD WIRE ASS'Y	1		
15	^{Δ06016} 92501-06012	SCREW, panhead	2		ΔK577048 ETL.
16	92901-06600	WASHER, plate	2		

CHASSIS




Fig. 15 FRAME · SIDE COVER




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
15- 1	2A6-21110-00-33	FRAME COMP.	1		Yamaha Black
2	2A6-21471-00-33	PROTECTOR, engine	1		Yamaha Black
3	97301-06012	BOLT	4		
4	92901-06600	WASHER, plate	4		
5	90105-08022	BOLT	1		
6	92901-08200	WASHER, plain	2		
7	90185-08054	NUT U	2		
8	90105-08099	BOLT	1		
9	92901-10100	WASHER, spring	1		
10	90105-10037	BOLT	1		
11	2A7-21711-00-01	COVER, side left	1		Balboa Blue
	2A7-21711-10-01	"	1	1 HC77083 SUNSHINE RED/L.E.	Low Gloss Black
12	2A7-21721-00-01	COVER, side right	1		Balboa Blue
	2A7-21721-10-01	"	1	1 HC77083 SUNSHINE RED/L.E.	Low Gloss Black
13	2A7-21786-00	EMBLEM, side cover	2		
	2A7-21786-10	"	2	2 HC77083	
14	90480-12053	GROMMET	6		
15	90502-09024	SPRING, conical	1		
16	2A6-23408-00	STEERING LOCK ASS'Y	1		
17	584-23484-01	CAP, handle lock	1		
18	90206-04003	WASHER, wave (214-23483-00)	1		
19	90269-04003	RIVET (214-23483-00)	1		
20	2A6-21308-00	HANGER, helmet	1		
21	92701-06018	SCREW, flathead	1		
22	2A6-28100-10	TOOL ASS'Y	1		

Fig.16 REAR ARM · CHAIN CASE




Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
16- 1	2A6-22110-00-33	REAR ARM COMP.	1		Yamaha Black
2	537-22141-01	SHAFT, pivot	1		
3	401-22128-01	COVER, thrust	2		
4	401-22127-00	SHIM	U.N		
5	90386-18028	BUSHING 1 (401-22123-00)	2		
6	403-22124-00	BUSHING 2	1		
7	92901-12100	WASHER, spring	1		
8	90185-12046	NUT U	1		
9	2A6-22151-00	SEAL, guard 1	1		
10	2A6-22152-00	SEAL, guard 2	1		
11	2A6-22311-00-98	CASE, chain	1		Low Gloss Black
12	98501-05015	SCREW, panhead	2		
13	97301-05012	BOLT, hexagon	1		
14	92901-05100	WASHER, spring	3		
15	90201-06067	WASHER, plate	2		
16	2A6-22318-00	GUARD, chain	1		
17	97301-08012	BOLT, hexagon	1		
18	92901-08100	WASHER, spring	1		
19	97301-06016	BOLT, hexagon	2		
20	92901-06100	WASHER, spring	2		
21	2A6-22179-00	ARM, chain tensioner	1		
22	93104-14044	OIL SEAL (SO-14-20-3)	2		
23	90508-35350	SPRING, torsion	1		
24	90109-10483	BOLT	1		
25	1W1-22178-10	TENSIONER	1		
26	1W1-22187-00	GUIDE, chain	1		
27	98501-05040	SCREW, panhead	2		
28	92901-05100	WASHER, spring	2		
29	95301-05700	NUT, hexagon	2		
30	91701-06042	PIN, clevis	2		
31	91401-20012	PIN, cotter	2		
32	92901-06600	WASHER, plate	2		

Fig. 17 REAR CUSHION



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
17- 1	2A6-22210-00	REAR CUSHION ASS'Y	1		
2	1M1-22219-00	. BRACKET, upper	1		
3	1M1-22216-00	. BUSHING, rear cushion	1		
4	1M1-22213-01	. SEAT, spring upper	1		
5	91401-30040	. PIN, cotter	1		
6	90501-90484	. SPRING, compression	1		
7	1M1-22496-02	. SLEEVE, rod	1		
8	2A6-22493-00	. STOPPER, bump	1		
9	1M1-22482-00	. STOPPER	1		
10	90380-12051	. BUSHING	2		
11	483-22128-00	COVER, thrust	2		
12	90109-10453	BOLT	1		
13	92901-10200	WASHER, plain	1		
14	95302-10900	NUT, slotted	1		
15	91401-20025	PIN, cotter	1		
16	90240-12059	PIN, with hole	1		
17	92901-12600	WASHER, plate	1		
18	91401-30022	PIN, cotter	1		


Fig. 18 STAND · FOOTREST · BRAKE PEDAL



FWD

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
18- 1	2A6-27311-00	STAND, side	1		
2	90109-10473	BOLT	1		
3	95301-10700	NUT	1		
4	90507-29008	SPRING, tension	1		
5	1M1-27411-02-33	FOOTREST, left	1		Yamaha Black
6	1M1-27421-02-33	FOOTREST, right	1		Yamaha Black
7	90508-20023	SPRING, torsion (214-27426-00)	2		
8	91701-08038	PIN, clevis	2		
9	91401-25012	PIN, cotter	2		
10	92901-08600	WASHER, plate	2		
11	2A6-27211-00-33	PEDAL, brake	1		Yamaha Black
12	90201-14212	WASHER, plate (611-44126-00)	1		
13	93430-10015	CIRCLIP	1		
14	90508-32354	SPRING, tension	1		
15	322-27231-00	ROD, brake	1		
16	90240-06006	PIN, with hole (248-27229-00)	1		
17	92901-06200	WASHER, plain	1		
18	91401-25012	PIN, cotter	1		
19	90501-10245	SPRING, compression (180-27236-00) ..	1		
20	90249-12008	PIN (156-27237-00)	1		
21	90175-06013	NUT, wing	1		
22	97301-06020	BOLT, hexagon	1		
23	95301-06700	NUT, hexagon	1		


Fig. 19 FRONT FENDER · REAR FENDER



FWD


Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
19- 1	1M1-21511-00 <i>Δ 2A7-21511-00</i>	FENDER, front	1	<i>Δ KC77083</i>	Balboa Blue <i>SUNSHINE RE</i>
2	97301-06025	BOLT, hexagon	4		
3	92901-06100	WASHER, spring	4		
4	90201-06067	WASHER, plate	4		
5	90480-14198	GROMMET	4		
6	90387-06388	COLLAR (322-21544-00)	4		
7	2A7-21611-00 <i>Δ 2A8-21611-00</i>	FENDER, rear	1	<i>Δ KC77083</i>	Balboa Blue <i>SUNSHINE RE</i>
8	2A6-21617-00	REINFORCEMENT, rear fender	1		
9	97301-06016	BOLT, hexagon	4		
10	92901-06100	WASHER, spring	4		
11	92901-06600	WASHER, plate	4		
12	2A7-21620-00 <i>Δ 2A7-21620-00</i>	MUD GUARD COMP.	1	<i>Δ KC77067</i>	<i>19-15 207H-2 (E) T</i>
13	2A6-21639-00	. DAMPER	1		
14	1M1-21621-00	FLAP	1		
15	90480-30167 <i>Δ 90480-30167</i>	GROMMET	2	<i>Δ KC77067</i>	<i>19-12 207H-2 (E) T</i>
16	97301-06016	BOLT, hexagon	3		
17	92901-06100	WASHER, spring	3		
18	90201-06067	WASHER, plate	3		

Fig. 20 FRONT FORK




Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
20- 1	2A6-23101-00	FRONT FORK ASS'Y	1		
2	2A6-23126-00-38	. TUBE, outer left	1		
3	2A6-23145-00	. . OIL SEAL	1		
4	2A6-23156-00	. . CLIP, oil seal	1		
5	2A6-23119-00	. . BOLT, drain	1		
6	2A6-23136-00-38	. TUBE, outer right	1		
7	2A6-23145-00	. . OIL SEAL	1		
8	2A6-23156-00	. . CLIP, oil seal	1		
9	2A6-23119-00	. . BOLT, drain	1		
10	1E7-23128-00	. . BOLT, stud	2		
11	2A6-23144-00	. SEAL, dust	2		
12	2A6-23193-00	. GUIDE, boot	2		
13	2A6-23124-00	. TUBE, inner	2		
14	1L9-23166-00	. TAPER, spindle	2		
15	2A6-23151-00	. SPRING, rebound	2		
16	2A6-23157-00	. RING, piston	2		
17	2A6-23170-00	. CYLINDER COMP., front fork	2		
18	^{40/} 2A6-23192-00	. BAND, boot A	2		△KC77048②有
19	2A6-23191-00	. BOOT	2		
20	^{40/} 2A6-23489-00	. BAND, boot B	2		△KC77048②有
21	2A6-23141-00	. SPRING, front fork	2		
22	2A6-23147-00	. O-RING (2.8-19.4)	2		
23	2A6-23111-00	. BOLT, cap	2		
24	2A6-23340-00-33	. UNDER BRACKET COMP.	1		Yamaha Black
25	2A6-23317-00	. CLIP	1		
26	92901-08100	. WASHER, spring	4		
27	2A6-23346-00	. BOLT	4		
28	1E7-23181-00	. BOLT	2		
29	2A6-23167-00	. HOLDER, axle	1		
30	92901-08600	. WASHER, plate	2		
31	90185-08054	. NUT U	2		
32	2A6-84118-00	STAY, head lamp 1	1		

Fig. 20 FRONT FORK




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No	Remarks
20-33	2A6-84119-00	STAY, head lamp 2	1		
34	92501-06020	SCREW, panhead	2		
35	92901-06100	WASHER, spring	2		
36	92901-06200	WASHER, plain	2		
37	2A6-23319-00	HOLDER, wire 2	1		
38	2A6-23318-00	HOLDER, wire 1	1		
39	97301-06020	BOLT, hexagon	1		
40	92901-06100	WASHER, spring	1		
41	355-85111-00	REFLECTOR	2		
42	90430-06012	GASKET (620-13168-00)	2		
43	2A6-83595-00	CLAMP	1		
44	92901-06600	WASHER, plate	1		
45	92901-06100	WASHER, spring	1		
46	97301-06012	BOLT, hexagon	1		

Fig. 21 STEERING




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
21- 1	164-23462-00	SEAL, dust	1		
2	156-23411-00	RACE, ball 1	1		
3	93501-04011	BALL (1/4 inch)	19		
4	156-23412-00	RACE, ball 2	1		
5	122-23412-00	RACE, ball 2	1		
6	93503-16010	BALL (3/16 inch)	22		
7	122-23411-00	RACE, ball 1	1		
8	583-23416-01	COVER, ball race	1		
9	90179-25033	NUT (137-23454-00)	1		
10	2A6-23435-00-98	CROWN, handle	1		Low Gloss Black
11	90105-14060	BOLT, steering fitting	1		
12	90468-20082	CLIP	1		
13	95811-08055	BOLT, flange	3		
14	90185-08054	NUT	3		
15	1E6-23441-00	HOLDER, handle upper	2		
16	95821-08035	BOLT, flange	4		

Fig. 22 HANDLE · WIRE




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
22- 1	2A6-26111-00	HANDLE	1		
2	1E6-26241-00	GRIP, left	1		
3	1T2-83972-00	SWITCH, handle 4	1		
	1M1-83973-50	SWITCH, handle 3	1		for Canada
4	498-82910-20	LEVER HOLDER ASS'Y, left	1		
5	498-82911-00	. HOLDER, lever left	1		
6	1J3-83912-20	. LEVER, left	1		
7	90109-06410	. BOLT	1		
8	90201-08083	. WASHER, plate (156-27226-00)	1		
9	97301-06022	. BOLT	1		
10	92901-06100	. WASHER, spring	1		
11	95601-06100	. NUT U	1		
12	1A0-26242-01	GRIP, right	1		
13	1M1-26249-01	RING, leaf	1		
14	434-26243-00	TUBE, guide	1		
15	437-83976-02	SWITCH, handle 1	1		
16	2A6-82920-90	LEVER HOLDER ASS'Y, right	1		
17	361-82921-31	. HOLDER, lever right	1		
18	2A6-83922-00	. LEVER, right	1		
19	97301-06022	. BOLT, hexagon	2		
20	90201-08083	. WASHER, plate (156-27226-00)	1		
21	92901-06100	. WASHER, spring	1		
22	214-83913-00	. COLLAR, lever	1		
23	95601-06100	. NUT U	1		
24	90170-10038	NUT, hexagon (169-26251-00)	1		
25	2A6-26311-00	WIRE, throttle 1 (690mm)	1		
26	2A6-26312-00	WIRE, throttle 2 (165mm)	1		
27	92901-08600	WASHER, plate	1		
28	93210-07100	O-RING	1		
29	90468-08086	CIRCLIP	1		
30	2A6-26335-01	WIRE, clutch (985mm)	1		
31	382-26372-01	. COVER, lever	1		

Fig. 22 HANDLE · WIRE



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
22-32	90123-08046	BOLT, wire adjusting	2		
33	90179-08148	NUT (168-26344-00)	2		
34	2A6-26341-01	WIRE, brake (1165mm)	1		
35	498-26372-00	. COVER, lever	1		
36	2A6-26397-00	CLAMP	1		
37	98501-05018	SCREW, panhead	1		
38	92901-05600	WASHER, plate	1		
39	92901-05100	WASHER, spring	1		
40	95301-05600	NUT, hexagon	1		
41	437-83936-00	BAND, switch cord	4		
42	90338-09012	PLUG (341-26329-00)	1		
43	1M1-83980-30	FRONT STOP SWITCH ASS'Y	1		
44	1Y1-26290-10	BACK MIRROR ASS'Y, left	1		Convex Mirror
45	1Y1-26290-00	BACK MIRROR ASS'Y, right	1		Optional Parts Convex Mirror


Fig. 23 FUEL TANK



Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
23- 1	2A6-24110-00-04	FUEL TANK COMP.	1		Baiboa Blue
	2A6-24110-00-06 " "		1	Δ MC77083	SUNSHINE RE
2	2A6-24244-00	. GRAPHIC, fuel tank left 1	1		
3	2A6-24245-00	. GRAPHIC, fuel tank right 1	1		
4	2A6-24246-00	. GRAPHIC, fuel tank left 2	1		
	2A6-24246-10 " "		1	Δ MC77083	
5	2A6-24247-00	. GRAPHIC, fuel tank right 2	1		
	2A6-24247-10 " "		1	Δ MC77083	
6	2A6-24248-00	. GRAPHIC, fuel tank left 3	1		
7	2A6-24249-00	. GRAPHIC, fuel tank right 3	1		
8	1W1-24612-00	PACKING CAP	1		
9	2A6-24611-00	BODY, cap	1		
10	90445-09115	HOSE (5-500)	1		
11	278-24181-00	DAMPER, locating 1	2		
12	2A6-24181-00	DAMPER, locating 1	2		
13	90201-06067	WASHER, plate	2		
14	92901-06100	WASHER, spring	2		
15	97301-06016	BOLT, hexagon	2		
16	2A6-24182-00	DAMPER, locating 2	1		
17	304-24500-05	FUEL COCK ASS'Y	1		
18	132-24521-00	. CUP, filter	1		
19	132-24522-00	. GASKET, filter	1		
20	304-24515-00	. NET, filter	1		
21	434-24532-00	. GASKET, nut	1		
22	132-24531-00	. NUT	1		
23	137-24523-00	. VALVE	1		
24	447-24524-00	. LEVER, cock	1		
25	132-14518-00	. WASHER, wave	1		
26	447-24525-00	. PLATE, lever fitting	1		
27	98501-03006	. SCREW, panhead	2		
28	90445-09086	HOSE (5-170)	1		
29	90467-08003	CLIP (101-24356-00)	2		


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
24- 1	2A6-21751-00	TANK, oil	1		
2	1T9-21771-00	BODY, cap	1		
3	90480-18171	GASKET	1		
4	1A0-85720-02	OIL LEVEL GAUGE ASS'Y	1		
5	90445-09361	HOSE (5-545)	1		
6	2A6-21796-00	HINGE, oil tank	1		
7	90201-06067	WASHER, plate	2		
8	92901-06100	WASHER, spring	2		
9	92501-06016	SCREW, panhead	2		
10	91701-05050	PIN, clevis	1		
11	90468-10050	CLIP (156-83525-00)	1		
12	90480-14102	GROMMET (214-21717-00)	1		
13	90387-07391	COLLAR (437-21633-00)	1		
14	90462-05004	CLAMP (278-15485-00)	1		
15	90179-06013	NUT	1		
16	90122-06001	BOLT	1		
17	93210-04122	O-RING	1		

Fig. 25 SEAT




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
25- 1	2A6-24770-90	SEMI DOUBLE SEAT ASS'Y	1		
2	2A6-24771-00	. COVER, semi double seat	1		
3	509-24724-00	DAMPER, seat 1	4		
4	214-24724-00	DAMPER, seat 2	2		
5	1M1-24748-00	BRACKET, seat front	1		
6	2A6-24738-00	BRACKET, seat rear	2		
7	97301-06012	BOLT, hexagon	6		
8	92901-06100	WASHER, spring	6		
9	97301-08012	BOLT, hexagon	2		
10	92901-08100	WASHER, spring	2		

Fig. 26 FRONT WHEEL




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
26- 1	2A6-25111-00-98	HUB, front	1		Low Gloss Black
2	2A6-25104-00	SPOKE SET	1s		
3	94127-21377	TIRE, front (2.75-21-4PR)	1		
4	94227-21123	TUBE, front (2.75-21)	1		
5	94330-21084	BAND, rim (3.00-21)	1		
6	94416-21206	RIM, front (1.60-21)	1		
7	1T1-25194-00	SPACER, bead	1		
8	90560-12138	SPACER, bearing (183-25117-00)	1		
9	109-25315-00	FLANGE, spacer	1		
10	93306-30102	BEARING (B6301)	2		
11	93102-18008	OIL SEAL (SD-18-37-8)	1		
12	90387-12095	COLLAR (183-25183-00)	1		
13	183-25118-00	COVER, hub dust	1		
14	90387-12100	COLLAR (315-25186-00)	1		
15	401-25181-01	SHAFT, wheel	1		
16	91401-30022	PIN, cotter	1		
17	93410-20009	CIRCLIP (S-20)	1		
18	90201-20269	WASHER, plate (183-25147-00)	2		
19	183-25149-00	CLUTCH, meter	1		
20	248-25135-10	GEAR, drive	1		
21	437-25330-00	BRAKE SHOE COMP.	2		
22	90506-16036	SPRING, tension (183-25333-00)	2		
23	93105-47007	OIL SEAL (SDD-47-58-7)	1		
24	2A6-25120-00-98	BRAKE SHOE PLATE ASS'Y	1		Low Gloss Black
25	90480-10068	. GROMMET	1		
26	248-25351-00	CAM, shaft	1		
27	559-25155-00	LEVER, camshaft	1		
28	90101-06278	BOLT, hexagon	1		
29	95301-06600	NUT, hexagon	1		
30	248-25138-10	GEAR, meter	1		
31	90201-07076	WASHER, plate (183-25146-00)	1		
32	109-25136-00	BUSHING	1		

Fig. 26 FRONT WHEEL




Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
26-33	93104-07003	OIL SEAL (SO-7-14-4)	1		
34	93210-14104	O-RING (2.4-13.8)	1		
35	102-25137-00	RING, stop	1		
36	92901-12200	WASHER, plain	1		
37	90171-12005	NUT, castle	1		

Fig. 27 REAR WHEEL




Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
27- 1	1W1-25311-00-98	HUB, rear	1		Low Gloss Black
2	2A6-25304-00	SPOKE SET	1s		
3	94135-18376	TIRE, rear (3.50-18-4PR)	1		
4	94232-18119	TUBE, rear (3.25-18)	1		
5	94330-18087	BAND, rim (3.00-18)	1		
6	94418-18171	RIM, rear (1.80-18)	1		
7	1T2-25394-00	SPACER, bead	1		
8	248-25317-00	SPACER, bearing	1		
9	148-25115-00	FLANGE, spacer	1		
10	93306-20203	BEARING (B6202Z)	1		
11	93104-22018	OIL SEAL (SO-22-35-5)	1		
12	437-25330-00	BRAKE SHOE COMP.	2		
13	90506-16036	SPRING, tension (183-25333-00)	2		
14	2A6-25320-00-98	BRAKE SHOE PLATE ASS'Y	1		Low Gloss Black
15	90480-10068	GROMMET	1		
16	^{2A6} 248-25351-00	CAMSHAFT	1	DMC 77067 ⑤有	
17	1E2-25155-00	LEVER, camshaft	1		
18	90101-06278	BOLT, hexagon	1		
19	95301-06600	NUT, hexagon	1		
20	90387-15524	COLLAR	1		
21	1W2-25389-00	PULLER, chain right	1		
22	2A6-25381-00	SHAFT, wheel	1		
23	91401-30030	PIN, cotter	1		
24	2A6-25449-10	GEAR, sprocket wheel (49T)	1		
25	1G8-25412-00	WASHER, lock	3		
26	90116-10221	BOLT, stud	6		
27	90170-10219	NUT, hexagon	6		
28	94580-15118	CHAIN (DID 428DSM-118L)	1		
29	94680-15001	JOINT, chain	1		
30	93306-30203	BEARING (B6302Z)	1		
31	93106-26005	OIL SEAL (DD-26-42-8)	1		
32	90387-15524	COLLAR (15-26-22)	1		

Fig. 27 REAR WHEEL



Ref. No.	Parts No.	Description	Q'ty	Accessories Machine No.	Remarks
27-33	401-25367-00	COVER, dust	1		
34	1W2-25388-00	PULLER, chain left	1		
35	90201-15238	WASHER, plate	1		
36	90171-14006	NUT, castle (214-25182-01)	1		


Fig. 28 HEAD LAMP



FWD

Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
28- 1	1M1-84130-60-98	HEAD LAMP BODY ASS'Y	1		Low Gloss Black
2	498-84145-60	. COLLAR	2		
3	498-84163-60	. BUSHING	2		
4	1M1-84164-60	. BUSHING	2		
5	2A6-84110-60	HEAD LAMP UNIT ASS'Y	1		
6	1M1-84195-61	. RING, retaining	1		
7	2A6-84120-60	. LENS ASS'Y	1		
8	341-84397-61	. COVER	1		
9	371-84312-60	. SOCKET CORD ASS'Y	1		
10	1M1-84124-60	. SPRING, reflector set	3		
11	1M1-84133-60	. COLLAR	1		
12	498-84128-60	. SPACER	1		
13	1M1-84137-60	BOLT, hexagon	1		
14	90109-08448	BOLT	2		
15	95301-08600	NUT, hexagon	2		
16	92901-08100	WASHER, spring	2		
17	92901-08200	WASHER, plain	2		


Fig. 29 SPEEDOMETER · TACHOMETER



FWD


Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
29- 1	2A6-83570-30	SPEEDOMETER ASS'Y	1		Mile/h
	2A6-83570-11	SPEEDOMETER ASS'Y	1		Km/h for Canada
2	122-83516-10	. BULB (6V-3W)	1		
3	1M1-83536-00	. SOCKET CORD ASS'Y	1		
4	1E6-83578-00 ^{41E6 60}	. KNOB	1		AKL77048 MISPRINT
5	2A6-83540-00	TACHOMETER ASS'Y	1		
6	122-83516-10	. BULB (6V-3W)	5		
7	2A6-83520-00	. SOCKET CORD ASS'Y	1		
8	2A6-83513-00	DAMPER	2		
9	2A6-83519-00	BRACKET, meter	1		
10	1M1-83526-00	DAMPER, meter	4		
11	1E6-83524-60	WASHER, meter fitting	4		
12	90468-12007	CLIP	4		
13	97301-06030	BOLT, hexagon	2		
14	92901-06100	WASHER, spring	2		
15	92901-06600	WASHER, plate	2		
16	90385-06001	BUSHING	2		
17	2A6-83550-00	SPEEDOMETER CABLE ASS'Y	1		
18	2A6-83560-00	TACHOMETER CABLE ASS'Y	1		

Fig. 30 TAIL LAMP




Ref. No.	Parts No.	Description	Q'ty	Associate Machine No.	Remarks
30- 1	1M1-84510-60	TAIL LAMP UNIT ASS'Y	1		
2	1M1-84511-60	. BASE, tail lamp	1		
3	1M1-84514-60	. BULB, tail lamp (6V-32/3CP)	1		
4	1M1-84523-60	. GASKET, tail lamp	1		
5	1M1-84521-60	. LENS, tail lamp	1		
6	1M1-84524-60	. SCREW, lens fitting	2		
7	1M1-84512-60	SHEET, base	1		
8	2A6-84551-60-33	BRACKET, license	1		Yamaha Black
9	1M1-84526-60	SCREW	2		
10	437-84525-60	WASHER, special	2		
11	1M1-84527-60	DAMPER	2		
12	1M1-84553-10	DAMPER	1		
13	1M1-84553-20	DAMPER	1		
14	90387-06553	COLLAR (6.5-10.5-16)	1		
15	92901-06600	WASHER, plate	1		
16	97301-06025	BOLT, hexagon	1		
17	90201-06074	WASHER, plate (248-21757-00)	1		
18	95301-06800	NUT, crown	1		
19	1M1-84553-00	DAMPER	1		
20	1M1-84553-10	DAMPER	2		
21	90387-06554	COLLAR (6.5-10.5-20.5)	2		
22	92901-06600	WASHER, plate	2		
23	97301-06035	BOLT, hexagon	2		
24	90201-06074	WASHER, plate (248-21757-00)	2		
25	95301-06600	NUT, hexagon	2		
26	1M1-84517-00	CORD, tail lamp	1		
27	1M1-85132-62	BRACKET 1	1		
28	97301-06016	BOLT, hexagon	2		
29	92901-06100	WASHER, spring	2		
30	90201-06075	WASHER, plate (808-24186-00)	2		
31	95301-06600	NUT, hexagon	2		
32	92901-06600	WASHER, plate	2		

Fig. 30 TAIL LAMP



Ref. No.	Parts No.	Description	Q'ty	Applicable Machine No.	Remarks
30-33	1M1-85131-10	REFLECTOR	} U.R 1		
	449-85131-01	REFLECTOR			
34	95301-05600	NUT, hexagon	1		
35	92901-05100	WASHER, spring	1		
36	92901-05200	WASHER, plain	1		

Fig. 31 FLASHER LAMP



Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
31- 1	1M1-83310-60	FRONT FLASHER LAMP ASS'Y	2		
2	115-83311-60	. BULB (6V-18W)	2		
3	1M1-83309-60	. REFLECTOR	2		
4	1M1-83313-60	. GASKET, lens	2		
5	341-83312-70	. LENS, flasher	2		
6	97701-03520	. SCREW, tapping	4		
7	1M1-83318-00	STAY, flasher	2		
8	95303-08800	NUT, crown	2		
9	1T9-83330-60	REAR FLASHER LAMP ASS'Y	2		
10	115-83311-60	. BULB (6V-18W)	2		
11	1M1-83309-60	. REFLECTOR	2		
12	1M1-83313-60	. GASKET, lens	2		
13	¹⁸³³¹² 341-83312 -70	. LENS, flasher	2		Δ MC-77048 MISPAINT.
14	97701-03520	. SCREW, tapping	4		
15	92901-10100	WASHER, spring	2		
16	95301-10600	NUT, hexagon	2		


This diagram illustrates the electrical system components of a vehicle, showing their relative positions and interconnections. The components are numbered as follows:

- 1:** Main wiring harness
- 2:** Alternator
- 3:** Alternator mounting bracket
- 4:** Alternator mounting nut
- 5:** Alternator mounting washer
- 6:** Alternator mounting nut
- 7:** Alternator mounting washer
- 8:** Alternator mounting nut
- 9:** Alternator mounting bracket
- 10:** Alternator mounting nut
- 11:** Alternator mounting washer
- 12:** Alternator mounting bracket
- 13:** Alternator mounting nut
- 14:** Alternator mounting washer
- 15:** Alternator mounting nut
- 16:** Alternator mounting bracket (FOR CANADA)
- 17:** Fuse block
- 18:** Fuse block mounting bracket
- 19:** Fuse block mounting nut
- 20:** Battery terminal post
- 21:** Battery terminal post
- 22:** Battery terminal post
- 23:** Battery terminal post
- 24:** Battery terminal post
- 25:** Battery terminal post
- 26:** Battery terminal post
- 27:** Battery terminal post
- 28:** Battery terminal post
- 29:** Battery terminal post
- 30:** Battery
- 31:** Battery terminal post
- 32:** Battery terminal post
- 33:** Battery terminal post
- 34:** Battery terminal post
- 35:** Battery terminal post
- 36:** Battery terminal post
- 37:** Battery terminal post
- 38:** Battery terminal post
- 39:** Battery terminal post
- 40:** Battery terminal post
- 41:** Battery terminal post
- 42:** Battery terminal post

The diagram also includes a label "FOR CANADA" and a "FWD" (Forward) indicator.

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
32- 1	2A7-82590-20	WIRE HARNESS ASS'Y	1		
	2A7-82590-50 2A7-82590-50	WIRE HARNESS ASS'Y	1	Δ K 77096 ③	for Canada
2	2A6-82508-20	MAIN SWITCH ASS'Y	1		
3	1M1-82555-00	. DAMPER, main switch	1		
4	1M1-82556-00	DAMPER, main switch	2		
5	437-82516-00	COLLAR, main switch	2		
6	90201-05033	WASHER, plate (829-77178-00)	2		
7	92901-05100	WASHER, spring	2		
8	98501-05025	SCREW, panhead	2		
9	2A6-83371-10 2A6-83371-10	HORN	1	Δ K 77096 ③	
10	92901-06100	WASHER, spring	2		
11	97301-06012	BOLT, hexagon	2		
12	1M2-82310-40	IGNITION COIL ASS'Y	1		
13	90462-05005	CLAMP (363-15485-01)	1		
14	92901-06100	WASHER, spring	2		
15	92501-06020	SCREW, panhead	2		
16	437-82370-21	PLUG CAP ASS'Y	1		
	512-82370-10	PLUG CAP ASS'Y	1		for Canada
17	2A6-83350-60	FLASHER RELAY ASS'Y	1		
18	136-82540-00	NEUTRAL SWITCH ASS'Y	1		
19	90430-11034	. GASKET	1		
20	1M1-81970-60	RECTIFIER ASS'Y	1		
21	92901-05600	WASHER, plate	1		
22	92901-05100	WASHER, spring	1		
23	98501-05020	SCREW, panhead	1		
24	2A6-81915-00	PLATE, regulator fitting	1		
25	443-81910-60	VOLTAGE REGULATOR ASS'Y	1	U.R.	
	498-81910-21	VOLTAGE REGULATOR ASS'Y			
26	92901-05600	WASHER, plate	3		
27	92901-05100	WASHER, spring	3		
28	97301-05012	BOLT, hexagon	3		
29	1M1-82519-00	WIRE, earth lead	1		

Fig. 32 ELECTRICAL



REPAIR KIT



Fig. 33 REPAIR KIT

Ref. No.	Parts No.	Description	Qty	Applicable Machine No.	Remarks
33- 1	2A7-11630-00	PISTON ASS'Y (STD)	1s		
	2A7-11630-10	PISTON ASS'Y (1st O.S)	1s		
	2A7-11630-20	PISTON ASS'Y (2nd O.S)	1s		
	2A7-11630-30	PISTON ASS'Y (3rd O.S)	1s		
	2A7-11630-40	PISTON ASS'Y (4th O.S)	1s		
2	2A7-11631-00-96 . PISTON (55.96mm STD)	} U.R 1			
	2A7-11631-00-98 . PISTON (55.98mm STD)				
	2A7-11635-00 . PISTON (56.25mm 1st O.S)	1			} 3-8
	2A7-11636-00 . PISTON (56.50mm 2nd O.S)	1			
	2A7-11637-00 . PISTON (56.75mm 3rd O.S)	1			
	2A7-11638-00 . PISTON (57.00mm 4th O.S)	1			
3	2A7-11610-00 . PISTON RING SET (STD)	1s			} 3-9
	2A7-11610-10 . PISTON RING SET (1st O.S)	1s			
	2A7-11610-20 . PISTON RING SET (2nd O.S)	1s			
	2A7-11610-30 . PISTON RING SET (3rd O.S)	1s			
	2A7-11610-40 . PISTON RING SET (4th O.S)	1s			
4	251-11633-00 . PIN, piston	1			3-11
5	93450-17044 . CIRCLIP	2			3-12
6	2A7-11650-00	CONNECTING ROD ASS'Y	1s		
7	2A6-11651-01 . ROD, connecting	1			3-4
8	248-11681-01 . PIN, crank	1			3-5
9	93310-42231 . BEARING, con-rod big end	1			3-6
10	90209-22071 . WASHER (164-11685-00)	2			3-7
11	93310-216E1 . BEARING, con-rod small end	1			3-10

NUMERICAL INDEX



NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
22-12	1A0-26242-01	29- 3	1M1-83536-00	8-20	1W1-15618-01
24- 4	1A0-85720-02	29- 4	1M1-83578-00	8- 3	1W1-15621-00
27-17	1E2-25155-00	22- 3	1M1-83973-50	8-11	1W1-15641-00
21-15	1E6-23441-00	22-43	1M1-83980-30	8-16	1W1-15666-00
22- 2	1E6-26241-00	28-10	1M1-84124-60	4- 8	1W1-16351-00
32-30	1E6-82110-11	28- 1	1M1-84130-60-98	4-14	1W1-16356-00
29-11	1E6-83524-60	28-11	1M1-84133-60	4-19	1W1-16357-00
13- 5	1E7-13176-00	28-13	1M1-84137-60	4-11	1W1-16358-00
20-10	1E7-23128-00	28- 4	1M1-84164-60	4-20	1W1-16380-00
20-28	1E7-23181-00	28- 6	1M1-84195-61	5-11	1W1-17471-01
4- 4	1G8-16371-00	30- 1	1M1-84510-60	7- 5	1W1-18101-01
27-25	1G8-25412-00	30- 2	1M1-84511-60	7- 6	1W1-18136-00
22- 6	1J3-83912-20	30- 7	1M1-84512-60	6-11	1W1-18140-00
20-14	1L9-23166-00	30- 3	1M1-84514-60	6-12	1W1-18177-00
12-20	1M1-14752-01	30-26	1M1-84517-00	6- 3	1W1-18185-00
19- 1	1M1-21511-00	30- 5	1M1-84521-60	7-10	1W1-18197-01
19-14	1M1-21621-00	30- 4	1M1-84523-60	6- 1	1W1-18541-00
17- 4	1M1-22213-01	30- 6	1M1-84524-60	6- 5	1W1-18561-00
17- 3	1M1-22216-00	30- 9	1M1-84526-60	16-25	1W1-22178-10
17- 2	1M1-22219-00	30-11	1M1-84527-60	16-26	1W1-22187-00
17- 9	1M1-22482-00	30-19	1M1-84553-00	23- 8	1W1-24612-00
17- 7	1M1-22496-02	30-12	1M1-84553-10	27- 1	1W1-25311-00-98
25- 5	1M1-24748-00	30-20	1M1-84553-10	1-20	1W2-11181-00
22-13	1M1-26249-01	30-13	1M1-84553-20	12-17	1W2-14714-00
18- 5	1M1-27411-02-33	30-33	1M1-85131-10	12- 9	1W2-14771-00
18- 6	1M1-27421-02-33	30-27	1M1-85132-62	5- 2	1W2-17151-00
32-20	1M1-81970-60	32-12	1M2-82310-40	5- 6	1W2-17161-00
32-29	1M1-82519-00	26- 7	1T1-25194-00	5-19	1W2-17241-00
32-39	1M1-82519-00	27- 7	1T2-25394-00	27-34	1W2-25388-00
32- 3	1M1-82555-00	22- 3	1T2-83972-00	27-21	1W2-25389-00
32- 4	1M1-82556-00	24- 2	1T9-21771-00	14- 3	1W2-85509-20
31- 3	1M1-83309-60	31- 9	1T9-83330-60	14-13	1W2-85519-20
31-11	1M1-83309-60	1-18	1W1-11351-00	22-45	1Y1-26290-00
31- 4	1M1-83313-60	3- 2	1W1-11412-01	22-44	1Y1-26290-10
31-12	1M1-83313-60	3- 3	1W1-11422-01	26-35	102-25137-00
31- 7	1M1-83318-00	5-35	1W1-15381-00	7-12	102-18137-00-10
29-10	1M1-83526-00	2- 6	1W1-15451-00	32-35	104-82141-09

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
26-32	109-25136-00	21- 5	156-23412-00	2-11	2A6-15456-00
26- 9	109-25315-00	11-24	164-14137-00	2- 4	2A6-15484-00
14-12	110-81345-21	21- 1	164-23462-00	8- 1	2A6-15611-00
31- 2	115-83311-60	11-20	166-14116-13	8- 9	2A6-15660-00
31-10	115-83311-60	11- 5	168-14190-25	3-22	2A6-16111-00
32-38	116-82151-00	11-17	174-14123-00	5- 7	2A6-17121-00
21- 7	122-23411-00	11-18	174-14134-00	5- 5	2A6-17131-00
21- 5	122-23412-00	5-32	174-17461-60	5-22	2A6-17211-00
29- 2	122-83516-10	11-37	183-14196-00	5-14	2A6-17221-00
29- 6	122-83516-10	11-38	183-14197-01	5-20	2A6-17231-00
13- 1	126-13116-00	26-13	183-25118-00	5-21	2A6-17251-00
11-29	127-14161-00	26-19	183-25149-00	5-17	2A6-17261-00
11-34	132-14173-00	1-33	2A6-11127-00	5- 1	2A6-17411-00
23-25	132-14518-00	1-34	2A6-11128-00	5-13	2A6-17421-00
7- 2	132-18113-01	1-35	2A6-11129-00	9- 2	2A6-17831-00
23-18	132-24521-00	1-30	2A6-11161-00	9- 6	2A6-17841-00
23-19	132-24522-00	1-31	2A6-11162-00	7- 1	2A6-18111-00
23-22	132-24531-00	3- 1	2A6-11100-01	7- 8	2A6-18120-00
6-15	136-18542-00	3- 4	2A6-11651-01	6- 9	2A6-18511-00
32-18	136-82540-00	13-11	2A6-13101-00	6-10	2A6-18512-00
13-12	137-13137-00-03	13-25	2A6-13115-00	6- 7	2A6-18531-00
13-12	137-13137-00-05	13-30	2A6-13164-00	6- 8	2A6-18535-00
13-12	137-13137-00-10	13- 8	2A6-13178-00	15- 1	2A6-21110-00-33
13-13	137-13138-01	10-15	2A6-14411-00	15-20	2A6-21308-00
11- 4	137-14143-27	10-17	2A6-14412-00	15- 2	2A6-21471-00-33
11- 4	137-14143-28	10-24	2A6-14417-00	19- 7	2A7-21611-00
11- 4	137-14143-30	10-25	2A6-14433-00	19- 8	2A6-21617-00
11- 3	137-14186-01	10-16	2A6-14450-00	19-13	2A6-21639-00
4- 7	137-16325-70	10-18	2A6-14452-00	24- 1	2A6-21751-00
5-27	137-17417-00-05	12- 1	2A6-14610-00	24- 6	2A6-21796-00
23-23	137-24523-00	12-19	2A6-14753-00	16- 1	2A6-22110-00-33
27- 9	148-25115-00	12- 5	2A6-14772-00	16- 9	2A6-22151-00
11-32	152-14174-00	1- 1	2A6-15111-01	16-10	2A6-22152-00
12- 2	152-14613-00	1- 2	2A6-15121-00	16-21	2A6-22179-00
11-30	156-14135-00	2-10	2A6-15416-00	17- 1	2A6-22210-00
8- 2	156-15618-01	2- 5	2A6-15431-00	16-11	2A6-22311-00-98
21- 2	156-23411-00	2- 2	2A6-15455-00	16-16	2A6-22318-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
17- 8	2A6-22493-00	23- 6	2A6-24248-00	29- 1	2A6-83570-30
20- 1	2A6-23101-00	23- 7	2A6-24249-00	20-43	2A6-83595-00
20-23	2A6-23111-00	23- 9	2A6-24611-00	12-29	2A6-83596-00
20- 5	2A6-23119-00	25- 6	2A6-24738-00	22-18	2A6-83922-00
20- 9	2A6-23119-00	25- 1	2A6-24770-90	28- 5	2A6-84110-60
20-13	2A6-23124-00	25- 2	2A6-24771-00	20-32	2A6-84118-00
20- 2	2A6-23126-00-38	26- 2	2A6-25104-00	20-33	2A6-84119-00
20- 6	2A6-23136-00-38	26- 1	2A6-25111-00-98	28- 7	2A6-84120-60
20-21	2A6-23141-00	26-24	2A6-25120-00-98	30- 8	2A6-84551-60-33
20-11	2A6-23144-00	27- 2	2A6-25304-00	1-21	2A7-11111-00
20- 3	2A6-23145-00	27-14	2A6-25320-00-98	1-19	2A7-11311-00
20- 7	2A6-23145-00	27-22	2A6-25381-00	3- 9	2A7-11610-00
20-22	2A6-23147-00	27-24	2A6-25449-10	3- 9	2A7-11610-10
20-15	2A6-23151-00	22- 1	2A6-26111-00	3- 9	2A7-11610-20
20- 4	2A6-23156-00	22-25	2A6-26311-00	3- 9	2A7-11610-30
20- 8	2A6-23156-00	22-26	2A6-26312-00	3- 9	2A7-11610-40
20-16	2A6-23157-00	22-30	2A6-26335-01	33- 1	2A7-11630-00
20-29	2A6-23167-00	22-34	2A6-26341-01	33- 1	2A7-11630-10
20-17	2A6-23170-00	22-36	2A6-26397-00	33- 1	2A7-11630-20
20-19	2A6-23191-00	18-11	2A6-27211-00-33	33- 1	2A7-11630-30
20-18	2A6-23192-00	18- 1	2A6-27311-00	33- 1	2A7-11630-40
20-12	2A6-23193-00	15-22	2A6-28100-10	3- 8	2A7-11631-00-96
20-25	2A6-23317-00	32-24	2A6-81915-00	3- 8	2A7-11631-00-98
20-38	2A6-23318-00	32-36	2A6-82115-00	3- 8	2A7-11635-00
20-37	2A6-23319-00	32-31	2A6-82122-00	3- 8	2A7-11636-00
20-24	2A6-23340-00-33	32-32	2A6-82131-00	3- 8	2A7-11637-00
20-27	2A6-23346-00	32- 2	2A6-82508-20	3- 8	2A7-11638-00
15-16	2A6-23408-00	22-16	2A6-82920-90	33- 6	2A7-11650-00
21-10	2A6-23435-00-98	32-17	2A6-83350-60	11- 1	2A7-14101-00
20-20	2A6-23489-00	32- 9	2A6-83371-10	10-13	2A7-14453-00
23- 1	2A6-24110-00-04	29- 8	2A6-83513-00	2- 1	2A7-15411-00
23-12	2A6-24181-00	29- 9	2A6-83519-00	4- 2	2A7-16150-00
23-16	2A6-24182-00	29- 7	2A6-83520-00	4- 1	2A7-16301-00
23- 2	2A6-24244-00	29- 5	2A6-83540-00	19-12	2A7-21620-00
23- 3	2A6-24245-00	29-17	2A6-83550-00	15-11	2A7-21711-00-01
23- 4	2A6-24246-00	29-18	2A6-83560-00	15-12	2A7-21721-00-01
23- 5	2A6-24247-00	29- 1	2A6-83570-11	15-13	2A7-21786-00

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
32- 1	2A7-82590-20	11- 7	314-14185-00	32- 5	437-82516-00
32- 1	2A7-82590-50	18-15	322-27231-00	22-41	437-83936-00
14- 1	2A7-85500-20	1-27	328-15316-00	22-15	437-83976-02
14- 4	2A7-85511-20	31- 5	341-83312-70	30-10	437-84525-60
14- 5	2A7-85512-20	31-13	341-83332-70	32-25	443-81910-60
14- 6	2A7-85513-20	28- 8	341-84397-61	14-11	445-85528-20
14-14	2A7-85515-20	10- 2	345-13610-70	23-24	447-24524-00
32-41	2A7-85540-20	10- 3	345-13613-70	23-26	447-24525-00
32-42	2A7-85546-00	10- 4	345-13616-70	30-33	449-85131-01
14- 2	2A7-85550-20	11-33	353-14138-00	17-11	483-22128-00
14-10	2A7-85580-20	32-37	353-82150-00	11-15	493-14122-00
11- 6	214-14195-00	20-41	355-85111-00	11-16	493-14133-00
25- 4	214-24724-00	22-17	361-82921-31	1-25	498-15371-00
22-22	214-83913-00	13-21	363-13133-01	22-35	498-26372-00
11-25	246-14126-00	11-21	363-14137-00	32-25	498-81910-21
11-22	246-14132-00	11-28	363-14155-00	22- 4	498-82910-20
3- 5	248-11681-01	11-27	363-14198-00	22- 5	498-82911-00
11-23	248-14131-00	32-40	371-82530-01	28-12	498-84128-60
8-12	248-15654-00	28- 9	371-84312-60	28- 2	498-84145-60
9- 1	248-17861-00	22-31	382-26372-01	28- 3	498-84163-60
26-20	248-25135-10	10- 7	401-13565-00	11-14	500-14115-00
26-30	248-25138-10	11-26	401-14158-00-33	10-22	509-14457-00
27- 8	248-25317-00	1-28	401-15317-00	25- 3	509-24724-00
26-26	248-25351-00	2-13	401-15362-00	32-16	512-82370-10
27-16	248-25351-00	8-14	401-15676-00	5-26	525-15651-00
3-11	251-11633-00	7- 7	401-18178-00	16- 2	537-22141-01
11- 2	260-14142-22	16- 4	401-22127-00	11-10	539-14181-04-33
23-11	278-24181-00	16- 3	401-22128-01	13- 3	558-13175-00
11-31	304-14171-00	26-15	401-25181-01	11- 3	558-14141-32
11- 9	304-14184-00	27-33	401-25367-00	11-13	558-14147-00
11-35	304-14261-00	13-20	402-13552-00	4- 6	558-16321-01
1-15	304-15128-00	16- 6	403-22124-00	26-27	559-25155-00
23-17	304-24500-05	23-21	434-24532-00	12-24	565-14747-00
23-20	304-24515-00	22-14	434-26243-00	1-32	579-11162-00
4- 5	307-16357-00	26-21	437-25330-00	21- 8	583-23416-01
10- 1	314-13621-02	27-12	437-25330-00	15-17	584-23484-01
11-19	314-14112-20	32-16	437-82370-21	26-28	90101-06278

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
27-18	90101-06278	16- 5	90201-06067	17-16	90240-12059
15- 5	90105-08022	19- 4	90201-06067	18-20	90249-12008
15- 8	90105-08099	19-18	90201-06067	15-19	90269-04003
15-10	90105-10037	23-13	90201-06067	3-26	90280-03017
21-11	90105-14060	24- 7	90201-06067	3-23	90282-05005
22- 7	90109-06410	30-17	90201-06074	22-42	90338-09012
28-14	90109-08448	30-24	90201-06074	1-10	90340-12005
17-12	90109-10453	30-30	90201-06075	17-10	90380-12051
18- 2	90109-10473	26-31	90201-07076	9- 4	90381-08002
16-24	90109-10483	22- 8	90201-08083	29-16	90385-06001
1-36	90116-06016	22-20	90201-08083	16- 5	90386-18028
1-17	90116-08104	1-22	90201-08100	12-11	90387-06388
27-26	90116-10221	12-26	90201-08113	19- 6	90387-06388
24-16	90122-06001	13- 2	90201-08624	30-14	90387-06553
22-32	90123-08046	9- 3	90201-10123	30-21	90387-06554
4-24	90149-08108	13- 7	90201-10135	10-29	90387-07391
7-14	90149-08111	8- 4	90201-12541	24-13	90387-07391
4-10	90159-05011	3-15	90201-12593	12-25	90387-08258
7-15	90170-08029	18-12	90201-14212	26-12	90387-12095
22-24	90170-10038	4-22	90201-14217	26-14	90387-12100
27-27	90170-10219	27-35	90201-15238	27-20	90387-15524
3-17	90170-12067	5- 8	90201-15563	27-32	90387-15524
4-15	90170-14171	5-23	90201-15563	3-21	90387-20488
26-37	90171-12005	8-17	90201-17327	5-31	90387-20503
27-36	90171-14006	4- 3	90201-17543	13-16	90430-04004
18-21	90175-06013	4-18	90201-17550	20-42	90430-06012
24-15	90179-06013	5-18	90201-18135	4-25	90430-08069
22-33	90179-08148	5- 3	90201-20266	32-19	90430-11034
1-13	90179-10201	26-18	90201-20269	1- 9	90430-12038
3-25	90179-12044	5-15	90201-22555	13-29	90445-05018
5-34	90179-16226	3-24	90204-12007	13-31	90445-05021
21- 9	90179-25033	15-18	90206-04003	13-23	90445-07036
15- 7	90185-08054	3- 7	90209-22071	1-26	90445-07340
20-31	90185-08054	7-16	90215-08014	32-34	90445-08357
21-14	90185-08054	4-16	90215-14122	23-28	90445-09086
16- 8	90185-12046	5-33	90215-16127	13-27	90445-09100
32- 6	90201-05033	18-16	90240-06006	23-10	90445-09115

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
24- 5	90445-09361	6-13	90506-09156	2- 3	92501-06030
12-18	90460-37026	26-22	90506-16036	2- 8	92501-06030
10-11	90460-43053	27-13	90506-16036	2- 9	92501-06040
10-26	90460-45040	18- 4	90507-29008	1- 5	92501-06050
10-12	90460-49058	18- 7	90508-20023	1- 6	92501-06060
10-14	90460-64065	4-21	90508-20345	1- 7	92501-06070
74-14	90462-05004	8-15	90508-26346	1- 8	92501-06075
10-10	90462-05005	7-11	90508-32349	1-16	92501-08010
32-13	90462-05005	18-14	90508-32354	5-36	92701-06012
13-22	90467-08003	16-23	90508-35350	15-21	92701-06018
23-29	90467-08003	26- 8	90560-12138	10- 5	92901-03100
10-23	90467-15012	8-18	90560-17032	11-12	92901-04100
22-29	90468-08086	4-17	90560-17147	14- 9	92901-04100
13-24	90468-02025	8- 8	91316-08025	10-20	92901-05100
13-28	90468-02033	11-36	91401-16015	13-14	92901-05100
13-26	90468-02078	16-31	91401-20012	16-14	92901-05100
21-12	90468-20082	17-15	91401-20025	16-28	92901-05100
24-11	90468-10050	18- 9	91401-25012	22-39	92901-05100
29-12	90468-12007	18-18	91401-25012	30-35	92901-05100
8-10	90468-26048	17-18	91401-30022	32- 7	92901-05100
26-25	90480-10068	26-16	91401-30022	32-22	92901-05100
27-15	90480-10068	27-23	91401-30030	32-27	92901-05100
15-14	90480-12053	17- 5	91401-30040	30-36	92901-05200
10-28	90480-14101	32-33	91401-03040	10-21	92901-05600
12-10	90480-14101	24-10	91701-05050	22-38	92901-05600
24-12	90480-14102	16-30	91701-06042	32-21	92901-05600
19- 5	90480-14198	18- 8	91701-08038	32-26	92901-05600
10-27	90480-18171	1-14	91810-16016	10-31	92901-06100
24- 3	90480-18171	1- 3	91810-19020	12- 3	92901-06100
19-15	90480-30167	1- 4	91830-21014	12-12	92901-06100
13-19	90501-02018	2- 7	91830-21014	12-22	92901-06100
18-19	90501-10245	12-21	92501-06012	16-20	92901-06100
8- 6	90501-10459	14-15	92501-06012	19- 3	92901-06100
4- 9	90501-20474	24- 9	92501-06016	19-10	92901-06100
17- 6	90501-90484	2-12	92501-06020	19-17	92901-06100
15-15	90502-09024	20-34	92501-06020	20-35	92901-06100
7- 9	90506-08155	32-15	92501-06020	20-40	92901-06100

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
20-45	92901-06100	18-10	92901-08600	5-29	93306-30411
22-10	92901-06100	20-30	92901-08600	5-10	93310-216E1
22-21	92901-06100	22-27	92901-08600	3- 6	93310-42231
23-14	92901-06100	15- 9	92901-10100	5-25	93311-31515
24- 8	92901-06100	31-15	92901-10100	5- 9	93311-41530
25- 8	92901-06100	17-13	92901-10200	6- 2	93315-21813
29-14	92901-06100	3-16	92901-12100	26-17	93410-20009
30-29	92901-06100	16- 7	92901-12100	5- 4	93410-20038
32-10	92901-06100	26-36	92901-12200	5-16	93410-22039
32-14	92901-06100	17-17	92901-12600	8-13	93410-30012
4-12	92901-06200	13- 6	93101-10002	6- 6	93430-08006
18-17	92901-06200	7- 4	93101-12060	13- 9	93430-08006
20-36	92901-06200	8-19	93101-17062	8- 5	93430-08007
10- 9	92901-06600	26-11	93102-18008	18-13	93430-10015
10-30	92901-06600	3-14	93102-25061	7-13	93430-10016
12-23	92901-06600	5-30	93102-26042	5-24	93440-15012
14-16	92901-06600	3-19	93103-28011	5-28	93440-15012
15- 4	92901-06600	26-33	93104-07003	3-12	93450-17044
16-32	92901-06600	4-23	93104-14004	21- 3	93501-04011
19-11	92901-06600	16-22	93104-14044	4-26	93503-16010
20-44	92901-06600	27-11	93104-22018	8- 7	93503-16010
29-15	92901-06600	26-23	93105-47007	21- 6	93503-16010
30-15	92901-06600	27-31	93106-26005	13-18	93505-32002
30-22	92901-06600	9- 8	93109-08017	13- 4	93603-22028
30-32	92901-06600	24-17	93210-04122	6- 4	93604-12037
12- 7	92901-08100	22-28	93210-07100	6-14	93604-30018
12-15	92901-08100	1-29	93210-11073	26- 3	94127-21377
12-27	92901-08100	9- 7	93210-14104	27- 3	94135-18378
16-18	92901-08100	26-34	93210-14104	26- 4	94227-21123
20-26	92901-08100	3-20	93210-18023	27- 4	94232-18119
25-10	92901-08100	2-14	93210-19123	27- 5	94330-18087
28-16	92901-08100	27-10	93306-20203	26- 3	94330-21084
9- 5	92901-08200	3-13	93306-20517	26- 6	94416-21206
15- 6	92901-08200	26-10	93306-30102	27- 6	94418-18171
28-17	92901-08200	27-30	93306-30203	27-28	94580-15118
12- 8	92901-08600	5-10	93306-30304	27-29	94680-15001
12-16	92901-08600	3-18	93306-30405	1-24	94701-00135

NUMERICAL INDEX

Ref No.	Parts No.	Ref No.	Parts No.	Ref No.	Parts No.
13-15	95301-05600	22- 9	97301-06022		
22-40	95301-05600	22-19	97301-06022		
30-34	95301-05600	10- 8	97301-06025		
16-29	95301-05700	10-32	97301-06025		
4-13	95301-06600	12-13	97301-06025		
12- 4	95301-06600	19- 2	97301-06025		
26-29	95301-06600	30-16	97301-06025		
27-19	95301-06600	29-13	97301-06030		
30-25	95301-06600	30-23	97301-06035		
30-31	95301-06600	16-17	97301-08012		
18-23	95301-06700	25- 9	97301-08012		
30-18	95301-06800	12- 6	97301-08016		
1-23	95301-08600	12-14	97301-08016		
28-15	95301-08600	12-28	97301-08030		
31-16	95301-10600	5-12	97321-06012		
18- 3	95301-10700	7- 3	97321-06020		
17-14	95302-10900	31- 6	97701-03520		
31- 8	95303-08800	31-14	97701-03520		
22-11	95601-06100	23-27	98501-03006		
22-23	95601-06100	14- 8	98501-04014		
1-11	95611-10630	14- 7	98501-04032		
1-12	95611-10640	10-19	98501-05012		
21-13	95811-08055	16-12	98501-05015		
21-16	95821-08035	13-10	98501-05016		
16-13	97301-05012	22-37	98501-05018		
32-28	97301-05012	32-23	98501-05020		
15- 3	97301-06012	32- 8	98501-05025		
20-46	97301-06012	16-27	98501-05040		
25- 7	97301-06012	11-11	98502-04014		
32-11	97301-06012	10- 6	98512-03008		
16-19	97301-06016	9- 9	98601-06030		
19- 9	97301-06016	13-17	98901-04008		
19-16	97301-06016				
23-15	97301-06016				
30-28	97301-06016				
18-22	97301-06020				
20-39	97301-06020				



YAMAHA MOTOR CO., LTD.

PRINTED IN JAPAN

First edition Mar., 1977

(LIT-10012-A7-00)(2A7-28198-60)