

YAMAHA



PARTS CATALOGUE


PW50'97 (3PTP) EUROPE, S.AFRICA

PW50'97 (3PTN) PORTUGAL

YAMAHA
GENUINE
Parts & Accessories

173PT-300E1

[Regresar](#)



A3

FOREWORD

This Parts Catalogue is related to the parts for the model(s) in the below frame. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

PW50'97(3PTP/3PTN)

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News. It is advisable that you make necessary corrections to the Parts Catalogue according to the Yamaha Parts News.

2. Abbreviations

The following abbreviations are used in this Parts Catalogue.

- "UR" Use specified parts number.
- "UN" Use as many as needed.
- "AP" Alternate Parts
- "LM" Local Made (Parts need to be ordered locally)
- "F#" Frame No. (Applicable machine No.)

3. Parts, which are to be supplied in an assembly, are listed with a dot (.) in front of the part name as shown below.

EXAMPLE

CARBURETOR ASSY
 . JET, PILOT
 . NOZZLE, MAIN

4. Number of component for assembly

The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

EXAMPLE


PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	. BULB (6V-18W)	1	

5. Applicable colors of graphics are represented in the "REMARKS" as shown below.


PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	FUEL TANK COMP.	1	MAXIM RED
3J1-24240-10	. GRAPHIC, FUEL TANK	1	for MXR

6. Applicable Serial No.

① Engine Serial No.



② Frame Serial No.




7. Note that the illustrations are for reference in finding parts numbers, not to be used for assembling. When assembling, please use the applicable service manual.
8. The asterisk (*) before a reference number indicates modification items after the first edition.


MODEL LABEL

(1) A label called "Model Label" is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross-refer the "model code - production code No." in the catalogue to the "model code - production code No." indicated on the Model Label affixed onto the product concerned.


(2) "Model Label" Indication



- ① Model Type Code
- ② Production Code No.
- ③ Colouring Type



(3) Model Label Affixing Location



(4) Model Code - Production Code Number of Model Listed in This Parts Catalog

Model code	Production code No.	Country (destination)	Model code	Production code No.	Country (destination)
3PTP	010	AUSTRIA			
	020	BELGIUM			
	020	HOLLAND			
	030	SWITZERLAND			
	040	DENMARK			
	040	FINLAND			
	050	SPAIN			
	060	ENGLAND			
	070	GREECE			
	080	SWEDEN			
	090	S.AFRICA			
3PTN	020	PORTUGAL			

(5) Colouring Information

Colouring type code	Colour code	Colour Name	Abbreviation
A	0206	PURPLISH WHITE SOLID 1	PWS1

CONTENTS

ENGINE

Cylinder	B2
Crankshaft · Piston	B3
Oil Pump	B4
Intake	B5
Carburetor	B6
Exhaust	B7
Crankcase	B8
Starter	B9
Clutch	B10
Transmission	B11

CHASSIS


Frame	B12
Front Fender	B13
Side Cover	B14
Oil Tank	B15
Rear Arm · Suspension	C2
Drive Shaft	C3

Front Fork	C4
Fuel Tank	C5
Seat	C6
Front Wheel	C7
Rear Wheel	C8
Steering Handle · Cable	C9
Stand · Footrest	C10
Generator	C11
Handle Switch · Lever	C12
Electrical 1	C13

INDEX

NUMERICAL INDEX	L1 ~ L2
-----------------------	---------

FIG. 1 CYLINDER




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4J2-11111-00	HEAD, cylinder 1	1	
2	517-11181-00	GASKET, cylinder head 1	1	
3	94701-00258	PLUG, spark (NGK BPR4HS)	1	
4	4J2-11311-00	CYLINDER 1	1	UR
	44V-11311-00	CYLINDER 1	1	UR FOR PORTUGAL
5	3PT-11351-00	GASKET, cylinder	1	
6	90116-06418	BOLT, stud	4	
7	95707-06500	NUT, flange	4	




3PT110-0010

FIG. 2 CRANKSHAFT • PISTON



3PT110-0020

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3L5-11400-01	CRANKSHAFT ASSY	1	
2	3L5-11412-00	•CRANK 1	1	
3	3L5-11422-01	•CRANK 2	1	
4	1YU-11681-00	•PIN, crank 1	1	
5	2E9-11651-00	•ROD, connecting	1	
6	93310-418N7	•BEARING, cylindrical	1	
7	90280-03017	KEY, woodruff	1	
8	92907-12600	WASHER, plate	1	
9	92907-12100	WASHER, spring	1	
10	95307-12700	NUT	1	
11	93308-20326	BEARING	2	
12	93102-17067	OIL SEAL	1	
13	93102-23174	OIL SEAL	1	
14	18U-11631-00-A0	PISTON (STD)	1	
	18U-11635-00	PISTON (0.25MM O/S)	1	AP
	18U-11636-00	PISTON (0.50MM O/S)	1	AP
	44V-11631-00-A0	PISTON (STD)	1	
	44V-11635-00	PISTON (0.25 MM O/S)	1	AP } FOR PORTUGAL
15	2E9-11633-00	PIN, piston	1	
16	260-11601-03	PISTON RING SET (STD)	1	
	260-11601-13	PISTON RING SET (0.25MM O/S)	1	AP
	260-11601-23	PISTON RING SET (0.50MM O/S)	1	AP
	260-11601-33	PISTON RING SET (STD)	1	
	260-11601-43	PISTON RING SET (0.25MM O/S)	1	AP } FOR PORTUGAL
17	93450-11021	CIRCLIP	2	
18	93310-210M0	BEARING, cylindrical	1	



3PT110-0030

FIG. 3 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3L5-13101-00	OIL PUMP ASSY	1	
2	93101-10090	.OIL SEAL	1	
3	93210-26240	.O-RING	1	
4	90430-04004	.GASKET	1	
5	90149-04135	.SCREW	1	
6	384-13138-00	.PLATE, adjusting	1	
7	90170-10105	.NUT	1	
8	90401-10029	.BOLT, union	1	
9	3L5-13124-00	.GEAR, worm wheel (56T)	1	
10	91609-30014	.PIN, spring	1	
11	99080-07600	.CIRCLIP	1	
12	3L5-13161-00	PIPE, delivery 1	1	
13	90468-02033	CLIP	2	
14	98507-05020	SCREW, pan head	1	
15	98507-05035	SCREW, pan head	1	
16	17J-15416-00	COVER, oil pump	1	
17	3L5-15426-00	COVER, oil pump 2	1	
18	97707-50115	SCREW, tapping	1	





FIG. 4 INTAKE

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3L5-13610-00	REED VALVE ASSY	1	
2	3L5-13613-00	•REED, valve	1	
3	3L5-13616-00	•STOPPER, reed valve	1	
4	98507-03010	•SCREW, pan head	2	
5	92907-03100	•WASHER, spring	2	
6	3L5-13624-00	•PLATE, reed valve	1	
7	3HK-13621-00	GASKET, valve seat	1	
8	3L5-13622-10	GASKET, valve seat	1	
9	3L5-13555-00	MANIFOLD, intake	1	
10	98507-06020	SCREW, pan head	4	
11	4X4-14411-00	CASE, air cleaner 1	1	
12	4X4-14412-00	CAP, cleaner case 1.	1	
13	4X4-14451-00	ELEMENT, air cleaner	1	
14	98507-06045	SCREW, pan head	1	
15	92907-06600	WASHER, plate	1	
16	4X4-14453-00	JOINT, air cleaner 1	1	
17	90467-20023	CLIP	1	
18	4X4-14493-01	STAY 1	1	
19	90159-06013	SCREW, with washer	1	


FIG. 5 CARBURETOR



3PT110-4050

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4X4-14101-00	CARBURETOR ASSY 1	1	
2	3L5-14184-00	.GASKET, float chamber	1	
3	620-14231-14	.JET, main (# 70)	1	UR STD
	620-14231-13	.JET, main (# 85)	1	UR
	620-14231-15	.JET, main (# 75)	1	UR
4	3L7-14141-12	.NOZZLE, main	1	
5	3L5-14142-40	.JET, pilot (# 40)	1	
6	98503-04014	.SCREW, pan head	4	
7	3L5-14198-00	.GASKET	1	
8	17L-14108-00	.CABLE ADJUST SCREW SET	2	
9	1R0-14169-00	.CAP	2	
10	3L6-14185-01	.FLOAT	1	
11	3L5-14190-01	.NEEDLE VALVE ASSY	1	
12	603-14188-00	.PIN, float	1	
13	3L5-14112-40	.VALVE, throttle 1	1	
14	36R-1490J-00	.NEEDLE SET	1	
15	174-14131-01	.SPRING, throttle valve	1	
16	36R-14103-00	.THROTTLE SCREW SET	1	
17	58E-14171-00	.PLUNGER, starter	1	
18	509-14135-00	.SPRING, plunger	1	
19	98501-05102	.SCREW, pan head	1	
20	92990-05100	.WASHER, spring	1	
21	17L-14104-00	.AIR SCREW SET	1	
22	95303-05800	.NUT	1	
23	98501-05030	.SCREW, pan head	1	
24	214-14197-00	.PIPE	1	
25	17L-14104-00	.AIR SCREW SET	1	

FIG. 6 EXHAUST




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4X4-14610-01	EXHAUST PIPE ASSY 1	1	
2	4X4-14623-10	GASKET, exhaust pipe	1	
3	90149-06113	SCREW	2	
4	97007-08020	BOLT	1	
5	92907-08100	WASHER, spring	1	
6	92907-08600	WASHER, plate	1	
7	4X4-14708-00	PROTECTOR ASSY	1	
8	90157-05003	SCREW, pan head	4	
9	90202-04214	WASHER, plate	2	
10	3RV-14766-00	WASHER, protector	6	
11	4X4-14714-00	GASKET, muffler	1	
12	90467-22048	CLIP	1	
13	4X4-14750-00	SILENCER ASSY	1	
14	92501-06008	SCREW, pan head	1	
15	92990-06100	WASHER, spring	1	
16	92901-08800	WASHER, plate	1	
17	97007-06016	BOLT	1	
18	92907-06100	WASHER, spring	1	
19	92907-06600	WASHER, plate	1	



3PT100-5080

FIG. 7 CRANKCASE




3PT100-5070

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4X4-15111-00	CRANKCASE 1	1	
2	99510-12016	PIN, dowel	2	
3	98507-06045	SCREW, pan head	8	
4	4J2-15121-00	CRANKCASE 2	1	
5	3L5-15128-00	HOLDER	1	
6	98507-06012	SCREW, pan head	1	
7	2E9-15316-00	DAMPER, engine mount 1	2	
8	4J2-15415-00	COVER, generator	1	
9	98507-05014	SCREW, pan head	3	
10	4X4-15421-01	COVER, crankcase 2	1	
11	3L5-17112-01	BUSH 1	1	
12	99510-12016	PIN, dowel	2	
13	3L5-15451-10	GASKET, crankcase cover 1	1	
14	98507-06035	SCREW, pan head	3	
15	98507-06025	SCREW, pan head	3	
16	90105-08103	BOLT, washer based	1	
17	90201-08087	WASHER, plate	1	
18	4J2-15363-00	PLUG, oil	1	
19	93210-14104	O-RING	1	
20	90109-08582	BOLT	2	
21	4J2-15113-00	PLATE	1	
22	98507-06012	SCREW, pan head	1	
23	92907-06100	WASHER, spring	1	
24	4X4-15491-00	PROTECTOR	1	
25	4X4-15484-00	CLAMP 2	1	


FIG. 8 STARTER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3L5-15601-00	KICK SHAFT ASSY	1	
2	3L5-15664-00	GUIDE, spring	1	
3	90508-28399	SPRING, torsion	1	
4	17J-15620-01	KICK CRANK ASSY	1	
5	2T4-15618-00	COVER, kick lever	1	
6	97017-06025	BOLT	1	
7	3L5-15631-00	GEAR, kick pinion (13T)	1	
8	3L5-15673-00	CLIP	1	
9	3L5-13178-00	GEAR, pump drive	1	
10	93109-15001	OIL SEAL	1	



3PT110-0080

FIG. 9 CLUTCH




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3L5-16111-00	GEAR, primary drive (33T)	1	
2	3L5-16115-00	ABSORBER 1	1	
3	3L5-16125-00	ABSORBER 2	1	
4	3L5-16114-00	PLATE, thrust 2	1	
5	3L5-16181-01	SPACER 1	1	
6	90387-16730	COLLAR	1	
7	90282-05034	KEY, straight	1	
8	90208-10012	WASHER, conical spring	1	
9	90170-10219	NUT	1	
10	99009-16400	CIRCLIP	1	
11	90201-16383	WASHER, plate	1	
12	3L5-16620-03	CLUTCH CARRIER ASSY	1	
13	3L5-16628-02	•WASHER	2	
14	2T4-16629-00	•DAMPER, clutch weight	2	
15	3L5-16627-02	•SPRING, clutch weight 2	2	
16	38R-16633-00	•SHAFT, clutch weight	4	
17	3L5-16611-02	CLUTCH HOUSING COMP.	1	
18	99009-16400	CIRCLIP	1	



3PT110-0090

FIG. 10 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3L5-17410-00	MAIN AXLE COMP. (15T)	1	
2	3L5-17531-00	SHIM, pinion	1	
3	3L5-17471-00	PLATE, cover	1	
4	3L5-17473-00	STOPPER	1	
5	91316-08018	BOLT	2	
6	15L-17552-00	PINION, driven	1	
7	93306-20301	BEARING	1	
8	3L5-17537-00	SHIM, thrust	1	
9	3L5-17442-00	COLLAR, distance	1	
10	90149-45134	SCREW	1	
11	93102-15267	OIL SEAL	1	



3PT110-0100




FIG. 11 FRAME


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	38E-21110-01-33	FRAME COMP.	1	YAMAHA BLACK
2	95607-10200	NUT, self-locking	1	
3	90105-10731	BOLT, washer based	1	



3PT351-0110


FIG. 12 FRONT FENDER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3PT-21511-10	FENDER, front	1	
2	90159-08060	SCREW, with washer	2	
3	99241-00080	EMBLEM, YAMAHA	1	
4	38E-21513-00	STAY, fender 1	2	




3PT100-7120

FIG. 13 SIDE COVER



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3PT-21711-00	COVER, side 1	1	
2	90159-06060	SCREW, with washer	4	
3	90119-06060	BOLT, with washer	2	
4	4X4-24181-00	DAMPER, locating 1	2	
5	3PT-21781-00	EMBLEM 1	2	
6	3PT-21731-50	COVER, side 3	1	
7	3PT-21741-50	COVER, side 4	1	
8	90159-06058	SCREW, with washer	2	
9	50W-28100-00	TOOL KIT	1	


FIG. 14 OIL TANK



3PT110-0140


REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4X4-21751-00	TANK, oil	1	
2	1Y1-21770-01	OIL TANK CAP ASSY	1	
3	90480-10408	GROMMET	2	
4	4X4-21788-00	PIPE, oil	1	
5	90501-08410	SPRING, compression	1	
6	90467-08003	CLIP	2	
7	4X4-2172K-00	BRACKET 1	1	
8	4X4-21773-00	GROMMET	1	
9	4X4-21829-00	GUARD, mud	1	

FIG. 15 REAR ARM • SUSPENSION



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3L7-22110-00-98	REAR ARM COMP.	1	LOW GLOSS BLACK
2	90101-08461	BOLT	6	
3	92907-08100	WASHER	6	
4	4X4-22110-01	REAR ARM COMP.	1	
5	4J2-22174-01	END 1	1	
6	93306-20117	BEARING	1	
7	93106-24018	OIL SEAL	2	
8	90105-08066	BOLT, washer based	2	
9	95707-08500	NUT, flange	2	
10	90201-08326	WASHER, plate	4	
11	164-22216-00	BUSH, rear shock absorber	1	
12	3PT-22210-00-UJ	SHOCK ABSORBER ASSY, rear	2	RADICAL WHITE
13	97027-08016	BOLT	2	
14	92907-08100	WASHER, spring	2	
15	90201-126A7	WASHER, plate	2	
16	90201-067A0	WASHER, plate	2	
17	90105-08121	BOLT, washer based	2	

FIG. 16 DRIVE SHAFT




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	4J2-46151-01	HOUSING, drive shaft	1	
2	59M-46121-00	GEAR, drive pinion	1	
3	93306-20111	BEARING (B6201)	1	
4	3L5-46127-00	SHIM, drive pinion	1	
5	93306-20111	BEARING (B6201)	1	
6	90149-35133	SCREW	1	
7	90560-25185	SPACER	1	
8	4J2-46110-01	RING GEAR COMP.	1	
9	93306-20226	BEARING	1	
10	90560-15315	SPACER	1	
11	3L5-46114-00	PLATE, cover	1	
12	97017-06016	BOLT	2	
13	4J2-46154-02	COVER, housing	1	
14	98507-06016	SCREW, pan head	3	
15	164-22216-00	BUSH, rear shock absorber	1	
16	93306-20209	BEARING (B6202)	1	
17	93211-05393	O-RING	1	
18	3L7-46171-00	SHAFT DRIVE ASSY	1	
19	90501-60556	SPRING, compression	1	
20	15L-18473-00	RETAINER, spring	1	
21	93440-17138	CIRCLIP	1	




3PT110-0160

FIG. 17 FRONT FORK



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3PT-23100-00-EX	FRONT FORK ASSY	1	INK BLUE
2	4X4-23340-02-33	•UNDER BRACKET COMP.	1	YAMAHA BLACK
3	3YJ-23414-00.	•RACE, ball 4	1	
4	3PT-23110-00	•INNER TUBE COMP. 1	1	
5	2E9-23144-01	•SEAL, dust	1	
6	93450-30057	•CIRCLIP	1	
7	54V-23125-01	•METAL, slide 1	1	
8	2E9-23113-01	•COLLAR	1	
9	36R-23151-00	•SPRING, rebound	1	
10	4X4-23106-00-EX	•OUTER TUBE COMP. (L.H)	1	INK BLUE
11	4X4-23141-00	•SPRING, front fork	1	
12	3L6-23195-00	•RUBBER	1	
13	2E9-23143-00	•SEAT, spring lower	2	
14	3PT-23103-00-EX	•FRONT FORK COMP. (R.H)	1	INK BLUE
15	91317-06016	•BOLT	2	
16	4X4-23435-00	CROWN, handle	1	UNI CHROME (BLACK)
17	90105-10006	BOLT, washer based	3	
18	90209-10160	WASHER	1	
19	90201-10742	WASHER, plate	2	
20	2E9-23412-00	RACE, ball 2	1	
21	2E9-23413-01	RACE, ball 3	1	
22	3PT-23411-00	RACE, ball 1	1	
23	93505-32002	BALL	52	
24	4X4-21543-00	PLATE 1	1	
25	90159-06060	SCREW, with washer	2	

FIG. 18 FUEL TANK




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3PT-24110-10	FUEL TANK COMP.	1	
2	2FG-24610-00	CAP ASSY	1	
3	90445-09252	HOSE	1	
4	4X4-24500-00	FUEL COCK ASSY 1	1	
5	90480-18290	GROMMET	2	
6	90201-06407	WASHER, plate	2	
7	90387-077F4	COLLAR	2	
8	97007-06085	BOLT	1	
9	90176-06038	NUT, crown	1	
10	3R0-24181-00	DAMPER, locating 1	1	
11	59V-24173-00	BAND, tank fitting 1	1	
12	36E-24311-00	PIPE, fuel 1	1	
13	90467-12052	CLIP	2	
14	90445-09074	HOSE	1	
15	90467-08003	CLIP	2	
16	90159-06013	SCREW, with washer	1	
17	3PT-24240-30	GRAPHIC SET	1	



3PT100-7180


FIG. 19 SEAT

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3PT-24710-30	SINGLE SEAT ASSY	1	
2	3PT-24731-30	COVER, single seat	1	



3PT110-0190

FIG. 20 FRONT WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M0-25180-00-UJ	FRONT WHEEL COMP.	1	RADICAL WHITE
2	90560-10173	SPACER	1	
3	2E9-25116-00	FLANGE, spacer 2	1	
4	93106-17015	OIL SEAL	1	
5	2T4-25121-00-98	PLATE, brake shoe	1	LOW GLOSS BLACK
6	93109-34057	OIL SEAL	1	
7	3PT-W2535-00	BRAKE SHOE SET	1	
8	2E9-25133-00	SPRING, return	1	
9	90336-15033	PLUG, taper	1	
10	2T4-25155-00	LEVER, camshaft 1	1	
11	25K-25151-00	CAMSHAFT	1	
12	87007-05020	BOLT	1	
13	95307-05600	NUT	1	
14	94125-10850	TIRE (2.50-10)	1	UR INOUE
	94125-10851	TIRE (2.50-10 4PR M29)	1	UR BRIDGESTONE
15	94225-10270	TUBE (2.50/2.75-10)	1	INOUE
16	93306-20006	BEARING (B6200)	2	NTN
17	2T4-25185-00	RING 1	1	
18	4N0-25181-00	AXLE, wheel	1	
19	90387-10820	COLLAR	1	
20	90171-10004	NUT, castle	1	
21	91401-20020	PIN, cotter	1	
22	92901-10200	WASHER, plain	1	
23	36E-2639F-00	PLATE 1	3	UR FOR EUROPE



3PT351-0200

FIG. 21 REAR WHEEL




REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5M0-25390-00-UJ	REAR WHEEL COMP.	1	RADICAL WHITE
2	94125-10650	TIRE (2.50-10)	1	UR INOUE
	94125-10651	TIRE (2.50-10 4PR M29)	1	UR BRIDGESTONE
3	94225-10270	TUBE (2.50/2.75-10)	1	INOUE
4	2T4-25185-00	RING 1	1	
5	3PT-W2535-10	BRAKE SHOE SET	1	
6	2E9-25133-00	SPRING, return	1	
7	3L5-25351-00	CAMSHAFT	1	
8	3L5-25355-00	LEVER, camshaft	1	
9	90101-05396	BOLT	1	
10	90185-12046	NUT, self-locking	1	
11	2E9-25412-00	WASHER	1	
12	90201-154E8	WASHER, plate	1	
13	4X4-25336-00	RING 2	1	
14	90387-125A5	COLLAR	2	
15	36E-2539F-00	PLATE 1	3	UR FOR EUROPE




3PT351-0210

FIG. 22 STEERING HANDLE • CABLE



3PT110-0220

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3PT-26111-00	HANDLEBAR	1	
2	95607-08100	NUT, u	2	
3	2E9-26129-00	WASHER	2	
4	4X4-26241-00	GRIP (LEFT)	1	
5	4X4-26243-00	TUBE, throttle guide	1	
6	4X4-26242-00	GRIP (RIGHT)	1	
7	4U1-26261-00	CONNECTOR, cable	1	
8	4X4-26311-01	CABLE, throttle 1	1	
9	4X4-26312-00	CABLE, throttle 2	1	
10	4X4-26321-00	CABLE, pump	1	
11	4X4-26331-01	CABLE, starter 1	1	
12	4X4-26341-00	CABLE, brake	1	
13	90501-10513	SPRING, compression	1	
14	90179-06176	NUT	1	
15	90249-12008	PIN	1	
16	4X4-26351-00	CABLE, brake	1	
17	90501-10074	SPRING, compression	1	
18	90179-06411	NUT	1	
19	90249-12008	PIN	1	
20	36R-26124-10	PROTECTOR, handlebar	1	YAMAHA BLACK
21	437-83936-11	BAND, switch cord	2	




3PT110-0230

FIG. 23 STAND • FOOTREST

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	214-27421-00	FOOTREST 2	2	UNICHROME (BLACK)
2	4X4-27413-00	COVER, footrest	2	
3	917D1-08038	PIN, clevis	2	
4	92907-08600	WASHER, plate	2	
5	91401-25020	PIN, cotter	2	
6	90508-20023	SPRING, torsion	2	
7	4X4-27111-00-33	STAND, main	1	YAMAHA BLACK
8	3L5-27151-02	BRACKET, main stand	1	
9	90508-29052	SPRING, tension	1	
10	116-27114-00	STOPPER, main stand	1	
11	90240-08121	PIN, clevis	1	
12	90468-12006	CLIP	1	
13	92907-08800	WASHER, plate	1	
14	90105-06301	BOLT, washer based	2	


FIG. 24 GENERATOR



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	3L8-85560-M0	ROTOR ASSY	1	
2	4X4-85560-M1	BASE ASSY	1	
3	4X4-81313-M0	.COIL, lighting 1	1	
4	4Y4-85520-M0	.COIL, charge	1	
5	3L5-85580-M0	.COIL, pulser	1	
6	4X4-8131X-M0	.CORD, ASSY	1	
7	90461-05038	.CLAMP	1	
8	98511-04025	.SCREW, pan head	2	
9	98511-04012	.SCREW, pan head	2	
10	98580-04010	.SCREW, pan head	1	
11	92901-04100	.WASHER, spring	1	
12	98501-04008	.SCREW, pan head	1	
13	92901-04100	.WASHER, spring	1	
14	98707-06016	SCREW, flat head	2	



3PT110-0240




3PT110-0260

FIG. 25 HANDLE SWITCH • LEVER

REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	2T4-83912-02	LEVER 1	1	
2	90149-05162	SCREW	1	
3	95607-05100	NUT, u	1	
4	4X4-82920-01	LEVER HOLDER ASSY (RIGHT)	1	
5	2T4-83922-02	•LEVER 2	1	
6	90149-05119	•SCREW	1	
7	98507-05025	•SCREW, pan head	2	
8	95607-05100	•NUT, u	1	
9	437-83936-01	BAND, switch cord	1	
10	3TB-83936-00	BAND, switch cord	1	
11	4X4-26257-00	STOPPER	1	
12	437-83936-01	BAND, switch cord	1	

FIG. 26 ELECTRICAL 1



REF. NO.	PART NO.	DESCRIPTION	Q'TY	REMARKS
1	5G3-85540-10	C.D.I. UNIT ASSY	1	
2	98507-06016	SCREW, pan head	1	
3	92907-06100	WASHER, spring	1	
4	92907-06600	WASHER, plate	1	
5	4X4-85590-M0	CONTROL UNIT ASSY	1	
6	4J2-85546-00	BAND	1	
7	5M0-82310-M0	IGNITION COIL ASSY	1	
8	98507-06016	SCREW, pan head	2	
9	166-82370-20	PLUG CAP ASSY	1	
10	4X4-82590-20	WIRE HARNESS ASSY	1	
11	3K7-81980-00	RECTIFIER 2	1	

INDEX

Continuar

Regresar

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.	PART NO.	GRID NO.
3PT-W2535-00	C - 7	603-14186-00	B - 6	36R-16633-00	B -10	59V-24173-00	C - 5	59M-46121-00	C - 3	90170-10105	B - 4
3PT-W2535-10	C - 8	3L5-14190-01	B - 6	3L5-17112-01	B - 8	3R0-24181-00	C - 5	3L5-46127-00	C - 3	90170-10219	B -10
4J2-11111-00	B - 2	214-14197-00	B - 8	3L5-17410-00	B -11	4X4-24181-00	B -14	4J2-46151-01	C - 3	90171-10004	C - 7
517-11181-00	B - 2	3L5-14198-00	B - 6	3L5-17442-00	B -11	3PT-24240-30	C - 5	4J2-46154-02	C - 3	90176-06038	C - 5
4J2-11311-00	B - 2	620-14231-13	B - 6	3L5-17471-00	B -11	36E-24311-00	C - 5	3L7-46171-00	C - 3	90179-06176	C - 9
44V-11311-00	B - 2	620-14231-14	B - 6	3L5-17473-00	B -11	4X4-24500-00	C - 5	4X4-8131X-M0	C -11	90179-06411	C - 9
3PT-11351-00	B - 2	620-14231-15	B - 6	3L5-17531-00	B -11	2FG-24610-00	C - 5	4X4-81313-M0	C -11	90185-12046	C - 8
3L5-11400-01	B - 3	4X4-14411-00	B - 5	3L5-17537-00	B -11	3PT-24710-30	C - 6	3K7-81980-00	C -13	90201-06407	C - 5
3L5-11412-00	B - 3	4X4-14412-00	B - 5	15L-17552-00	B -11	3PT-24731-30	C - 6	5M0-82310-M0	C -13	90201-067A0	C - 2
3L5-11422-01	B - 3	4X4-14451-00	B - 5	15L-18473-00	C - 3	2E9-25116-00	C - 7	166-82370-20	C -13	90201-08087	B - 8
260-11601-03	B - 3	4X4-14453-00	B - 5	36E-21110-01-33	B -12	2T4-25121-00-98	C - 7	4X4-82590-20	C -13	90201-08326	C - 2
260-11601-13	B - 3	4X4-14493-01	B - 5	3PT-21511-10	B -13	2E9-25133-00	C - 7	4X4-82920-01	C -12	90201-10742	C - 4
260-11601-23	B - 3	4X4-14610-01	B - 7	36E-21513-00	B -13		C - 8	2T4-83912-02	C -12	90201-126A7	C - 2
260-11601-33	B - 3	4X4-14623-10	B - 7	4X4-21543-00	C - 4	25K-25151-00	C - 7	2T4-83922-02	C -12	90201-154E8	C - 8
260-11601-43	B - 3	4X4-14708-00	B - 7	4X4-21629-00	B -15	2T4-25155-00	C - 7	3TB-83936-00	C -12	90201-16383	B -10
18U-11631-00-A0	B - 3	4X4-14714-00	B - 7	3PT-21711-00	B -14	5M0-25180-00-UJ	C - 7	437-83936-01	C -12	90202-04214	B - 7
44V-11631-00-A0	B - 3	4X4-14750-00	B - 7	4X4-2172K-00	B -15	4N0-25181-00	C - 7	437-83936-11	C - 9	90208-10012	B -10
2E9-11633-00	B - 3	3RV-14766-00	B - 7	3PT-21731-50	B -14	2T4-25185-00	C - 7	4Y4-85520-M0	C -11	90209-10160	C - 4
18U-11635-00	B - 3	36R-1490J-00	B - 6	3PT-21741-50	B -14		C - 8	5G3-85540-10	C -13	90240-08121	C -10
44V-11635-00	B - 3	4X4-15111-00	B - 8	4X4-21751-00	B -15	4X4-25336-00	C - 8	4J2-85546-00	C -13	90249-12008	C - 9
18U-11636-00	B - 3	4J2-15113-00	B - 8	4X4-21766-00	B -15	3L5-25351-00	C - 8	3L6-85550-M0	C -11	90280-03017	B - 3
2E9-11651-00	B - 3	4J2-15121-00	B - 8	1Y1-21770-01	B -15	3L5-25355-00	C - 8	4X4-85560-M1	C -11	90282-05034	B -10
1YU-11681-00	B - 3	3L5-15126-00	B - 8	4X4-21773-00	B -15	36E-2539F-00	C - 7	3L5-85580-M0	C -11	90336-15033	C - 7
3L5-13101-00	B - 4	2E9-15316-00	B - 8	3PT-21781-00	B -14		C - 8	4X4-85590-M0	C -13	90387-077F4	C - 5
3L5-13124-00	B - 4	4J2-15363-00	B - 8	3L7-22110-00-98	C - 2	5M0-25390-00-UJ	C - 8	90101-05396	C - 8	90387-10620	C - 7
384-13138-00	B - 4	4J2-15415-00	B - 8	4X4-22110-01	C - 2	2E9-25412-00	C - 8	90101-08461	C - 2	90387-125A5	C - 8
3L5-13161-00	B - 4	17J-15416-00	B - 4	4J2-22174-01	C - 2	3PT-26111-00	C - 9	90105-06301	C -10	90387-16730	B -10
3L5-13178-00	B - 9	4X4-15421-01	B - 8	3PT-22210-00-UJ	C - 2	36R-26124-10	C - 9	90105-08066	C - 2	90401-10029	B - 4
3L5-13555-00	B - 5	3L5-15426-00	B - 4	164-22216-00	C - 2	2E9-26129-00	C - 9	90105-08103	B - 8	90430-04004	B - 4
3L5-13610-00	B - 5	3L5-15451-10	B - 8		C - 3	4X4-26241-00	C - 9	90105-08121	C - 2	90445-09074	C - 5
3L5-13613-00	B - 5	4X4-15484-00	B - 8	3PT-23100-00-EX	C - 4	4X4-26242-00	C - 9	90105-10006	C - 4	90445-09252	C - 5
3L5-13616-00	B - 5	4X4-15491-00	B - 8	3PT-23103-00-EX	C - 4	4X4-26243-00	C - 9	90105-10731	B -12	90461-05036	C -11
3HK-13621-00	B - 5	3L5-15601-00	B - 9	4X4-23106-00-EX	C - 4	4X4-26257-00	C -12	90109-08582	B - 8	90467-06003	B -15
3L5-13622-10	B - 5	2T4-15618-00	B - 9	3PT-23110-00	C - 4	4U1-26261-00	C - 9	90116-06418	B - 2		C - 5
3L5-13624-00	B - 5	17J-15620-01	B - 9	2E9-23113-01	C - 4	4X4-26311-01	C - 9	90119-06060	B -14	90467-12052	C - 5
4X4-14101-00	B - 6	3L5-15631-00	B - 9	54V-23125-01	C - 4	4X4-26312-00	C - 9	90149-04135	B - 4	90467-20023	B - 5
36R-14103-00	B - 6	3L5-15664-00	B - 9	4X4-23141-00	C - 4	4X4-26321-00	C - 9	90149-05119	C -12	90467-22048	B - 7
17L-14104-00	B - 6	3L5-15673-00	B - 9	2E9-23143-00	C - 4	4X4-26331-01	C - 9	90149-05162	C -12	90468-02033	B - 4
17L-14106-00	B - 6	3L5-16111-00	B -10	2E9-23144-01	C - 4	4X4-26341-00	C - 9	90149-06113	B - 7	90468-12006	C -10
3L5-14112-40	B - 6	3L5-16114-00	B -10	36R-23151-00	C - 4	4X4-26351-00	C - 9	90149-35133	C - 3	90480-10408	B -15
174-14131-01	B - 6	3L5-16115-00	B -10	3L6-23195-00	C - 4	4X4-27111-00-33	C -10	90149-45134	B -11	90480-18290	C - 5
509-14135-00	B - 6	3L5-16125-00	B -10	4X4-23340-02-33	C - 4	116-27114-00	C -10	90157-05003	B - 7	90501-08410	B -15
3L7-14141-12	B - 6	3L5-16181-01	B -10	3PT-23411-00	C - 4	3L5-27151-02	C -10	90158-06013	B - 5	90501-10074	C - 9
3L5-14142-40	B - 6	3L5-16611-02	B -10	2E9-23412-00	C - 4	4X4-27413-00	C -10		C - 5	90501-10513	C - 9
1R0-14169-00	B - 6	3L5-16620-03	B -10	2E9-23413-01	C - 4	214-27421-00	C -10	90159-06058	B -14	90501-80556	C - 3
58E-14171-00	B - 6	3L5-16627-02	B -10	3YJ-23414-00	C - 4	50W-28100-00	B -14	90159-06060	B -13	90506-29052	C -10
3L5-14184-00	B - 6	3L5-16628-02	B -10	4X4-23435-00	C - 4	4J2-46110-01	C - 3		B -14	90508-20023	C -10
3L6-14185-01	B - 6	2T4-16629-00	B -10	3PT-24110-10	C - 5	3L5-46114-00	C - 3		C - 4	90508-28398	B - 9

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
90560-10173	C - 7	93310-416N7	B - 3
90560-15315	C - 3	93440-17138	C - 3
90560-25185	C - 3	93450-11021	B - 3
91316-06016	B -11	93450-30057	C - 4
91317-06016	C - 4	93505-32002	C - 4
91401-20020	C - 7	94125-10850	C - 7
91401-26020	C -10		C - 8
91609-30014	B - 4	94125-10851	C - 7
91701-08038	C -10		C - 8
92501-06008	B - 7	94225-10270	C - 7
92901-04100	C -11		C - 8
92901-06600	B - 7	94701-00258	B - 2
92901-10200	C - 7	95303-05600	B - 6
92907-03100	B - 5	95307-05600	C - 7
92907-06100	B - 7	95307-12700	B - 3
	B - 8	95607-05100	C -12
	C - 2	95607-08100	C - 9
	C -13	95607-10200	B -12
92907-06600	B - 5	95707-06500	B - 2
	B - 7	95707-08500	C - 2
	C -13	97007-05020	C - 7
92907-08100	B - 7	97007-06016	B - 7
	C - 2	97007-06085	C - 5
92907-08600	B - 7	97007-08020	B - 7
	C -10	97017-06016	C - 3
92907-12100	B - 3	97017-08025	B - 9
92907-12600	B - 3	97027-06016	C - 2
92990-05100	B - 6	97707-50115	B - 4
92990-06100	B - 7	98501-04008	C -11
93101-10090	B - 4	98501-05030	B - 6
93102-15267	B -11	98501-05102	B - 6
93102-17067	B - 3	98503-04014	B - 6
93102-23174	B - 3	98507-03010	B - 5
93106-17015	C - 7	98507-05014	B - 8
93106-24018	C - 2	98507-05020	B - 4
93109-15001	B - 9	98507-05025	C -12
93109-34057	C - 7	98507-05035	B - 4
93210-14104	B - 8	98507-06012	B - 8
93210-26240	B - 4	98507-06016	C - 3
93211-05393	C - 3		C -13
93306-20006	C - 7	98507-06020	B - 5
93306-20111	C - 3	98507-06025	B - 8
93306-20117	C - 2	98507-06035	B - 8
93306-20209	C - 3	98507-06045	B - 5
93306-20226	C - 3		B - 8
93306-20301	B -11	98511-04012	C -11
93306-20326	B - 3	98511-04025	C -11
93310-210M0	B - 3	98580-04010	C -11

NUMERICAL INDEX

PART NO.	GRID NO.	PART NO.	GRID NO.
98707-06016	C -11		
99009-16400	B -10		
99080-07800	B - 4		
99241-00080	B -13		
99510-12016	B - 8		