

PARTS CATALOGUE
MODEL YEAR 2000
COMPETITION
WR400FM (5GS5)

STARTING VIN (5GS5): JYACH043*YA000010

Color Code	Color Name	Abbreviation
583	DEEP PURPLISH BLUE SOLID E	CPBSE

OWNERS/SERVICE LIT-11626-13-45
ASSEMBLY LIT-11666-13-45

FOREWORD

-INTRODUCTION- To The Yamaha Parts Fiche

This parts fiche lists parts and sub-assemblies for the WR400FM. When preparing a parts order, please refer to the most recently updated microfiche for this model.

THE YAMAHA PARTS FICHE

SYMBOLS

I	Inactive, no longer available
U.R.	Use size (thickness) and/or number as required
U.N.	Use as many as you need
T	Number of teeth in a gear
V	Voltage for light bulbs
S	"S" type oil seal or "S" type circlip
SD,SO,SW	"SD", "SO", or "SW" type oil seal
E,R	"E" or "R" type circlip
F/No.	Frame No. (Applicable Machine No.)
L.M.	Locally made
O.L.	Obtain locally
AP	Alternate Part

SUPERSEDED PART NUMBERS

If part 'A' has been superseded by part 'B', the superseding part number "B" will appear in the part number listing with the superseded part number "A" appearing in parentheses immediately following the description.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
	(Part 'B')	(Part 'A')	
8	123-45678-00-00	CYLINDER (111-12345-00-00)	1

A part that has been supersede to a kit may be identified by a 99999-00000-00 part number appearing in the part number column. The old superseded part number will appear in parentheses immediately following the description. Listed directly below the 99999 part number will be those parts making up the kit. The description of the parts making up the kit will be preceded by a small black dot (.) and the description will be indented one letter space.

EXAMPLE:

Ref. No.	Part No.	Description	Qty.
8	99999-12345-00	CYLINDER (111-12345-00-00)	1
	234-56789-00-00	• HEAD, CYLINDER	1
	345-67890-00-00	• GASKET, CYLINDER	1

SIZES

Except for steel balls (ball sizes are indicated in inches), all parts sizes are indicated in millimeters as in the following examples:

Hose (Rubber or Vinyl)Inside Diameter - Length

O-RingSection Area - Inside Diameter

Washer, Shim, CollarInside Diameter - Outside Diameter
Thickness (Length)

ASSEMBLIES AND COMPONENT PARTS

Assemblies and their component parts, are identified by an indention of one letter space, and the description is preceded by a dot (.). If two main assemblies are listed, and have the same basic description (i.e.: left and right sides of the same assembly), one will immediately follow the other. If each of these main assemblies is made up of almost the same components, these component parts will be listed immediately under the second main assembly line and will be indicated, as noted above.


If the component is the same for both main assemblies, the quantity indicated will be the total required. If the component is not the same for both main assemblies, the quantity for each separate item will be listed separately.

EXAMPLE:


Description	Qty
CARBURETOR ASSY, LEFT	1
CARBURETOR ASSY, RIGHT	1
. JET, PILOT	2
. NOZZLE, MAIN	2
. LEVER, STARTER, LEFT	1
. LEVER, STARTER, RIGHT	1

APPLICABLE SERIAL NO.

(1) Engine Serial No.



(2) Frame Serial No.




FOREWORD

THE YAMAHA PART NUMBER

The Yamaha part number consists of 12 digits. Each number represents a specific piece of information relating to a replacement part. The following is a guide for reading and interpreting the Yamaha part number.

BASIC PART NUMBER CONFIGURATION:



MODEL CODE NUMBER

FIRST THREE DIGITS . . . 000-00000-00-00


Every model in each Yamaha product line is assigned a model number to identify that particular model. All component parts are given the model code number relating to the model on which they were first used.

Example: 4DU-00000-00-00 identifies the XJ600SE.
3FA-00000-00-00 identifies the YFA1E.

BASIC CODE NUMBER


MIDDLE FIVE DIGITS . . . 000-00000-00-00

These "Middle Five Digits" indicate the type of part i.e., piston, rings, lower units, etc. The five digits are broken down as follows:



The "Major Classification" indicates the section to which the parts belong, i.e., engine, electrical etc. The "Intermediate" and "Minor Classifications" indicate more specific details.

Example:



DESIGN CODE NUMBER: 000-00000-00-00

The design code distinguishes like component parts from one another when specification differences are involved. For example, distinguishing a standard size piston ring from an oversized piston ring.

Example:

4BR-11610-0 0 0-00 Standard Piston Ring Set for XJ600SE
4BR-11610-2 0 0-00 Oversize Piston Ring Set for XJ600SE

DESIGN CHANGE CODE NUMBER: 000-00000-00-00

This code number is used to identify a difference between a new component part and old one when a new part is created by changing the old one.

Example: YFZ350E

2GU-11610-0 0 0-00 PISTON RING SET, STD. - ORIGINAL
2GU-11610-0 1 0-00 PISTON RING SET, STD. - FIRST DESIGN CHANGE


Only major changes to performance, durability, quality, appearance, cost or interchangeability will affect a part number change.

COLOR CODE & SIZE CODE NUMBER: 000-00000-00-00

When applicable, the last two digits of the part number identify:

1. Color Code: The painted color or type of plating or surface treatment used on certain parts.
2. Size Code: The last two digits are also used to show the size of parts (mm). Such as the thickness of shims or the size of pistons.

HARDWARE (Fastener) PART NUMBER CONFIGURATION:



TYPE:

A fastener part number always begins with the number "9" followed by either a 0, 1, 2, 3, 4, 5, 6, 7 or 8 designating one of eight major divisions within this group.


FOREWORD

Example:

- 9 0 000-00000-00 "0" designates various types.
- 9 1 000-00000-00 "1" designates bolts, cotter pins, etc.
- 9 2 000-00000-00 "2" designates screw, nuts, etc.
- 9 3 000-00000-00 "3" designates oil seals, o-rings, bearings, etc.
- 9 4 000-00000-00 "4" designates spark plugs.
- 9 5 000-00000-00 "5" designates bolts and nuts.
- 9 7 000-00000-00 "7" designates ISO bolts.
- 9 8 000-00000-00 "8" designates ISO screws and nuts.

The only major divisions which the mechanic should become familiar with are those related to the general hardware (nuts, bolts, and washers), since these are the most commonly used and most often replaced items. By knowing how to interpret the part number, the dimensions of a piece of hardware can be determined. This can be very helpful during major engine repair, and general parts replacement.


BOLT EXAMPLE:




EXCEPTION:

It is NOT possible to identify the LENGTH of bolts having a 901 prefix. Only the bolt diameter can be identified with this number.


NUT AND WASHER EXAMPLE:



"MODEL LABEL" INDICATION



MODEL LABEL AFFIXING LOCATION



MODEL CODE - PRODUCTION CODE NUMBER OF MODEL LISTED IN THIS PARTS CATALOG

Model Code	Production Code No.	Country (destination)
5GS5		USA


-MODEL LABEL-

A label called "Model Label" is affixed in the location as indicated in (3) below. When using this parts catalogue, please be sure to cross-reference the "model code - production code No." in the catalogue to the "model code - production code No." indicated on the Model Label affixed onto the product concerned.

CYLINDER

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-11102-30-00	CYLINDER HEAD ASSY	1	(5GS5)
2	5BE-11133-10-00	. GUIDE, INTAKE VALVE	3	(5GS5)
3	5BE-11134-10-00	. GUIDE, EXHAUST VALVE ...	2	(5GS5)
4	93440-10153-00	. CIRCLIP	5	(5GS5)
5	91808-16023-00	. PIN, DOWEL	4	(5GS5)
6	90105-067A6-00	. BOLT, WASHER BASED	10	(5GS5)
7	90340-12112-00	. PLUG, STRAIGHT SCREW ...	1	(5GS5)
8	95617-06635-00	BOLT, STUD	2	(5GS5)
9	95617-08635-00	BOLT, STUD	2	(5GS5)
10	95617-08620-00	BOLT, STUD	1	(5GS5)
11	95707-08500-00	NUT, FLANGE	1	(5GS5)
12	NGK-CR8E0-00-00	PLUG, SPARK (NGK-R CR8E) .	1	UR (5GS5)
13	5GR-11181-00-00	GASKET, CYLINDER HEAD 1 .	1	(5GS5)
14	90105-104A7-00	BOLT, WASHER BASED	2	(5GS5)
15	90105-106A3-00	BOLT, WASHER BASED	2	(5GS5)
16	90201-101A4-00	WASHER, PLATE	4	(5GS5)
17	5BE-11191-00-00	COVER, CYLINDER HEAD 1 ..	1	(5GS5)
18	5BE-11167-00-00	PIPE, BREATHER 2	1	(5GS5)
19	90109-066F0-00	BOLT	2	(5GS5)
20	4KG-1111G-00-00	RUBBER, MOUNT 1	2	(5GS5)
21	371-11167-01-00	PIPE, BREATHER 2	1	(5GS5)
22	5BE-11166-00-00	PIPE, BREATHER 1	1	(5GS5)
23	90445-112K0-00	HOSE	1	(5GS5)
24	90467-11106-00	CLIP	2	(5GS5)
25	90467-14015-00	CLIP	1	(5GS5)
26	5BE-11193-10-00	GASKET, HEAD COVER 1	1	(5GS5)
27	5BE-11311-10-00	CYLINDER 1	1	(5GS5)
28	5BE-11351-00-00	GASKET, CYLINDER	1	(5GS5)
29	90179-06500-00	NUT	2	(5GS5)


CONTINUED ON NEXT FRAME ➤



5JG1100-0010

CYLINDER


Ref. No.	Part Number	Description	Qty	Remarks
30	93612-16254-00	PIN, DOWEL	2	(5GS5)
31	90179-08270-00	NUT	2	(5GS5)
32	95027-06040-00	BOLT, FLANGE	1	(5GS5)
33	5JG-11387-00-00	CLAMP, HOSE 1	1	(5GS5)




5JG1100-0010

CRANKSHAFT. PISTON

Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-11400-00-00	CRANKSHAFT ASSY	1	(5GS5)
2	5JG-11412-00-00	. CRANK 1	1	(5GS5)
3	5JG-11422-00-00	. CRANK 2	1	(5GS5)
4	5BE-11681-00-00	. PIN, CRANK 1	1	(5GS5)
5	93310-634B0-00	. BEARING	1	(5GS5)
6	5BE-11651-10-00	. ROD, CONNECTING	1	(5GS5)
7	93306-30633-00	BEARING	2	(5GS5)
8	5BE-11536-00-00	GEAR, DRIVE	1	(5GS5)
9	90282-05058-00	KEY, STRAIGHT	1	(5GS5)
10	5BE-11455-00-00	SHAFT 1	1	(5GS5)
11	5BE-11454-00-00	WEIGHT 1	1	(5GS5)
12	5BE-11531-00-00	GEAR, BALANCE WT	1	(5GS5)
13	90149-06250-00	SCREW	3	(5GS5)
14	93306-20335-00	BEARING	1	(5GS5)
15	93311-62574-00	BEARING	1	(5GS5)
16	90170-14171-00	NUT	1	(5GS5)
17	90215-14204-00	WASHER, LOCK	1	(5GS5)
18	90280-03017-00	KEY, WOODRUFF	1	(5GS5)
19	5GR-11631-00-00	PISTON (STD)	1	(5GS5)
20	5BE-11603-00-00	PISTON RING SET (STD)	1	(5GS5)
21	5GR-11633-01-00	PIN, PISTON	1	(5GS5)
22	93420-18082-00	CIRCLIP	2	(5GS5)



5BE100-8020




5BE100-8030

VALVE

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-12111-10-00	VALVE, INTAKE	1	(5GS5)
2	5BE-12112-10-00	VALVE, INTAKE 2	2	(5GS5)
3	5BE-12121-10-00	VALVE, EXHAUST	2	(5GS5)
4	3GM-12126-00-00	SEAT, VALVE SPRING 2	5	(5GS5)
5	5GS-12113-00-00	SPRING, VALVE INNER	3	(5GS5)
6	5GS-12114-00-00	SPRING, VALVE OUTER	2	(5GS5)
7	5BE-12117-00-00	RETAINER, VALVE SPRING ..	3	(5GS5)
8	4GY-12117-00-00	RETAINER, VALVE SPRING ..	2	(5GS5)
9	1AA-12118-00-00	COTTER, VALVE	4	(5GS5)
10	1WG-12118-00-00	COTTER, VALVE	6	(5GS5)
11	33M-12119-00-00	SEAL, VALVE STEM	2	(5GS5)
12	4SV-12119-00-00	SEAL, VALVE STEM	3	(5GS5)
13	3LD-12168-00-00	PAD, ADJUSTING (1.20)	5	UR (5GS5)
	3LD-12168-20-00	PAD, ADJUSTING (1.25)	5	UR (5GS5)
	3LD-12168-40-00	PAD, ADJUSTING (1.30)	5	UR (5GS5)
	3LD-12168-60-00	PAD, ADJUSTING (1.35)	5	UR (5GS5)
	3LD-12168-80-00	PAD, ADJUSTING (1.40)	5	UR (5GS5)
	3LD-12168-A0-00	PAD, ADJUSTING (1.45)	5	UR (5GS5)
	3LD-12168-F0-00	PAD, ADJUSTING (1.50)	5	UR (5GS5)
	3LD-12168-H1-00	PAD, ADJUSTING (1.55)	5	UR (5GS5)
	3LD-12168-K1-00	PAD, ADJUSTING (1.60)	5	UR (5GS5)
	3LD-12168-M1-00	PAD, ADJUSTING (1.65)	5	UR (5GS5)
	3LD-12168-R1-00	PAD, ADJUSTING (1.70)	5	UR (5GS5)
	3LD-12168-U1-00	PAD, ADJUSTING (1.75)	5	UR (5GS5)
	3LD-12168-W1-00	PAD, ADJUSTING (1.80)	5	UR (5GS5)
	3LD-12168-Y1-00	PAD, ADJUSTING (1.85)	5	UR (5GS5)
	3LD-12169-11-00	PAD, ADJUSTING (1.90)	5	UR (5GS5)
	3LD-12169-31-00	PAD, ADJUSTING (1.95)	5	UR (5GS5)
	3LD-12169-50-00	PAD, ADJUSTING (2.00)	5	UR (5GS5)

CONTINUED ON NEXT FRAME ➤




5BE100-8030

VALVE

Ref. No.	Part Number	Description	Qty	Remarks
13	3LD-12169-70-00	PAD, ADJUSTING (2.05)	5	UR (5GS5)
	3LD-12169-90-00	PAD, ADJUSTING (2.10)	5	UR (5GS5)
	3LD-12169-E0-00	PAD, ADJUSTING (2.15)	5	UR (5GS5)
	3LD-12169-G0-00	PAD, ADJUSTING (2.20)	5	UR (5GS5)
	3LD-12169-J0-00	PAD, ADJUSTING (2.25)	5	UR (5GS5)
	3LD-12169-L0-00	PAD, ADJUSTING (2.30)	5	UR (5GS5)
	3LD-12169-N0-00	PAD, ADJUSTING (2.35)	5	UR (5GS5)
	3LD-12169-T0-00	PAD, ADJUSTING (2.40)	5	UR (5GS5)
14	3FV-12153-00-00	LIFTER, VALVE	5	UR BLACK (5GS5)
	3FV-12153-10-00	LIFTER, VALVE	5	UR YELLOW (5GS5)
	3FV-12153-20-00	LIFTER, VALVE	5	UR BLUE (5GS5)


CAMSHAFT. CHAIN

Ref. No.	Part Number	Description	Qty	Remarks
1	5BF-12170-00-00	CAMSHAFT ASSY 1	1	(5GS5)
2	5BF-12180-00-00	CAMSHAFT ASSY 2	1	(5GS5)
3	93440-41178-00	CIRCLIP	2	(5GS5)
4	94591-50120-00	CHAIN	1	(5GS5)
5	5BE-12210-00-00	TENSIONER ASSY, CAM CHAIN	1	(5GS5)
6	4FM-12213-00-00	GASKET, TENSIONER CASE ..	1	(5GS5)
7	95027-06025-00	BOLT, FLANGE	2	(5GS5)
8	5BE-12251-10-00	DAMPER, CHAIN 1	1	(5GS5)
9	5BE-12252-00-00	DAMPER, CHAIN 2	1	(5GS5)
10	97027-06016-00	BOLT	2	(5GS5)
11	92907-06600-00	WASHER, PLATE	2	(5GS5)
12	5BE-12241-00-00	GUIDE, STOPPER 2	1	(5GS5)
13	90109-06418-00	BOLT	1	(5GS5)
14	90430-06014-00	GASKET	1	(5GS5)
15	93102-12224-00	OIL SEAL	1	(5GS5)
16	5BE-12280-10-00	DECOMPRESSION ASSY	1	(5GS5)
17	90508-162B2-00	SPRING, TORSION	1	(5GS5)
18	5BE-12283-00-00	BRACKET, DECOMPRESSION .	1	(5GS5)
19	5BE-12292-00-00	CABLE, DECOMPRESSION ...	1	(5GS5)
20	95827-06014-00	BOLT, FLANGE	1	(5GS5)



WATER PUMP


Ref. No.	Part Number	Description	Qty	Remarks
1	5GR-12458-00-00	SHAFT, IMPELLER	1	(5GS5)
2	5DJ-12451-00-00	IMPELLER, WATER PUMP	1	(5GS5)
3	90201-08512-00	WASHER, PLATE	1	(5GS5)
4	93109-11073-00	OIL SEAL	1	(5GS5)
5	93102-12106-00	OIL SEAL (SD 12-22-5 HS)	1	(5GS5)
6	93306-00105-00	BEARING (B6001)	1	(5GS5)
7	5BE-12422-10-00	COVER, HOUSING	1	(5GS5)
8	5BE-12439-00-00	O-RING	1	(5GS5)
9	93604-10011-00	PIN, DOWEL	2	(5GS5)
10	90430-06014-00	GASKET	1	(5GS5)
11	95027-06025-00	BOLT, FLANGE	4	(5GS5)
12	5BE-12564-00-00	PIPE, WATER	2	(5GS5)
13	93210-19758-00	O-RING	2	(5GS5)



5BE100-8050

RADIATOR. HOSE


Ref. No.	Part Number	Description	Qty	Remarks
1	5BF-1240A-10-00	RADIATOR ASSY	1	(5GS5)
2	5BF-12461-10-00	RADIATOR ASSY	1	(5GS5)
3	5HD-12462-00-00	CAP, RADIATOR	1	(5GS5)
4	3GD-24181-00-00	DAMPER, LOCATING 1	1	(5GS5)
5	5BE-12481-10-00	PIPE 1	1	(5GS5)
6	95027-06012-00	BOLT, FLANGE	1	(5GS5)
7	93210-16500-00	O-RING	1	(5GS5)
8	5BE-12576-00-00	HOSE 1	1	(5GS5)
9	5BE-12577-00-00	HOSE 2	1	(5GS5)
10	5BE-12578-00-00	HOSE 3	1	(5GS5)
11	5BE-12579-01-00	HOSE 4	1	(5GS5)
12	5BE-12482-00-00	PIPE 2	1	(5GS5)
13	95027-06012-00	BOLT, FLANGE	1	(5GS5)
14	93210-16500-00	O-RING	1	(5GS5)
15	90450-28014-00	HOSE CLAMP ASSY	3	(5GS5)
16	90450-25037-00	HOSE CLAMP ASSY	5	(5GS5)
17	90480-15528-00	GROMMET	6	(5GS5)
18	90387-06004-00	COLLAR	6	(5GS5)
19	95027-06030-00	BOLT, FLANGE	6	(5GS5)
20	90201-06071-00	WASHER, PLATE	6	(5GS5)



5GS5110-0060


OIL PUMP

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-13300-00-00	OIL PUMP ASSY	1	(5GS5)
2	1HX-13310-00-00	ROTOR ASSY 1	1	(5GS5)
3	93603-17070-00	PIN, DOWEL	1	(5GS5)
4	93440-10085-00	CIRCLIP	1	(5GS5)
5	93210-10197-00	O-RING	1	(5GS5)
6	99530-10114-00	PIN, DOWEL	1	(5GS5)
7	99530-08012-00	PIN, DOWEL	1	(5GS5)
8	91317-06025-00	BOLT	2	(5GS5)
9	91314-06030-00	BOLT	1	(5GS5)
10	99001-08600-00	CIRCLIP	1	(5GS5)
11	5BE-13341-00-00	GEAR, OIL PUMP IDLE	1	(5GS5)
12	5BE-13342-00-00	SHAFT, IDLE GEAR	1	(5GS5)
13	99009-12400-00	CIRCLIP	1	(5GS5)
14	90201-12166-00	WASHER, PLATE	1	(5GS5)
15	5BE-13412-00-00	HOUSING, STRAINER	1	(5GS5)
16	95027-06025-00	BOLT, FLANGE	2	(5GS5)
17	5BE-13411-00-00	STRAINER, OIL	1	(5GS5)
18	5BE-13464-00-00	HOSE, OIL 1	1	(5GS5)
19	93210-10197-00	O-RING	1	(5GS5)
20	99530-10114-00	PIN, DOWEL	1	(5GS5)
21	95027-06025-00	BOLT, FLANGE	1	(5GS5)
22	90450-22017-00	HOSE CLAMP ASSY	1	(5GS5)
23	5BE-13416-00-00	PIPE, OIL 1	1	(5GS5)
24	5BE-13465-00-00	HOSE, OIL 2	1	(5GS5)
25	90450-22017-00	HOSE CLAMP ASSY	1	(5GS5)
26	93210-10197-00	O-RING	2	(5GS5)
27	99530-10114-00	PIN, DOWEL	2	(5GS5)
28	95027-06025-00	BOLT, FLANGE	1	(5GS5)
29	95024-06020-00	BOLT, FLANGE	1	(5GS5)



5BE100-8070

OIL CLEANER



Ref. No.	Part Number	Description	Qty	Remarks
1	1UY-13440-02-00	ELEMENT ASSY, OIL CLEANER	1	(5GS5)
2	5BE-13447-00-00	COVER, OIL ELEMENT	1	(5GS5)
3	93210-50553-00	O-RING	1	(5GS5)
4	93210-07135-00	O-RING	3	(5GS5)
5	90109-065G2-00	BOLT	1	(5GS5)
6	95027-06065-00	BOLT, FLANGE	1	(5GS5)
7	95027-06020-00	BOLT, FLANGE	1	(5GS5)
8	5BE-13161-01-00	PIPE, DELIVERY 1	1	(5GS5)
9	90401-10159-00	BOLT, UNION	1	(5GS5)
10	90430-10188-00	GASKET	2	(5GS5)
11	90401-08038-00	BOLT, UNION	2	(5GS5)
12	90430-08119-00	GASKET	4	(5GS5)
13	5BE-13171-00-00	PIPE, DELIVERY 2	1	(5GS5)
14	93210-07003-00	O-RING	1	(5GS5)
15	93210-09008-00	O-RING	1	(5GS5)
16	93210-12759-00	O-RING	1	(5GS5)
17	95027-06012-00	BOLT, FLANGE	1	(5GS5)




5BE100-8080

INTAKE


Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-13597-00-00	JOINT, CARBURETOR 3	1	(5GS5)
2	90450-57092-00	HOSE CLAMP ASSY	1	(5GS5)
3	90450-59091-00	HOSE CLAMP ASSY	1	(5GS5)
4	5JG-1440F-00-00	JOINT, AIR FILTER 1	1	(5GS5)
5	91317-05014-00	BOLT	2	(5GS5)
6	4FN-14561-00-00	O-RING	1	(5GS5)
7	90460-61162-00	CLAMP, HOSE	1	(5GS5)
8	5JG-14293-00-00	COVER 1	1	(5GS5)
9	5JG-14428-00-00	BOLT	1	(5GS5)
10	5JG-14401-00-00	AIR CLEANER CASE ASSY	1	(5GS5)
11	5JG-14453-00-00	JOINT, AIR CLEANER 1	1	(5GS5)
12	3JD-14459-01-00	HOLDER, GUIDE	1	(5GS5)
13	3JD-14477-00-00	PLATE	1	(5GS5)
14	95607-05100-00	NUT, U	5	(5GS5)
15	5BF-14437-00-00	DUCT	1	(5GS5)
16	5BF-1441A-10-00	COVER, CLEANER CASE 1	1	(5GS5)
17	5BF-14452-00-00	SEAL	1	(5GS5)
18	97707-50012-00	SCREW, TAPPING	4	(5GS5)
19	4XM-14451-00-00	ELEMENT, AIR CLEANER	1	(5GS5)
20	90209-06096-00	WASHER	1	(5GS5)
21	90122-06035-00	BOLT, WING	1	(5GS5)
22	5BE-14458-00-00	GUIDE	1	(5GS5)
23	90146-06014-00	SCREW, OVAL FILLISTER	4	(5GS5)
24	5BF-14493-00-00	STAY 1	2	(5GS5)
25	90267-32070-00	RIVET, BLIND	9	(5GS5)
26	5BF-14457-00-00	SEAL	1	(5GS5)
27	5BE-1441A-00-00	COVER, CLEANER CASE 1	1	(5GS5)
28	5BE-1441E-00-00	COVER, CLEANER CASE 2	1	(5GS5)
29	5BF-1443E-00-00	PIPE, DRAIN	1	(5GS5)

CONTINUED ON NEXT FRAME ➤




INTAKE

Ref. No.	Part Number	Description	Qty	Remarks
30	90467-17089-00	CLIP	1	(5GS5)
31	90201-03313-00	WASHER, PLATE	5	(5GS5)
32	90183-06023-00	NUT, SPRING	2	(5GS5)
33	95027-06012-00	BOLT, FLANGE	1	(5GS5)
34	5JG-14417-00-00	COVER 1	1	AP (5GS5)




CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-14101-50-00	CARBURETOR ASSY 1	1	(5GS5)
2	5JG-14959-00-00	. GASKET	1	(5GS5)
3	91316-04012-00	. BOLT	4	(5GS5)
4	91316-04012-00	. BOLT	2	(5GS5)
5	91316-04008-00	. BOLT	3	(5GS5)
6	90202-08045-00	. WASHER, PLATE	1	(5GS5)
7	5JG-14951-00-00	. WASHER	1	(5GS5)
8	5JG-14522-00-00	. SCREW, ADJUST	1	(5GS5)
9	5JG-14388-00-00	. VALVE, VACUUM CONTROL .	1	(5GS5)
10	3TJ-14267-40-00	. ROLLER	1	(5GS5)
11	5JG-14546-00-00	. VALVE, NEEDLE	1	(5GS5)
12	4FN-14997-00-00	. SEAL	1	(5GS5)
13	5GS-14916-R1-00	. NEEDLE (DRQ)	1	AP (5GS5)
	5GS-14916-RP-00	. NEEDLE (DRP)	1	AP (5GS5)
	5GS-14916-RR-00	. NEEDLE (DRR)	1	AP (5GS5)
	5GS-14916-RS-00	. NEEDLE (DRS)	1	STD (5GS5)
	5GS-14916-RT-00	. NEEDLE (DRT)	1	AP (5GS5)
	5GS-14916-RU-00	. NEEDLE (DRU)	1	AP (5GS5)
	5GS-14916-RV-00	. NEEDLE (DRV)	1	AP (5GS5)
14	3TJ-14159-40-00	. CLIP	1	(5GS5)
15	5JG-14521-00-00	. SCREW, ADJUST	1	(5GS5)
16	5JG-14275-00-00	. SPRING	1	(5GS5)
17	5JG-14264-00-00	. COLLAR	1	(5GS5)
18	5JG-14947-00-00	. JET, NEEDLE	1	(5GS5)
19	4MX-14943-38-00	. JET, MAIN (155)	1	AP (5GS5)
	4MX-14943-39-00	. JET, MAIN (160)	1	AP (5GS5)
	4MX-14943-40-00	. JET, MAIN (165)	1	STD (5GS5)
	4MX-14943-41-00	. JET, MAIN (170)	1	AP (5GS5)
	4MX-14943-42-00	. JET, MAIN (175)	1	AP (5GS5)

CONTINUED ON NEXT FRAME ➤


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
19	4MX-14943-89-00	. JET, MAIN (158)	1	AP (5GS5)
	4MX-14943-90-00	. JET, MAIN (162)	1	AP (5GS5)
	4MX-14943-91-00	. JET, MAIN (168)	1	AP (5GS5)
	4MX-14943-92-00	. JET, MAIN (172)	1	AP (5GS5)
	4MX-14943-93-00	. JET, MAIN (178)	1	AP (5GS5)
20	3TJ-14943-47-00	. JET (200)	1	(5GS5)
21	4MX-14948-02-00	. JET, SLOW (38)	1	AP (5GS5)
	4MX-14948-03-00	. JET, SLOW (40)	1	AP (5GS5)
	4MX-14948-04-00	. JET, SLOW (42)	1	AP (5GS5)
	4MX-14948-05-00	. JET, SLOW (45)	1	STD (5GS5)
	4MX-14948-06-00	. JET, SLOW (48)	1	AP (5GS5)
22	3TJ-1494F-10-00	. JET (58)	1	AP (5GS5)
	3TJ-1494F-11-00	. JET (60)	1	AP (5GS5)
	3TJ-1494F-12-00	. JET (62)	1	AP (5GS5)
	3TJ-1494F-13-00	. JET (65)	1	STD (5GS5)
	3TJ-1494F-14-00	. JET (68)	1	AP (5GS5)
	3TJ-1494F-15-00	. JET (70)	1	AP (5GS5)
23	7A9-14943-17-00	. JET (75)	1	(5GS5)
24	3TJ-14105-40-00	. PILOT SCREW SET	1	(5GS5)
25	5BE-14107-00-00	. NEEDLE VALVE SET	1	(5GS5)
26	5BE-14216-00-00	. SCREW	1	(5GS5)
27	4SR-14985-00-00	. FLOAT	1	(5GS5)
28	676-14548-00-00	. PIN, FLOAT ARM	1	(5GS5)
29	5JG-14984-00-00	. GASKET, FLOAT CHAMBER	1	(5GS5)
30	3TJ-14293-40-00	. COVER 1	1	(5GS5)
31	5BE-14940-17-00	. DIAPHRAGM ASSY	1	AP (5GS5)
	5BE-14940-18-00	. DIAPHRAGM ASSY	1	STD (5GS5)
	5BE-14940-19-00	. DIAPHRAGM ASSY	1	AP (5GS5)
32	3TJ-14536-40-00	. GASKET	1	(5GS5)

CONTINUED ON NEXT FRAME ➤


CARBURETOR



Ref. No.	Part Number	Description	Qty	Remarks
33	3TJ-14933-40-00	. SPRING, DIAPHRAGM	1	(5GS5)
34	6H4-14561-00-00	. O-RING	1	(5GS5)
35	5JG-14171-00-00	. PLUNGER, STARTER	1	(5GS5)
36	5JG-14371-00-00	. PLUNGER, STARTER	1	(5GS5)
37	5JG-14379-00-00	. ROD, STARTER	1	(5GS5)
38	3TJ-14325-40-00	. SCREW, PAN HEAD	1	(5GS5)
39	5JG-14922-00-00	. SCREW, THROTTLE	1	(5GS5)
40	90201-08410-00	. WASHER, PLATE	1	(5GS5)
41	4FN-14934-00-00	. SPRING, THROTTLE STOP ..	1	(5GS5)
42	5JG-85885-00-00	. THROTTLE SENSOR ASSY ..	1	(5GS5)
43	5BE-14449-00-00	. COLLAR	1	(5GS5)
44	5BE-14562-00-00	. O-RING	1	(5GS5)
45	4YR-14557-00-00	. WASHER	2	(5GS5)
46	4YR-14216-00-00	. SCREW	2	(5GS5)
47	4MX-14561-00-00	. O-RING	1	(5GS5)
48	4MX-14115-00-00	. PLUG, SCREW	1	(5GS5)
49	3TJ-14137-40-00	. CLIP	5	(5GS5)
50	5JG-14146-00-00	. PLATE	1	(5GS5)
51	5BE-14146-00-00	. PLATE	1	(5GS5)
52	5JG-14197-00-00	. PIPE	2	(5GS5)
53	5JG-14197-10-00	. PIPE	2	(5GS5)
54	5JG-14987-00-00	. HOSE	1	(5GS5)
55	5JG-14346-00-00	. PLATE	1	(5GS5)
56	5JG-14565-00-00	. SCREW	1	(5GS5)
57	5JG-14531-00-00	. SPRING, ADJUST SCREW ...	1	(5GS5)
58	5GS-14591-00-00	. SCREW	1	(5GS5)
59	5GS-14940-00-00	. DIAPHRAGM ASSY	1	(5GS5)
60	5GS-14958-00-00	. COVER, DIAPHRAGM	1	(5GS5)
61	5GS-14933-00-00	. SPRING, DIAPHRAGM	1	(5GS5)


EXHAUST

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-14611-00-00	PIPE, EXHAUST 1	1	(5GS5)
2	5BE-14628-00-00	PROTECTOR, EXHAUST PIPE .	1	(5GS5)
3	4BD-14766-00-00	WASHER, PROTECTOR	6	(5GS5)
4	98980-06008-00	SCREW, BIND	3	(5GS5)
5	90206-06090-00	WASHER, WAVE	3	(5GS5)
6	3VD-14613-00-00	GASKET, EXHAUST PIPE	1	(5GS5)
7	91317-08020-00	BOLT	1	(5GS5)
8	5BF-14710-00-00	MUFFLER ASSY 1	1	(5GS5)
9	95804-06010-00	. BOLT, FLANGE	3	(5GS5)
10	3GW-14714-00-00	. GASKET, MUFFLER	1	(5GS5)
11	22W-24181-00-00	. DAMPER, LOCATING 1	1	(5GS5)
12	95804-06016-00	. BOLT, FLANGE	1	(5GS5)
13	5BE-14788-00-00	. BAND, SILENCER	1	(5GS5)
14	95817-08014-00	BOLT, FLANGE	2	(5GS5)




5GS5110-0110


CRANKCASE




Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-15150-02-00	CRANKCASE ASSY	1	(5GS5)
2	99530-14016-00	PIN, DOWEL	2	(5GS5)
3	91317-06040-00	BOLT	3	(5GS5)
4	91317-06050-00	BOLT	4	(5GS5)
5	91317-06060-00	BOLT	2	(5GS5)
6	91317-06075-00	BOLT	3	(5GS5)
7	5BE-15441-00-00	HOLDER, CLUTCH CABLE ...	1	(5GS5)
8	5BE-15421-00-00	COVER, CRANKCASE 2	1	(5GS5)
9	98507-06025-00	SCREW, PAN HEAD	2	(5GS5)
10	5BE-17466-10-00	GUIDE, CHAIN	1	(5GS5)
11	90340-12059-00	PLUG, STRAIGHT SCREW	1	(5GS5)
12	90430-12213-00	GASKET	1	(5GS5)
13	4L0-17471-00-00	PLATE, COVER	1	(5GS5)
14	90105-06553-00	BOLT, WASHER BASED	2	(5GS5)
15	4JT-15381-01-00	PLATE, BEARING COVER	5	(5GS5)
16	5BE-15383-00-00	PLATE, BEARING COVER	4	(5GS5)
17	90151-06002-00	SCREW, COUNTERSUNK	4	(5GS5)
18	90149-06326-00	SCREW	5	(5GS5)
19	5DH-18562-00-00	PLATE, STOPPER 2	4	(5GS5)
20	90105-06553-00	BOLT, WASHER BASED	4	(5GS5)
21	93210-10197-00	O-RING	1	(5GS5)
22	99530-10114-00	PIN, DOWEL	1	(5GS5)
23	90387-1712Y-00	COLLAR	2	(5GS5)
24	99530-10116-00	PIN, DOWEL	2	(5GS5)
25	90461-10136-00	CLAMP	1	(5GS5)

CRANKCASE COVER 1

Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-15411-00-00	COVER, CRANKCASE 1	1	(5GS5)
2	90340-32123-00	PLUG, STRAIGHT SCREW	1	(5GS5)
3	93210-32172-00	O-RING	1	(5GS5)
4	90340-14128-00	PLUG, STRAIGHT SCREW	1	(5GS5)
5	93210-14369-00	O-RING	1	(5GS5)
6	5BE-15451-00-00	GASKET, CRANKCASE COVER 1	1	(5GS5)
7	99530-08016-00	PIN, DOWEL	2	(5GS5)
8	95027-06040-00	BOLT, FLANGE	2	(5GS5)
9	95027-06030-00	BOLT, FLANGE	6	(5GS5)
10	5JG-15431-00-00	COVER, CRANKCASE 3	1	(5GS5)
11	93101-14164-00	OIL SEAL	1	(5GS5)
12	90201-15701-00	WASHER, PLATE (1.0T)	1	(5GS5)
13	99009-22500-00	CIRCLIP	1	(5GS5)
14	5BE-15462-00-00	GASKET, CRANKCASE COVER 3	1	(5GS5)
15	91812-16001-00	PIN, DOWEL	2	(5GS5)
16	95027-06030-00	BOLT, FLANGE	10	(5GS5)
17	5JG-15415-00-00	COVER, GENERATOR	1	(5GS5)
18	95027-06030-00	BOLT, FLANGE	4	(5GS5)
19	95027-06040-00	BOLT, FLANGE	1	(5GS5)
20	90105-065A1-00	BOLT, WASHER BASED	2	(5GS5)
21	99530-08016-00	PIN, DOWEL	2	(5GS5)
22	5JG-15453-00-00	GASKET, CARBURETOR COVER	1	(5GS5)
23	90462-10241-00	CLAMP	1	(5GS5)
24	583-13113-00-00	SEAT, CHECK BALL	1	(5GS5)
25	93503-08007-00	BALL	1	(5GS5)
26	90501-043E0-00	SPRING, COMPRESSION	1	(5GS5)




5BE100-8130



STARTER

Ref. No.	Part Number	Description	Qty	Remarks
1	5GR-15601-00-00	KICK SHAFT ASSY	1	(5GS5)
2	90201-20685-00	. WASHER, PLATE (0.5T)	1	(5GS5)
3	93410-20038-00	. CIRCLIP	1	(5GS5)
4	90501-16107-00	. SPRING, COMPRESSION	1	(5GS5)
5	90201-167P7-00	. WASHER, PLATE	1	(5GS5)
6	99009-16400-00	. CIRCLIP	1	(5GS5)
7	5GR-15664-00-00	. GUIDE, SPRING	1	(5GS5)
8	90508-30743-00	. SPRING, TORSION	1	(5GS5)
9	90201-162H4-00	WASHER, PLATE	1	(5GS5)
10	5BE-15668-00-00	STOPPER	1	(5GS5)
11	5BE-15674-00-00	GUIDE, RATCHET WHEEL	1	(5GS5)
12	5BE-15686-01-00	WASHER, LOCK	1	(5GS5)
13	90101-06001-00	BOLT	2	(5GS5)
14	93102-20108-00	OIL SEAL	1	(5GS5)
15	5BE-15651-00-00	GEAR, KICK IDLE	1	(5GS5)
16	90201-20276-00	WASHER, PLATE (1.0T)	1	(5GS5)
17	99009-20400-00	CIRCLIP	1	(5GS5)
18	5BE-15620-02-00	KICK CRANK ASSY	1	(5GS5)
19	3SP-15621-02-00	. BOSS, KICK CRANK	1	(5GS5)
20	90501-13720-00	. SPRING, COMPRESSION	1	(5GS5)
21	93501-04011-00	. BALL	1	(5GS5)
22	90152-06010-00	. SCREW, COUNTERSUNK	1	(5GS5)
23	93210-19216-00	. O-RING	1	(5GS5)
24	90105-08752-00	BOLT, WASHER BASED	1	(5GS5)
25	90201-087A9-00	WASHER, PLATE	1	(5GS5)



CLUTCH

Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-16111-00-00	GEAR, PRIMARY DRIVE	1	(5GS5)
2	90215-21001-00	WASHER, LOCK	1	(5GS5)
3	90179-20001-00	NUT	1	(5GS5)
4	5BE-16150-00-00	PRIMARY DRIVEN GEAR	1	(5GS5)
5	2JN-16371-00-00	BOSS, CLUTCH	1	(5GS5)
6	3YF-16351-00-00	PLATE, PRESSURE 1	1	(5GS5)
7	360-16325-00-00	PLATE, CLUTCH 2	7	(5GS5)
8	5BE-16321-00-00	PLATE, FRICTION	7	(5GS5)
9	90501-23141-00	SPRING, COMPRESSION	5	(5GS5)
10	90159-06092-00	SCREW, WITH WASHER	5	(5GS5)
11	2JN-16154-00-00	PLATE, THRUST 1	1	(5GS5)
12	5BE-16331-00-00	PLATE, FRICTION 2	1	(5GS5)
13	90215-20231-00	WASHER, LOCK	1	(5GS5)
14	90170-20327-00	NUT	1	(5GS5)
15	5BE-16356-00-00	ROD, PUSH 1	1	(5GS5)
16	93340-21505-00	BEARING	1	(5GS5)
17	90201-125L6-00	WASHER, PLATE	1	(5GS5)
18	93440-10085-00	CIRCLIP	1	(5GS5)
19	5BE-16357-00-00	ROD, PUSH 2	1	(5GS5)
20	5BE-16381-00-00	PUSH LEVER COMP.	1	(5GS5)
21	93315-11206-00	BEARING	1	(5GS5)
22	93102-12224-00	OIL SEAL	1	(5GS5)
23	4JT-16384-00-00	PLATE, SEAT	1	(5GS5)
24	95027-06010-00	BOLT, FLANGE	1	(5GS5)
25	90508-142B5-00	SPRING, TORSION	1	(5GS5)




5GS5100-0150

TRANSMISSION

Ref. No.	Part Number	Description	Qty	Remarks
1	5BF-17411-00-00	AXLE, MAIN	1	(5GS5)
2	93306-20532-00	BEARING	1	(5GS5)
3	5BF-17151-00-00	GEAR, 5TH PINION	1	(5GS5)
4	90201-253K0-00	WASHER, PLATE (T=1.0)	1	(5GS5)
5	93440-25084-00	CIRCLIP	3	(5GS5)
6	5BF-17131-10-00	GEAR, 3RD PINION	1	(5GS5)
7	5BF-17141-10-00	GEAR, 4TH PINION	1	(5GS5)
8	90387-2113G-00	COLLAR	1	(5GS5)
9	5BF-17121-00-00	GEAR, 2ND PINION	1	(5GS5)
10	90209-21332-00	WASHER	1	(5GS5)
11	93306-00431-00	BEARING	1	(5GS5)
12	93306-00426-00	BEARING	1	(5GS5)
13	5BE-17421-00-00	AXLE, DRIVE	1	(5GS5)
14	5BF-17211-00-00	GEAR, 1ST WHEEL	1	(5GS5)
15	5BF-17251-00-00	GEAR, 5TH WHEEL	1	(5GS5)
16	93440-25084-00	CIRCLIP	1	(5GS5)
17	90209-21332-00	WASHER	1	(5GS5)
18	90201-253K0-00	WASHER, PLATE (T=1.0)	1	(5GS5)
19	5BF-17231-00-00	GEAR, 3RD WHEEL	1	(5GS5)
20	93440-28062-00	CIRCLIP	1	(5GS5)
21	5BF-17241-00-00	GEAR, 4TH WHEEL	1	(5GS5)
22	90209-26348-00	WASHER	1	(5GS5)
23	5BF-17221-00-00	GEAR, 2ND WHEEL	1	(5GS5)
24	93306-20593-00	BEARING	1	(5GS5)
25	93102-32480-00	OIL SEAL	1	(5GS5)
26	90387-2513F-00	COLLAR	1	(5GS5)
27	93210-22298-00	O-RING	1	(5GS5)
28	9383E-14215-00	SPROCKET, DRIVE (14T)	1	STD (5GS5)
29	90215-21001-00	WASHER, LOCK	1	(5GS5)


CONTINUED ON NEXT FRAME ➤



5GS5100-0160

TRANSMISSION


Ref. No.	Part Number	Description	Qty	Remarks
30	90179-20001-00	NUT	1	(5GS5)
31	5GR-17471-00-00	PLATE, COVER	1	(5GS5)
32	90105-06553-00	BOLT, WASHER BASED	2	(5GS5)



5GS5100-0160

SHIFT CAM. FORK


Ref. No.	Part Number	Description	Qty	Remarks
1	5BE-18541-00-00	CAM, SHIFT	1	(5GS5)
2	93306-90501-00	BEARING	1	(5GS5)
3	4BA-18542-00-00	POINT, NEUTRAL	1	(5GS5)
4	90501-06022-00	SPRING, COMPRESSION	1	(5GS5)
5	3XK-18140-00-00	STOPPER LEVER ASSY	1	(5GS5)
6	90508-26561-00	SPRING, TORSION	1	(5GS5)
7	90109-063F8-00	BOLT	1	(5GS5)
8	5BE-18501-00-00	FORK, SHIFT 1	1	(5GS5)
9	5BE-18502-10-00	FORK, SHIFT 2	1	(5GS5)
10	5BE-18503-00-00	FORK, SHIFT 3	1	(5GS5)



5BE100-8170

SHIFT SHAFT

Ref. No.	Part Number	Description	Qty	Remarks
1	3XK-18101-02-00	SHIFT SHAFT ASSY	1	(5GS5)
2	3XK-18122-00-00	LEVER, SHIFT 2	1	(5GS5)
3	90387-124F4-00	COLLAR	1	(5GS5)
4	90508-291A8-00	SPRING, TORSION	1	(5GS5)
5	93608-33046-00	PIN, DOWEL	1	(5GS5)
6	5BE-18110-00-00	SHIFT PEDAL ASSY	1	(5GS5)
7	95027-06020-00	BOLT, FLANGE	1	(5GS5)
8	93102-12106-00	OIL SEAL (SD 12-22-5 HS)	1	(5GS5)
9	3XJ-18173-00-00	PIN, SHIFT	1	(5GS5)
10	3XJ-18178-00-00	ROLLER, SHIFT LEVER	1	(5GS5)
11	3XJ-18182-00-00	PAWL, SHIFTER	2	(5GS5)
12	90501-052G5-00	SPRING, COMPRESSION	2	(5GS5)
13	3XJ-18184-00-00	PIN, PAWL	2	(5GS5)
14	5BE-18172-00-00	GUIDE, SHIFT	1	(5GS5)
15	90101-06664-00	BOLT	2	(5GS5)
16	4EW-18185-00-00	SEGMENT	1	(5GS5)




5BE100-8180

FRAME


Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-21101-50-P0	FRONT FRAME COMP.	1	DPBMC (5GS5)
2	5BE-21756-00-00	. NET, FILTER	1	(5GS5)
3	90430-18130-00	. GASKET	1	(5GS5)
4	95827-08012-00	. BOLT, FLANGE	1	(5GS5)
5	90430-08119-00	. GASKET	1	(5GS5)
6	5GS-21190-50-P0	REAR FRAME COMP.	1	DPBMC (5GS5)
7	90110-08096-00	BOLT, HEXAGON SOCKET HEAD	2	(5GS5)
8	90105-08099-00	BOLT, WASHER BASED	1	(5GS5)
9	95827-08016-00	BOLT, FLANGE	1	(5GS5)
10	95817-10160-00	BOLT, FLANGE	1	(5GS5)
11	95607-10200-00	NUT, SELF-LOCKING	1	(5GS5)
12	5GR-21425-01-00	BRACKET, REAR UPPER 1 ...	1	(5GS5)
13	5BE-21425-01-00	BRACKET, REAR UPPER 1 ...	1	(5GS5)
14	92017-08055-00	BOLT, BUTTON HEAD	3	(5GS5)
15	90201-086P8-00	WASHER, PLATE	6	(5GS5)
16	90185-08169-00	NUT, SELF-LOCKING	3	(5GS5)
17	95817-10050-00	BOLT, FLANGE	1	(5GS5)
18	90105-10733-00	BOLT, WASHER BASED	1	(5GS5)
19	95607-10200-00	NUT, SELF-LOCKING	1	(5GS5)
20	95027-08040-00	BOLT, FLANGE	1	(5GS5)
21	3JD-22178-10-00	TENSIONER	1	(5GS5)
22	4EW-22178-00-00	TENSIONER	1	(5GS5)
23	93300-60804-00	BEARING	2	(5GS5)
24	90387-086N4-00	COLLAR	2	(5GS5)
25	95027-08065-00	BOLT, FLANGE	1	(5GS5)
26	95707-08500-00	NUT, FLANGE	1	(5GS5)
27	90201-086P8-00	WASHER, PLATE	3	(5GS5)
28	90480-17218-00	GROMMET	2	(5GS5)

CONTINUED ON NEXT FRAME ➤




FRAME

Ref. No.	Part Number	Description	Qty	Remarks
29	5BE-21417-00-00	BRACKET, FRONT LOWER 1	2	(5GS5)
30	95827-08016-00	BOLT, FLANGE	4	(5GS5)
31	5BE-21471-00-00	PROTECTOR, ENGINE	1	(5GS5)
32	5BE-15362-00-00	PLUG, OIL LEVEL	1	(5GS5)
33	93210-19123-00	O-RING	1	(5GS5)
34	5BE-2147A-00-00	GUARD, ENGINE 1	1	(5GS5)
35	95027-08012-00	BOLT, FLANGE	5	(5GS5)
36	5ET-28166-00-00	WRENCH, HEXAGON	1	(5GS5)
37	5BE-2814F-00-00	BOX, SPARK PLUG	1	(5GS5)



FENDER

Ref. No.	Part Number	Description	Qty	Remarks
1	5HD-21511-00-00	FENDER, FRONT	1	(5GS5)
2	3JD-21748-00-00	COLLAR	4	(5GS5)
3	90119-06096-00	BOLT, WITH WASHER	4	(5GS5)
4	99241-00080-00	EMBLEM, YAMAHA	1	(5GS5)
5	5BF-21611-00-00	FENDER, REAR	1	(5GS5)
6	90105-06553-00	BOLT, WASHER BASED	1	(5GS5)
7	90119-06163-00	BOLT, WITH WASHER	1	(5GS5)
8	90480-14323-00	GROMMET	1	(5GS5)
9	90183-06023-00	NUT, SPRING	2	(5GS5)
10	90387-0701A-00	COLLAR	2	(5GS5)
11	5BE-21642-00-00	GUARD, FLAP	1	(5GS5)
12	90105-06690-00	BOLT, WASHER BASED	2	(5GS5)
13	90387-06009-00	COLLAR	2	(5GS5)
14	97707-60016-00	SCREW, TAPPING	2	(5GS5)
15	90201-06557-00	WASHER, PLATE	2	(5GS5)
16	5GS-2163G-00-00	EMBLEM 1	2	(5GS5)
17	99241-00080-00	EMBLEM, YAMAHA	1	(5GS5)



5GS5100-0200

SIDE COVER


Ref. No.	Part Number	Description	Qty	Remarks
1	5BF-21711-00-00	COVER, SIDE 1	1	(5GS5)
2	95827-06016-00	BOLT, FLANGE	1	(5GS5)
3	90119-08238-00	BOLT, WITH WASHER	1	(5GS5)
4	5BF-21721-00-00	COVER, SIDE 2	1	(5GS5)
5	5BF-2174A-00-00	INSULATOR, SIDE COVER ...	1	(5GS5)
6	3FY-21575-01-00	SEAL 1	1	(5GS5)
7	95827-06016-00	BOLT, FLANGE	1	(5GS5)
8	90119-08238-00	BOLT, WITH WASHER	1	(5GS5)
9	5BE-21731-10-00	COVER, SIDE 3	1	(5GS5)
10	5GS-2173E-50-00	GRAPHIC 1	1	(5GS5)
11	90159-06182-00	SCREW, WITH WASHER	2	(5GS5)
12	90159-06078-00	SCREW, WITH WASHER	1	(5GS5)
13	5BF-2172A-10-00	PANEL 1	1	(5GS5)
14	5BE-21741-10-00	COVER, SIDE 4	1	(5GS5)
15	5GS-2173F-50-00	GRAPHIC 2	1	(5GS5)
16	90159-06182-00	SCREW, WITH WASHER	2	(5GS5)
17	90159-06078-00	SCREW, WITH WASHER	1	(5GS5)
18	5BF-2172A-10-00	PANEL 1	1	(5GS5)
19	90183-06069-00	NUT, SPRING	2	(5GS5)
20	5GS-21871-00-00	TANK, RECOVERY	1	(5GS5)
21	26H-21875-00-00	CAP	1	(5GS5)
22	26H-21874-00-00	GASKET	1	(5GS5)
23	90119-06060-00	BOLT, WITH WASHER	1	(5GS5)
24	5BF-21823-00-00	CLAMP, HOSE	1	(5GS5)
25	91A20-05130-00	TUBE, FLEXIBLE VINYL	1	(5GS5)
26	91A21-05105-00	TUBE, FLEXIBLE	1	(5GS5)
27	90467-08017-00	CLIP	3	(5GS5)
28	90464-13077-00	CLAMP	2	(5GS5)
29	90464-13073-00	CLAMP	1	(5GS5)

CONTINUED ON NEXT FRAME ➤


5GS5110-0210

SIDE COVER


Ref. No.	Part Number	Description	Qty	Remarks
30	90464-16039-00	CLAMP	1	(5GS5)



5GS5110-0210

REAR ARM

Ref. No.	Part Number	Description	Qty	Remarks
1	5CU-22110-00-00	REAR ARM COMP.	1	(5GS5)
2	90151-04048-00	SCREW, COUNTERSUNK	4	(5GS5)
3	5ET-22355-00-00	PATCH	2	(5GS5)
4	93317-22262-00	BEARING	4	(5GS5)
5	90338-16148-00	PLUG	2	(5GS5)
6	93106-22019-00	OIL SEAL (DC 22-28-8)	2	(5GS5)
7	93342-22217-00	BEARING	2	(5GS5)
8	93109-28043-00	OIL SEAL	2	(5GS5)
9	90387-1714R-00	COLLAR	2	(5GS5)
10	90387-1714S-00	COLLAR	2	(5GS5)
11	5JG-22151-00-00	SEAL, GUARD	1	(5GS5)
12	98507-05008-00	SCREW, PAN HEAD	4	(5GS5)
13	5JG-22156-00-00	WASHER, PLATE	4	(5GS5)
14	4XM-22199-00-00	SUPPORT, CHAIN	1	(5GS5)
15	4XM-22128-00-00	COVER, THRUST 1	1	(5GS5)
16	95027-06050-00	BOLT, FLANGE	2	(5GS5)
17	90179-06568-00	NUT	2	(5GS5)
18	95027-06010-00	BOLT, FLANGE	1	(5GS5)
19	5DH-22141-00-00	SHAFT, PIVOT	1	(5GS5)
20	90185-16127-00	NUT, SELF-LOCKING	1	(5GS5)
21	90201-164H4-00	WASHER, PLATE	1	(5GS5)
22	5ET-2217A-00-00	ARM, RELAY	1	(5GS5)
23	93315-32056-00	BEARING	2	(5GS5)
24	93109-20076-00	OIL SEAL	4	(5GS5)
25	90387-164N2-00	COLLAR	2	(5GS5)
26	90387-164N3-00	COLLAR	2	(5GS5)
27	90387-167Y9-00	COLLAR	1	(5GS5)
28	90109-147F2-00	BOLT	1	(5GS5)
29	90109-142F4-00	BOLT	2	(5GS5)




5JG1100-0220


CONTINUED ON NEXT FRAME ➤

REAR ARM

Ref. No.	Part Number	Description	Qty	Remarks
30	90201-164H4-00	WASHER, PLATE	2	(5GS5)
31	90201-14740-00	WASHER, PLATE	3	(5GS5)
32	90185-14112-00	NUT, SELF-LOCKING	1	(5GS5)
33	95617-14100-00	NUT, U	2	(5GS5)
34	5DH-2217F-01-00	ROD, CONNECTING 1	1	(5GS5)
35	93315-32056-00	BEARING	2	(5GS5)
36	93109-20076-00	OIL SEAL	2	(5GS5)
37	5HD-2135F-00-00	COVER	2	(5GS5)
38	99244-00200-00	EMBLEM, YAMAHA	2	(5GS5)



REAR SUSPENSION




Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-22210-50-00	SHOCK ABSORBER ASSY, REAR	1	(5GS5)
2	5GS-22201-50-00	. DAMPER SUB ASSY	1	(5GS5)
3	3SP-22234-00-00	.. GUIDE, SPRING 3	1	(5GS5)
4	3SP-22213-00-00	.. SEAT, SPRING UPPER	1	(5GS5)
5	509-23184-L0-00	.. CAP, AIR VALVE	1	(5GS5)
6	4JX-22226-00-00	.. BUSH, SHOCK ABSORBER LOWER	1	(5GS5)
7	5DH-23183-00-00	.. CIRCLIP	1	(5GS5)
8	5DH-23183-00-00	.. CIRCLIP	1	(5GS5)
9	4JX-22226-00-00	.. BUSH, SHOCK ABSORBER LOWER	1	(5GS5)
10	5DH-22212-30-00	. SPRING (K=5.0)	1	(5GS5)
11	5DH-22214-00-00	. GUIDE, SPRING 1	1	(5GS5)
12	5DH-22224-00-00	. GUIDE, SPRING 2	1	(5GS5)
13	5DH-22253-00-00	. COLLAR, DISTANCE	2	(5GS5)
14	3JE-22475-00-00	. SEAL, DUST	4	(5GS5)
15	4EW-22253-00-00	. COLLAR, DISTANCE	2	(5GS5)
16	4EW-22474-00-00	. SEAL, RING	4	(5GS5)
17	90105-10323-00	BOLT, WASHER BASED	1	(5GS5)
18	95607-10200-00	NUT, SELF-LOCKING	1	(5GS5)
19	90105-105A2-00	BOLT, WASHER BASED	1	(5GS5)
20	90201-112U6-00	WASHER, PLATE	1	(5GS5)

 5GR100-9230

STEERING


Ref. No.	Part Number	Description	Qty	Remarks
1	93332-00081-00	BEARING	1	(5GS5)
2	93332-00068-00	BEARING	1	(5GS5)
3	4EW-23416-00-00	COVER, BALL RACE 2	1	(5GS5)
4	90179-28650-00	NUT	1	(5GS5)
5	5GS-23435-50-00	CROWN, HANDLE	1	(5GS5)
6	90170-24373-00	NUT	1	(5GS5)
7	90201-247L2-00	WASHER, PLATE	1	(5GS5)
8	3SP-23441-00-00	HOLDER, HANDLE UPPER ...	2	(5GS5)
9	95027-08035-00	BOLT, FLANGE	4	(5GS5)
10	95027-08040-00	BOLT, FLANGE	4	(5GS5)
11	4GY-2831V-00-00	STAY, HEAD LIGHT 1	1	(5GS5)
12	4GY-2832V-00-00	STAY, HEAD LIGHT 2	1	(5GS5)
13	4GY-23389-00-00	GUIDE, CABLE	1	(5GS5)
14	90105-05361-00	BOLT, WASHER BASED	1	(5GS5)
15	90201-286K9-00	WASHER, PLATE	2	(5GS5)
16	4DA-23389-00-00	GUIDE, CABLE	1	(5GS5)
17	90119-05071-00	BOLT, WITH WASHER	1	(5GS5)



5GS5100-0240

FRONT FORK

Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-23102-50-00	FRONT FORK ASSY (L.H)	1	(5GS5)
2	5HD-23136-L0-00	. TUBE, OUTER (RIGHT)	1	(5GS5)
3	5DH-23120-L0-00	. INNER TUBE COMP 2	1	(5GS5)
4	5ET-23171-L0-00	. PISTON, FRONT FORK	1	(5GS5)
5	5ET-23125-L0-00	. METAL, SLIDE 1	1	(5GS5)
6	4SS-23146-L0-00	. WASHER, OIL SEAL	1	(5GS5)
7	5ET-23145-L0-00	. OIL SEAL	1	(5GS5)
8	4SS-23153-L0-00	. RING, SNAP	1	(5GS5)
9	5HD-23144-L0-00	. SEAL, DUST	1	(5GS5)
10	5GS-23170-50-00	. CYLINDER COMP., FRONT FORK	1	(5GS5)
11	5GS-2316A-50-00	. VALVE COMP.	1	(5GS5)
12	5HD-23111-L0-00	. BOLT, CAP	1	(5GS5)
13	5DH-23142-L0-00	. SEAT, SPRING UPPER	1	(5GS5)
14	5HD-23393-L0-00	. NUT, SPECIAL	1	(5GS5)
15	5DH-23195-L0-00	. RUBBER	1	(5GS5)
16	5DH-23149-L0-00	. WASHER, SPRING UPPER	1	(5GS5)
17	5DH-23118-L0-00	. SPACER	1	(5GS5)
18	4SS-23158-L0-00	. GASKET	1	(5GS5)
19	5GR-23141-L0-00	. SPRING, FRONT FORK (K=0.46)	1	(5GS5)
20	3JD-2312G-L0-00	. PLUG	1	(5GS5)
21	5GS-23103-50-00	FRONT FORK ASSY (R.H)	1	(5GS5)
22	5HD-23136-L0-00	. TUBE, OUTER (RIGHT)	1	(5GS5)
23	5BF-23110-L0-00	. INNER TUBE COMP 1	1	(5GS5)
24	5ET-23171-L0-00	. PISTON, FRONT FORK	1	(5GS5)
25	5ET-23125-L0-00	. METAL, SLIDE 1	1	(5GS5)
26	4SS-23146-L0-00	. WASHER, OIL SEAL	1	(5GS5)
27	5ET-23145-L0-00	. OIL SEAL	1	(5GS5)




CONTINUED ON NEXT FRAME ►


5GS5110-0250

FRONT FORK


Ref. No.	Part Number	Description	Qty	Remarks
28	4SS-23153-L0-00	. RING, SNAP	1	(5GS5)
29	5HD-23144-L0-00	. SEAL, DUST	1	(5GS5)
30	5GS-23170-50-00	. CYLINDER COMP., FRONT FORK	1	(5GS5)
31	5GS-2316A-50-00	. VALVE COMP.	1	(5GS5)
32	5HD-23111-L0-00	. BOLT, CAP	1	(5GS5)
33	5DH-23142-L0-00	. SEAT, SPRING UPPER	1	(5GS5)
34	5HD-23393-L0-00	. NUT, SPECIAL	1	(5GS5)
35	5DH-23195-L0-00	. RUBBER	1	(5GS5)
36	5DH-23149-L0-00	. WASHER, SPRING UPPER ..	1	(5GS5)
37	5DH-23118-L0-00	. SPACER	1	(5GS5)
38	4SS-23158-L0-00	. GASKET	1	(5GS5)
39	5GR-23141-L0-00	. SPRING, FRONT FORK (K=0.46)	1	(5GS5)
40	3JD-2312G-L0-00	. PLUG	1	(5GS5)
41	5GS-23340-50-00	UNDER BRACKET COMP.	1	(5GS5)
42	95021-08040-00	BOLT, FLANGE	8	(5GS5)
43	4SS-2314G-L0-00	PROTECTOR GUIDE COMP., 2	1	(5GS5)
44	5DH-2314F-L0-00	PROTECTOR GUIDE COMP., 1	1	(5GS5)
45	4SS-23346-L0-00	BOLT 1	2	(5GS5)
46	5BF-2314J-00-00	PROTECTOR COMP., 2	1	(5GS5)
47	5DH-2314H-00-00	PROTECTOR COMP., 1	1	(5GS5)
48	3SP-23356-L0-00	BOLT 2	6	(5GS5)
49	5HC-2331E-00-00	GUIDE, CABLE	1	(5GS5)



5GS5110-0250

FUEL TANK


Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-24110-00-00	FUEL TANK COMP.	1	(5GS5)
2	1UY-24610-00-00	CAP ASSY	1	(5GS5)
3	90445-09220-00	HOSE	1	(5GS5)
4	3XJ-24380-00-00	PIPE JOINT ASSY	1	(5GS5)
5	90445-09100-00	HOSE	1	(5GS5)
6	24X-24144-00-00	HOLDER, DAMPER	2	(5GS5)
7	90480-18549-00	GROMMET	2	(5GS5)
8	95027-06016-00	BOLT, FLANGE	4	(5GS5)
9	90119-06214-00	BOLT, WITH WASHER	2	(5GS5)
10	3JD-24186-00-00	WASHER, SPECIAL	2	(5GS5)
11	98907-06020-00	SCREW, BIND	1	(5GS5)
12	3SP-24173-00-00	BAND, TANK FITTING 1	1	(5GS5)
13	4EW-2412F-00-00	BRACKET, SEAT	1	(5GS5)
14	98707-06025-00	SCREW, FLAT HEAD	1	(5GS5)
15	4SS-24181-00-00	DAMPER, LOCATING 1	1	(5GS5)
16	2GU-24500-01-00	FUEL COCK ASSY 1	1	(5GS5)
17	3AJ-24534-00-00	. SEAL, COCK	1	(5GS5)
18	97801-03008-00	. SCREW, PAN HEAD	2	(5GS5)
19	4X8-24512-00-00	. O-RING	1	(5GS5)
20	3AJ-24523-00-00	. VALVE PACKING	1	(5GS5)
21	90445-114K9-00	HOSE	1	(5GS5)
22	90467-10008-00	CLIP	2	(5GS5)
23	90202-05193-00	WASHER, PLATE	2	(5GS5)
24	90149-06011-00	SCREW	2	(5GS5)
25	5BE-24182-00-00	DAMPER, LOCATING 2	1	(5GS5)
26	3V6-22358-00-00	SEAL 1	2	(5GS5)
27	5GS-24240-50-00	GRAPHIC SET	1	(5GS5)



5GS5110-0260

SEAT


Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-24710-00-00	SINGLE SEAT ASSY	1	(5GS5)
2	5GS-24731-00-00	. COVER, SEAT	1	(5GS5)
3	5BE-24728-00-00	. BRACKET, SEAT	2	(5GS5)
4	97007-06012-00	. BOLT	4	(5GS5)
5	92907-06100-00	. WASHER, SPRING	4	(5GS5)



5BE100-8270

FRONT WHEEL


Ref. No.	Part Number	Description	Qty	Remarks
1	5BF-25111-01-00	HUB, FRONT	1	(5GS5)
2	93306-90403-00	BEARING	2	(5GS5)
3	5DH-25117-00-00	SPACER, BEARING	1	(5GS5)
4	93102-26468-00	OIL SEAL	1	(5GS5)
5	94416-21613-00	RIM (1.60-21)	1	(5GS5)
6	4DA-25104-00-00	SPOKE SET, FRONT	1	(5GS5)
7	94108-21008-00	TIRE (80/100-21 51M D739F) ..	1	DUNLOP (5GS5)
8	94227-21123-00	TUBE (80/100-21 TR4 BTL) ...	1	DUNLOP (5GS5)
9	94330-21084-00	BAND, RIM (70-80/100-21)	1	DUNLOP (5GS5)
10	2J5-25394-01-00	SPACER, BEAD	1	(5GS5)
11	5BE-25181-00-00	AXLE, WHEEL	1	(5GS5)
12	5DH-25183-00-00	COLLAR, WHEEL	1	(5GS5)
13	5BF-25190-01-00	GEAR UNIT ASSY	1	(5GS5)
14	90179-16672-00	NUT	1	(5GS5)



5BF100-8280


FRONT BRAKE CALIPER

Ref. No.	Part Number	Description	Qty	Remarks
1	4XM-2582T-00-00	DISC, BRAKE	1	(5GS5)
2	90149-06327-00	SCREW	6	(5GS5)
3	5DH-2580T-00-00	CALIPER ASSY (LEFT)	1	(5GS5)
4	4EW-W0057-00-00	. PISTON ASSY, CALIPER	1	(5GS5)
5	3JD-W0047-00-00	. . CALIPER SEAL KIT	1	(5GS5)
6	5DH-25919-00-00	. SUPPORT, PAD	1	(5GS5)
7	1UY-W0048-50-00	. BLEED SCREW KIT	1	(5GS5)
8	5DH-W0045-00-00	. BRAKE PAD KIT	1	(5GS5)
9	5DH-25933-00-00	. PIN, PAD	1	(5GS5)
10	5DH-25916-00-00	. PLUG	1	(5GS5)
11	90105-08659-00	BOLT, WASHER BASED	2	(5GS5)
12	5DH-2314E-00-00	COVER, HOSE	1	(5GS5)
13	95827-06012-00	BOLT, FLANGE	1	(5GS5)
14	95027-08020-00	BOLT, FLANGE	1	(5GS5)
15	5DH-25875-00-00	HOLDER, BRAKE HOSE 1	1	(5GS5)
16	92907-08200-00	WASHER	1	(5GS5)



5BE100-8290

REAR WHEEL




Ref. No.	Part Number	Description	Qty	Remarks
1	5ET-25311-00-00	HUB, REAR	1	(5GS5)
2	5ET-25317-00-00	SPACER, BEARING	1	(5GS5)
3	93306-27205-00	BEARING	1	(5GS5)
4	93306-07202-00	BEARING	1	(5GS5)
5	93106-30044-00	OIL SEAL	1	(5GS5)
6	93106-30045-00	OIL SEAL	1	(5GS5)
7	99009-45500-00	CIRCLIP	1	(5GS5)
8	94421-18610-00	RIM (2.15-18)	1	(5GS5)
9	5GS-25304-00-00	SPOKE SET, REAR	1	(5GS5)
10	94111-18008-00	TIRE (110/100-18 64M D739) ..	1	DUNLOP (5GS5)
11	94212-18188-00	TUBE (120/90-18)	1	DUNLOP (5GS5)
12	94309-18146-00	BAND, RIM (110/100-18)	1	DUNLOP (5GS5)
13	3JE-25394-00-00	SPACER, BEAD	2	(5GS5)
14	4XM-25364-00-00	DAMPER	2	(5GS5)
15	5GS-25448-50-00	SPROCKET, DRIVEN (48T) ...	1	AP (5GS5)
	5GS-25450-50-00	SPROCKET, DRIVEN (50T) ...	1	STD (5GS5)
	5GS-25452-50-00	SPROCKET, DRIVEN (52T) ...	1	AP (5GS5)
16	90109-081G1-00	BOLT	6	(5GS5)
17	90185-08169-00	NUT, SELF-LOCKING	6	(5GS5)
18	90201-08326-00	WASHER, PLATE	6	(5GS5)
19	5ET-25383-00-00	COLLAR, WHEEL	2	(5GS5)
20	5ET-25388-00-00	PULLER, CHAIN 1	1	(5GS5)
21	5ET-25389-00-00	PULLER, CHAIN 2	1	(5GS5)
22	90101-08777-00	BOLT	2	(5GS5)
23	90179-08299-00	NUT	2	(5GS5)
24	5ET-25381-00-00	AXLE, WHEEL	1	(5GS5)
25	90185-20168-00	NUT, SELF-LOCKING	1	(5GS5)
26	90201-203U1-00	WASHER, PLATE	1	(5GS5)
27	9Y581-76113-00	CHAIN (DID 520VM-114LL) ...	1	(5GS5)

CONTINUED ON NEXT FRAME ➤


REAR WHEEL

Ref. No.	Part Number	Description	Qty	Remarks
28	94681-76001-00	. JOINT, CHAIN	1	(5GS5)
29	5ET-25367-00-00	COVER, HUB DUST	2	(5GS5)



REAR BRAKE CALIPER


Ref. No.	Part Number	Description	Qty	Remarks
1	5DH-2582W-00-00	DISC, REAR BRAKE 2	1	(5GS5)
2	90109-065G4-00	BOLT	6	(5GS5)
3	5GR-2580W-00-00	CALIPER ASSY, REAR 2	1	(5GS5)
4	5ET-W0057-50-00	. PISTON ASSY, CALIPER	1	(5GS5)
5	5ET-W0047-50-00	. . CALIPER SEAL KIT	1	(5GS5)
6	5DH-25919-50-00	. SUPPORT, PAD	1	(5GS5)
7	1UY-W0048-50-00	. BLEED SCREW KIT	1	(5GS5)
8	5GR-W0046-00-00	. BRAKE PAD KIT 2	1	(5GS5)
9	5DH-25828-50-00	. . SHIM, CALIPER	1	(5GS5)
10	5DH-25827-50-00	. . SHIM, CALIPER	1	(5GS5)
11	5GR-22898-50-00	. . INSULATOR, HEAT	2	(5GS5)
12	8CR-25924-00-00	. PIN, PAD	1	(5GS5)
13	5DH-25916-00-00	. PLUG	1	(5GS5)
14	5DH-25718-01-00	PROTECTOR, DISK BRAKE ...	1	(5GS5)
15	95027-06012-00	BOLT, FLANGE	2	(5GS5)
16	4GY-27491-00-00	PROTECTOR	1	(5GS5)
17	95027-06016-00	BOLT, FLANGE	2	(5GS5)



5GS1100-9310

STEERING HANDLE. CABLE


Ref. No.	Part Number	Description	Qty	Remarks
1	4XM-26111-00-00	HANDLEBAR	1	(5GS5)
2	4GY-26241-00-00	GRIP (LEFT)	1	(5GS5)
3	5BE-26240-00-00	GRIP ASSY	1	(5GS5)
4	4GY-26242-00-00	. GRIP (RIGHT)	1	(5GS5)
5	3Y1-26249-00-00	. RING, LEAF	1	(5GS5)
6	5BE-26281-00-00	CAP, GRIP UPPER	1	(5GS5)
7	5BE-26282-00-00	CAP, GRIP LOWER	1	(5GS5)
8	98507-05020-00	SCREW, PAN HEAD	2	(5GS5)
9	5JG-26302-00-00	THROTTLE CABLE ASSY	1	(5GS5)
10	5JG-26335-00-00	CABLE, CLUTCH	1	(5GS5)
11	90387-225N2-00	COLLAR	1	(5GS5)
12	5HD-26342-00-00	BOOT, CABLE	1	(5GS5)
13	5JG-26372-00-00	COVER, HANDLE LEVER 1 ...	1	(5GS5)



5GS5100-0320

FRONT MASTER CYLINDER


Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-25872-00-00	HOSE, BRAKE 1	1	(5GS5)
2	90201-10118-00	WASHER, PLATE	4	(5GS5)
3	90401-10172-00	BOLT, UNION	2	(5GS5)
4	4SS-W2587-01-00	MASTER CYLINDER SUB ASSY	1	(5GS5)
5	4SS-W0041-00-00	. CYLINDER KIT, MASTER	1	(5GS5)
6	98706-04012-00	. SCREW, FLAT HEAD	2	(5GS5)
7	4SS-25852-00-00	. CAP, RESERVOIR	1	(5GS5)
8	4SS-25854-00-00	. DIAPHRAGM, RESERVOIR ..	1	(5GS5)
9	4SS-25889-00-00	. SEPARATOR ASSY	1	(5GS5)
10	4SS-25880-00-00	. PUSH ROD COMP.	1	(5GS5)
11	4SS-25868-00-00	. BOOT, MASTER CYLINDER ..	1	(5GS5)
12	4SS-2538E-00-00	NUT, ADJUSTING	2	(5GS5)
13	4SS-83913-00-00	COLLAR, LEVER 1	1	(5GS5)
14	3YX-25866-10-00	CIRCLIP	1	(5GS5)
15	4SS-25866-00-00	CIRCLIP	1	(5GS5)
16	4SS-2583G-00-00	WASHER	1	(5GS5)
17	4SS-83922-01-00	LEVER 2	1	(5GS5)
18	95606-06100-00	NUT, U	1	(5GS5)
19	4SS-2589F-00-00	BOLT, LEVER	1	(5GS5)
20	3YK-25867-00-00	BRACKET, MASTER CYLINDER	1	(5GS5)
21	4SS-25833-00-00	BOLT, FITTING	2	(5GS5)
22	90465-16258-00	CLAMP	2	(5GS5)
23	91317-06014-00	BOLT	2	(5GS5)



5BE100-8330

STAND. FOOTREST


Ref. No.	Part Number	Description	Qty	Remarks
1	4XM-27200-00-00	PEDAL, BRAKE	1	(5GS5)
2	5JG-27217-00-00	BOLT	1	(5GS5)
3	93210-11073-00	O-RING	2	(5GS5)
4	91401-20012-00	PIN, COTTER	1	(5GS5)
5	90506-16500-00	SPRING, TENSION	1	(5GS5)
6	90240-08120-00	PIN, CLEVIS	1	(5GS5)
7	90201-08089-00	WASHER, PLATE	1	(5GS5)
8	90468-16191-00	CLIP	1	(5GS5)
9	5ET-27411-00-00	FOOTREST 1	1	(5GS5)
10	5ET-27421-00-00	FOOTREST 2	1	(5GS5)
11	90240-10142-00	PIN, CLEVIS	2	(5GS5)
12	91401-25015-00	PIN, COTTER	2	(5GS5)
13	90508-282B8-00	SPRING, TORSION	1	(5GS5)
14	90508-282B9-00	SPRING, TORSION	1	(5GS5)
15	90201-10119-00	WASHER, PLATE	2	(5GS5)
16	5BF-27311-00-00	STAND, SIDE	1	(5GS5)
17	90506-35473-00	SPRING, TENSION	1	(5GS5)
18	5GS-27315-50-00	LINK, SIDE STAND	1	(5GS5)
19	90101-10738-00	BOLT	1	(5GS5)
20	90201-112U6-00	WASHER, PLATE	1	(5GS5)
21	90387-1003G-00	COLLAR	1	(5GS5)
22	92990-10200-00	WASHER, PLAIN	1	(5GS5)
23	95617-10100-00	NUT, U	1	(5GS5)
24	5GS-21458-50-00	BRACKET, SIDE STAND	1	(5GS5)
25	95027-10020-00	BOLT, FLANGE	2	(5GS5)



5GS5100-0340

REAR MASTER CYLINDER


Ref. No.	Part Number	Description	Qty	Remarks
1	5JG-2583V-00-00	RR. MASTER CYLINDER ASSY.	1	(5GS5)
2	4SS-W0042-50-00	. CYLINDER KIT, MASTER	1	(5GS5)
3	93210-15620-00	. O-RING	1	(5GS5)
4	2VN-25866-00-00	. CIRCLIP	1	(5GS5)
5	4ML-2582A-50-00	. JOINT	1	(5GS5)
6	3SP-27222-00-00	. JOINT	1	(5GS5)
7	95301-08700-00	. NUT	2	(5GS5)
8	5BE-25894-00-00	. TANK, RESERVOIR	1	(5GS5)
9	5BE-25852-00-00	. CAP, RESERVOIR	1	(5GS5)
10	98706-04040-00	. SCREW, FLAT HEAD	2	(5GS5)
11	56A-25854-00-00	. DIAPHRAGM, RESERVOIR ..	1	(5GS5)
12	90467-12085-00	. CLIP	2	(5GS5)
13	5BE-25895-00-00	. HOSE, RESERVOIR	1	(5GS5)
14	3FV-2589A-00-00	. COVER, DUST	1	(5GS5)
15	5BE-2117M-00-00	COVER 2	1	(5GS5)
16	92014-06016-00	BOLT, BUTTON HEAD	2	(5GS5)
17	95027-06012-00	BOLT, FLANGE	1	(5GS5)
18	5DH-25873-00-00	HOSE, BRAKE 2	1	(5GS5)
19	90401-10172-00	BOLT, UNION	2	(5GS5)
20	90201-10118-00	WASHER, PLATE	3	(5GS5)
21	2VM-25876-00-00	HOLDER, BRAKE HOSE 2	2	(5GS5)
22	97780-50510-00	SCREW, TAPPING	4	(5GS5)
23	5BE-25844-00-00	WASHER, LOCK	1	(5GS5)



5BE100-8350

GENERATOR


Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-85560-50-00	BASE ASSY	1	(5GS5)
2	5BF-85550-00-00	ROTOR ASSY	1	(5GS5)
3	90149-06324-00	SCREW	3	(5GS5)
4	90179-10247-00	NUT	1	(5GS5)
5	90201-101J1-00	WASHER, PLATE	1	(5GS5)




5BF100-8360

METER


Ref. No.	Part Number	Description	Qty	Remarks
1	2HR-83505-G0-00	TRIP METER COMP.	1	MILE (5GS5)
2	4V5-83513-00-00	DAMPER	1	(5GS5)
3	2HR-83519-01-00	BRACKET, METER	1	(5GS5)
4	1M1-83526-00-00	DAMPER 2	2	(5GS5)
5	90201-05033-00	WASHER, PLATE	2	(5GS5)
6	437-83525-00-00	CLIP	2	(5GS5)
7	11H-83578-00-00	KNOB, TRIP METER	1	(5GS5)
8	90157-02031-00	SCREW, PAN HEAD	1	(5GS5)
9	2HR-83592-00-00	DAMPER	1	(5GS5)
10	95027-06010-00	BOLT, FLANGE	2	(5GS5)
11	5BF-83550-00-00	SPEEDOMETER CABLE ASSY	1	(5GS5)
12	5BF-2317M-00-00	STAY 3	1	(5GS5)
13	92017-05008-00	BOLT, BUTTON HEAD	2	(5GS5)
14	5BF-84319-00-00	STAY, HEADLIGHT 2	1	(5GS5)
15	95027-06010-00	BOLT, FLANGE	2	(5GS5)



5BF100-8370

HEADLIGHT


Ref. No.	Part Number	Description	Qty	Remarks
1	5BF-84310-00-00	HEADLIGHT UNIT ASSY	1	(5GS5)
2	5V2-84314-00-XX	. BULB (12V-60/55W)	1	(H4)HALOGEN (5GS5)
3	5BF-84397-00-00	. COVER, SOCKET	1	(5GS5)
4	5BF-84330-00-00	BODY ASSY	1	(5GS5)
5	55U-84337-00-00	BOLT, SPECIAL	2	(5GS5)
6	5BF-8433E-00-00	SCREW, ADJUSTING	1	(5GS5)
7	5BF-84335-00-00	SPRING	1	(5GS5)
8	5BF-84334-00-00	NUT, ADJUSTING	1	(5GS5)
9	90159-06189-00	SCREW, WITH WASHER	3	(5GS5)
10	5BF-2339E-00-00	GRAPHIC 1	1	(5GS5)



5GS5100-0380


TAILLIGHT

Ref. No.	Part Number	Description	Qty	Remarks
1	5BF-84710-00-00	TAILLIGHT UNIT ASSY	1	(5GS5)
2	1A2-84714-41-00	. BULB, TAILLIGHT (12V-21/5W)	1	(5GS5)
3	4GY-84733-00-00	. LENS, TAILLIGHT	1	(5GS5)
4	97706-40530-00	. SCREW, TAPPING	2	(5GS5)
5	4GY-84723-00-00	. GASKET, TAIL LENS	1	(5GS5)
6	90387-065L5-00	COLLAR	3	(5GS5)
7	90201-06057-00	WASHER, PLATE	3	(5GS5)
8	95707-06500-00	NUT, FLANGE	3	(5GS5)
9	90480-14102-00	GROMMET	3	(5GS5)
10	90461-11099-00	CLAMP	2	(5GS5)
11	97780-40010-00	SCREW, TAPPING	2	(5GS5)



HANDLE SWITCH. LEVER


Ref. No.	Part Number	Description	Qty	Remarks
1	5HD-82911-00-00	HOLDER, LEVER 1	1	(5GS5)
2	38V-82913-00-00	HOLDER, LEVER LOWER 1 ...	1	(5GS5)
3	5HD-83912-00-00	LEVER 1	1	(5GS5)
4	90109-06027-00	BOLT	1	(5GS5)
5	95607-06100-00	NUT, U	1	(5GS5)
6	97007-05016-00	BOLT	2	(5GS5)
7	5HD-26337-00-00	BOLT, ADJUSTING	1	(5GS5)
8	5HD-83951-00-00	BOLT, CABLE ADJUSTING ...	1	(5GS5)
9	5HD-26372-00-00	COVER, HANDLE LEVER 1 ...	1	(5GS5)
10	23X-83976-00-00	SWITCH, HANDLE 1	1	(5GS5)
11	5BF-83976-00-00	SWITCH, HANDLE 1	1	(5GS5)
12	98507-04014-00	. SCREW, PAN HEAD	2	(5GS5)
13	583-83981-00-00	LEVER, DECOMPRESSION ...	1	(5GS5)
14	5BE-83913-00-00	COLLAR, LEVER 1	1	(5GS5)
15	98907-05020-00	SCREW, BIND	1	(5GS5)
16	95607-05100-00	NUT, U	1	(5GS5)
17	5BE-82912-00-00	HOLDER, LEVER UPPER 1 ...	1	(5GS5)
18	38V-82913-00-00	HOLDER, LEVER LOWER 1 ...	1	(5GS5)
19	97007-05016-00	BOLT	2	(5GS5)
20	583-26352-00-00	COVER, DECOMPRESSION CABLE	1	(5GS5)




5GS5100-0400

ELECTRICAL 1

Ref. No.	Part Number	Description	Qty	Remarks
1	5GS-85540-50-00	C.D.I. UNIT ASSY	1	(5GS5)
2	5BE-85546-00-00	BAND	1	(5GS5)
3	5BE-82310-00-00	IGNITION COIL ASSY	1	(5GS5)
4	91317-06016-00	BOLT	2	(5GS5)
5	5BE-82370-00-00	PLUG CAP ASSY	1	(5GS5)
6	5BE-82540-01-00	NEUTRAL SWITCH ASSY	1	(5GS5)
7	93210-21276-00	O-RING	1	(5GS5)
8	90154-05073-00	SCREW, BINDING	2	(5GS5)
9	90464-16061-00	CLAMP	2	(5GS5)
10	90464-13073-00	CLAMP	1	(5GS5)
11	90464-15195-00	CLAMP	1	(5GS5)
12	90460-15126-00	CLAMP, HOSE	1	(5GS5)
13	90464-13077-00	CLAMP	2	(5GS5)
14	90464-15152-00	CLAMP	2	(5GS5)
15	90464-13073-00	CLAMP	1	(5GS5)
16	90465-13275-00	CLAMP	1	(5GS5)
17	90464-15195-00	CLAMP	2	(5GS5)
18	90465-13152-00	CLAMP	1	(5GS5)
19	5GS-82509-50-00	WIRE, SUB LEAD	1	(5GS5)
20	5GS-81910-50-00	VOLTAGE REGULATOR ASSY	1	(5GS5)
21	95827-06020-00	BOLT, FLANGE	2	(5GS5)



ALTERNATE (CHASSIS)



Ref. No.	Part Number	Description	Qty	Remarks
1	5DH-22212-10-00	SPRING (K=4.6)	1	AP (5GS5)
	5DH-22212-20-00	SPRING (K=4.8)	1	AP (5GS5)
	5DH-22212-30-00	SPRING (K=5.0)	1	AP (5GS5)
	5DH-22212-40-00	SPRING (K=5.2)	1	AP (5GS5)
	5DH-22212-50-00	SPRING (K=5.4)	1	AP (5GS5)
	5DH-22212-60-00	SPRING (K=5.6)	1	AP (5GS5)
	5DH-22212-70-00	SPRING (K=4.4)	1	AP (5GS5)
	5ET-22212-00-00	SPRING (K=APPROX.4.8)	1	AP (5GS5)
	5ET-22212-10-00	SPRING (K=APPROX.5.0)	1	AP (5GS5)
	5ET-22212-20-00	SPRING (K=APPROX.4.6)	1	AP (5GS5)
	5ET-22212-30-00	SPRING (K=APPROX.5.2)	1	AP (5GS5)
	5ET-22212-40-00	SPRING (K=APPROX.5.4)	1	AP (5GS5)
	5ET-22212-50-00	SPRING (K=APPROX.5.6)	1	AP (5GS5)
2	4SS-23141-10-00	SPRING, FRONT FORK (K=0.38)	2	AP (5GS5)
	4SS-23141-20-00	SPRING, FRONT FORK (K=0.39)	2	AP (5GS5)
	4SS-23141-30-00	SPRING, FRONT FORK (K=0.40)	2	AP (5GS5)
	4SS-23141-40-00	SPRING, FRONT FORK (K=0.41)	2	AP (5GS5)
	4SS-23141-50-00	SPRING, FRONT FORK (K=0.42)	2	AP (5GS5)
	4SS-23141-60-00	SPRING, FRONT FORK (K=0.43)	2	AP (5GS5)
	4SS-23141-70-00	SPRING, FRONT FORK (K=0.44)	2	AP (5GS5)
	5BE-23141-00-00	SPRING, FRONT FORK (K=0.46)	2	AP (5GS5)
	5BE-23141-L0-00	SPRING, FRONT FORK (K=0.45)	2	AP (5GS5)
	5ET-23141-00-00	SPRING (K=APPROX.0.41)	2	AP (5GS5)
	5ET-23141-10-00	SPRING (K=APPROX.0.43)	2	AP (5GS5)
	5ET-23141-20-00	SPRING (K=APPROX.0.40)	2	AP (5GS5)
	5ET-23141-30-00	SPRING (K=APPROX.0.42)	2	AP (5GS5)
	5ET-23141-40-00	SPRING (K=APPROX.0.44)	2	AP (5GS5)
	5GR-23141-00-00	SPRING, FRONT FORK (K=0.47)	2	AP (5GS5)
3	4SS-23364-L0-00	COLLAR 2	2	UN (5GS5)

 5BE100-8390