



PARTS CATALOGUE

YFM600FM

(5GT6) U49

YFM600FMC

(5GT7) CALIFORNIA

YFM600FHM

(5GT9) U49

YFM600FHMC

(5GTA) CALIFORNIA

YFM600FM/YFM600FMC/
YFM600FHM/YFM600FHC
PARTS CATALOGUE

©2001 by Yamaha Motor Co., Ltd.

1st Edition, Jan. 2001

All rights reserved.

Any reprinting or unauthorized use
without the written permission of

Yamaha Motor Co., Ltd.
is expressly prohibited.

Printed in Japan



FOREWORD

This Parts Catalogue is related to the parts for the model(s) in the below frame. When you are ordering replacement parts, please refer to this Parts Catalogue and quote both part numbers and part names correctly.

YFM600FM(5GT6), YFM600FMC(5GT7), YFM600FHM(5GT9),
YFM600FPMC(5GTA)

1. Modifications or additions which have been made after issue of the Parts Catalogue will be announced in the Yamaha Parts News.
It is advisable that you make necessary corrections to the Parts Catalogue according to the Yamaha Parts News.

2. Abbreviations

The Following abbreviations are used in this Parts Catalogue.

- "UR" Use specified parts number.
- "UN" Use as many as needed.
- "AP" Alternate Parts
- "LM" Local Made (Parts need to be ordered locally)
- "F#" Frame No. (Applicable machine No.)

3. Parts, which are to be supplied in an assembly, are listed with a dot(.) in front of the part name as shown below.

EXAMPLE

CARBURETOR ASSY

.JET, PILOT

.NOZZLE, MAIN

4. Number of component for assembly
The numeral appearing to the right of each component part indicates the quantity of parts for each assembly unit.

EXAMPLE

PART NO.	DESCRIPTION	Q'TY	REMARKS
2F5-83310-60	FRONT FLASHER LIGHT ASSY	2	
115-83311-60	.BULB (6V-18W)	1	
1M1-83309-60	.REFLECTOR	1	



5. Applicable colors of graphics are represented in the "REMARKS" as shown below.

PART NO.	DESCRIPTION	Q'TY	REMARKS
2N4-24110-00-X5	.FUEL TANK COMP.	2	MXR
3J1-24240-10	.GRAPHIC, FUEL TANK	1	for MXR

6. Applicable Serial No.

Engine Serial No.

Frame Serial No.



7. Note that the illustrations for reference in finding parts numbers, not to be used for assembling. When assembling, please use the applicable service manual.
8. The asterisk (*) before a reference number indicates modification items after the first edition.

MODEL LABEL

- (2) "Model Label" Indication

a: Model Type Code
b: Production Code No.
c: Colouring Type

○ 4TW1-010
● A

-

- [illegible]

- | Model Code | Colouring type code | Colour code | Colour Name | Abbreviation |
|------------------------------|---------------------|-------------|-----------------------------|--------------|
| 5GT6
5GT7
5GT9
5GTA | A | 00K0 | PASTEL DEEP GREEN | PDG |
| 5GT6 | B | 00TR | POMANTIQUE ROUGE | RTR |
| 5GT7 | C | 0598 | DARK GRAYISH YELLOW SOLID 1 | DNYS1 |

CONTENTS

ENGINE

CYLINDER HEAD	1
CYLINDER	3
CRANKSHAFT. PISTON	4
VALVE	5
CAMSHAFT. CHAIN	6
BLOWER	7
OIL PUMP	8
INTAKE	10
CARBURETOR	12
EXHAUST	14
CRANKCASE	15
CRANKCASE COVER 1	17
STARTER	19
CLUTCH	20
TRANSMISSION	22
MIDDLE DRIVE GEAR	24
SHIFT CAM. FORK	26
SHIFT SHAFT	27

CHASSIS

FRAME	28
FRONT FENDER	30
REAR FENDER	31
REAR ARM	33
DRIVE SHAFT	34
FRONT DIFFERENTIAL	37
REAR SUSPENSION	40
STEERING	41
FRONT SUSPENSION. WHEEL	43

FUEL TANK	44
SEAT	45
FRONT WHEEL	46
FRONT BRAKE	48
REAR WHEEL	49
STEERING HANDLE. CABLE	51
FRONT MASTER CYLINDER	53
STAND. FOOTREST	54
GUARD	56
GENERATOR	57
STARTING MOTOR	58
METER	59
HEADLIGHT	60
TAILLIGHT	61
HANDLE SWITCH. LEVER	62
ELECTRICAL 1	63
ELECTRICAL 2	64
EMBLEM.LABEL 1	67

INDEX

NUMERICAL INDEX	68
-----------------------	----






FIG. 1 CYLINDER HEAD

REF. NO.	PART NO.	DESCRIPTION	SGT6	SGT7	SGT9	SGT10	REMARKS
1	3TB-11101-02	CYLINDER HEAD ASSY	1	1	1	1	
2	4H7-11133-10	.GUIDE, INTAKE VALVE	4	4	4	4	
3	93440-12052	.CIRCLIP	4	4	4	4	
4	90116-06475	.BOLT, STUD	4	4	4	4	
5	90116-10378	.BOLT, STUD	2	2	2	2	
6	99530-10116	.PIN, DOWEL	2	2	2	2	
7	90340-14117	PLUG, STRAIGHT SCREW	1	1	1	1	
8	93210-13657	O-RING	1	1	1	1	
9	94701-00275	PLUG, SPARK (NGK DP8EA-9)	1	1	1	1	
10	91317-06125	BOLT	2	2	2	2	
11	91317-06115	BOLT	1	1	1	1	
12	91317-06025	BOLT	4	4	4	4	
13	91317-06040	BOLT	2	2	2	2	
14	91317-06055	BOLT	6	6	6	6	
15	90109-063E9	BOLT	1	1	1	1	
16	91317-06050	BOLT	1	1	1	1	
17	92907-06600	WASHER, PLATE	3	3	3	3	
18	1L9-11186-00	COVER, CYLINDER HEAD SIDE 2	2	2	2	2	
19	93210-32172	O-RING	2	2	2	2	
20	5Y1-11187-00	COVER, CYLINDER HEAD SIDE 3	1	1	1	1	
21	93210-62523	O-RING	1	1	1	1	
22	91317-06018	BOLT	2	2	2	2	
23	3TB-12215-01	CAP, TENSIONER CASE	1	1	1	1	
24	93210-19522	O-RING	1	1	1	1	
25	90401-06001	BOLT, UNION	1	1	1	1	
26	90430-06192	GASKET	1	1	1	1	
27	91317-06020	BOLT	1	1	1	1	


[illegible]



4WV1100-8020

FIG. 2 CYLINDER


REF. NO.	PART NO.	DESCRIPTION	SGT6	SGT7	SGT9	SGT1	REMARKS
1	3TB-11310-00	CYLINDER	1	1	1	1	
2	93210-98473	O-RING	1	1	1	1	
3	1VJ-11351-00	GASKET, CYLINDER	1	1	1	1	
4	90201-080L8	WASHER, PLATE	2	2	2	2	
5	90176-08026	NUT, CROWN	2	2	2	2	
6	90201-10590	WASHER, PLATE	2	2	2	2	
7	90179-10201	NUT	2	2	2	2	
8	90201-10124	WASHER, PLATE	2	2	2	2	
9	90179-10279	NUT	2	2	2	2	
10	91317-06035	BOLT	1	1	1	1	
11	90110-06204	BOLT, HEXAGON SOCKET HEAD	1	1	1	1	
12	2KF-11181-01	GASKET, CYLINDER HEAD 1	1	1	1	1	
13	99530-12016	PIN, DOWEL	2	2	2	2	
14	90105-08505	BOLT, WASHER BASED	4	4	4	4	
15	90201-085L3	WASHER, PLATE	4	4	4	4	
16	90430-08178	GASKET	1	1	1	1	
17	99530-08016	PIN, DOWEL	1	1	1	1	



5GT1100-9031

FIG. 3 CRANKSHAFT. PISTON


REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT4	REMARKS
1	5GT-11400-00	CRANKSHAFT ASSY	1	1	1	1	
2	5GT-W1141-00	.CRANK 1	1	1	1	1	
3	5GT-W1142-00	.CRANK 2	1	1	1	1	
4	4WV-11681-10	.PIN, CRANK 1	1	1	1	1	
5	93310-637D3	.BEARING	1	1	1	1	
6	5GT-11651-00	.ROD, CONNECTING	1	1	1	1	
7	90280-16053	KEY, WOODRUFF	1	1	1	1	
8	90201-10321	WASHER, PLATE	1	1	1	1	
9	90101-10568	BOLT	1	1	1	1	
10	93210-16290	O-RING	1	1	1	1	
11	93306-30702	BEARING (B6307)	1	1	1	1	
12	3TB-11631-00-Y0	PISTON (STD)	1	1	1	1	
	3TB-11636-00	PISTON (0.50MM O/S)	1	1	1	1	AP
	3TB-11638-00	PISTON (1.00MM O/S)	1	1	1	1	AP
13	34L-11610-00	PISTON RING SET (STD)	1	1	1	1	
	34L-11610-20	PISTON RING SET (0.50MM O/S)	1	1	1	1	AP
	34L-11610-40	PISTON RING SET (1.00MM O/S)	1	1	1	1	AP
14	1JK-11633-01	PIN, PISTON	1	1	1	1	
15	93450-24028	CIRCLIP	2	2	2	2	
*16	5GT-11500-00	BALANCER ASSY	1	1	1	1	
17	93306-30525	BEARING (B6305)	1	1	1	1	
18	93306-30534	BEARING	1	1	1	1	
19	93101-25106	OIL SEAL	2	2	2	2	



4WV1100-8040

FIG. 4 VALVE

REF. NO.	PART NO.	DESCRIPTION	SGT6	SGT7	SGT9	SGTA	REMARKS
1	4WV-12111-00	VALVE, INTAKE	2	2	2	2	
2	4WV-12121-00	VALVE, EXHAUST	2	2	2	2	
3	5Y1-12113-00	SPRING, VALVE INNER	4	4	4	4	
4	5Y1-12114-00	SPRING, VALVE OUTER	4	4	4	4	
5	4H7-12116-00	SEAT, VALVE SPRING	4	4	4	4	
6	1J7-12119-01	SEAL, VALVE STEM	4	4	4	4	
7	2F3-12117-00	RETAINER, VALVE SPRING	4	4	4	4	
8	1J7-12118-00	COTTER, VALVE	8	8	8	8	
9	34K-12151-00	ARM, VALVE ROCKER	1	1	1	1	
10	34K-12161-00	ARM, VALVE ROCKER 2	1	1	1	1	
11	4WV-12162-00	ARM, VALVE ROCKER 3	1	1	1	1	
12	34K-12163-00	ARM, VALVE ROCKER 4	1	1	1	1	
13	2NX-12146-00	SHAFT, ROCKER	1	1	1	1	
14	2NX-12156-00	SHAFT, ROCKER 2	1	1	1	1	
15	2NX-12166-00	SHAFT, ROCKER 3	1	1	1	1	
16	93210-08521	O-RING	2	2	2	2	
17	90109-063E8	BOLT	2	2	2	2	
18	2NX-12159-00	SCREW, VALVE ADJUSTING	4	4	4	4	
19	90170-06128	NUT	4	4	4	4	
20	90206-12075	WASHER, WAVE	4	4	4	4	



4WV1100-8050

FIG. 5 CAMSHAFT. CHAIN

REF. NO.	PART NO.	DESCRIPTION	SGT6	SGT7	SGT9	SGTA	REMARKS
1	4WV-12170-00	CAMSHAFT ASSY 1	1	1	1	1	
2	3YF-12284-00	.PIN, DECOMPRESSION LEVER	1	1	1	1	
3	90501-051L0	.SPRING, COMPRESSION	1	1	1	1	
4	3YF-12290-00	.LEVER, DECOMPRESSION SPRING	1	1	1	1	
5	3YF-12176-00	SPROCKET, CAM CHAIN	1	1	1	1	
6	4WV-12288-00	CAM, DECOMPRESSION	2	2	2	2	
7	3YF-12247-00	SHAFT, TENSIONER	2	2	2	2	
8	3YF-12216-00	SPRING	2	2	2	2	
9	4WV-12233-00	PLATE, GUIDE STOPPER 1	2	2	2	2	
10	90105-07342	BOLT, WASHER BASED	2	2	2	2	
11	94590-27126	CHAIN	1	1	1	1	
12	34K-12231-00	GUIDE, STOPPER 1	1	1	1	1	
13	34K-12241-00	GUIDE, STOPPER 2	1	1	1	1	
14	90105-060A6	BOLT, WASHER BASED	2	2	2	2	
15	3TB-12210-00	TENSIONER ASSY, CAM CHAIN	1	1	1	1	
16	90110-06225	BOLT, HEXAGON SOCKET HEAD	2	2	2	2	
17	4DW-12213-00	GASKET, TENSIONER CASE	1	1	1	1	

[illegible]




FIG. 7 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-13300-00	OIL PUMP ASSY	1	1	1	1	
2	4WV-13411-00	.STRAINER, OIL	1	1	1	1	
3	98507-06008	.SCREW, PAN HEAD	3	3	3	3	
4	4WV-13329-00	GASKET, PUMP COVER	1	1	1	1	
5	91317-06050	BOLT	3	3	3	3	
6	5GT-13325-00	GEAR, PUMP DRIVEN	1	1	1	1	
7	99009-11400	CIRCLIP	1	1	1	1	
8	4WV-13416-00	PIPE, OIL 1	1	1	1	1	
9	51Y-13411-00	STRAINER, OIL	1	1	1	1	
10	90501-18576	SPRING, COMPRESSION	1	1	1	1	
11	4HC-15351-00	PLUG, DRAIN	1	1	1	1	
12	93210-35520	O-RING	1	1	1	1	
13	4X7-13440-01	ELEMENT ASSY, OIL CLEANER	1	1	1	1	
14	583-13447-01	COVER, OIL ELEMENT	1	1	1	1	
15	93210-64297	O-RING	1	1	1	1	
16	95027-06020	BOLT, FLANGE	3	3	3	3	
17	90149-05110	SCREW	1	1	1	1	
18	90430-05126	GASKET	1	1	1	1	
19	5GT-13464-00	HOSE, OIL 1	1	1	1	1	
20	5GT-13465-00	HOSE, OIL 2	1	1	1	1	
21	91317-06016	BOLT	4	4	4	4	
22	93210-10197	O-RING	2	2	2	2	
23	4WV-13161-00	PIPE, DELIVERY 1	1	1	1	1	
24	93210-06422	O-RING	2	2	2	2	
25	95027-06012	BOLT, FLANGE	1	1	1	1	
26	3HN-13470-00	OIL COOLER ASSY	1	1	1	1	
27	90480-15235	GROMMET	3	3	3	3	




FIG. 7 OIL PUMP

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT A	REMARKS
28	90387-0714B	COLLAR	2	2	2	2	
29	90209-06174	WASHER	2	2	2	2	
30	95807-06020	BOLT, FLANGE	2	2	2	2	
31	93210-12152	O-RING	2	2	2	2	
32	93612-16254	PIN, DOWEL	2	2	2	2	
33	25G-13490-00	RELIEF VALVE ASSY	1	1	1	1	
34	93210-10096	O-RING	1	1	1	1	
35	4WV-1319K-00	PLATE	1	1	1	1	
36	95027-06012	BOLT, FLANGE	1	1	1	1	
37	4WV-13446-00	CONNECTOR	1	1	1	1	
38	93101-30171	OIL SEAL	2	2	2	2	
39	93450-42138	CIRCLIP	2	2	2	2	
40	90430-08178	GASKET	1	1	1	1	
41	95027-06025	BOLT, FLANGE	2	2	2	2	
42	95027-06040	BOLT, FLANGE	1	1	1	1	
43	99530-08016	PIN, DOWEL	2	2	2	2	




FIG. 8 INTAKE

REF. NO.	PART NO.	DESCRIPTION	SGT6	SGT7	SGT9	SGT1A	REMARKS
1	4WV-13586-00	JOINT, CARBURETOR 1	1	1	1	1	
2	93210-36769	O-RING	2	2	2	2	
3	91317-06020	BOLT	4	4	4	4	
4	90450-63088	HOSE CLAMP ASSY	1	1	1	1	
5	4WV-13596-00	JOINT, CARBURETOR 2	1	1	1	1	
6	90450-57044	HOSE CLAMP ASSY	1	1	1	1	
7	4X7-14467-01	SEAL	1	1	1	1	
8	4WV-14349-00	PIPE	1	1	1	1	
9	24W-14193-00	PIPE	1	1	1	1	
10	91A20-07010	TUBE, FLEXIBLE VINYL	1	1	1	1	
11	1UY-14411-01	CASE, AIR CLEANER 1	1	1	1	1	
12	1UY-14458-01	GUIDE	1	1	1	1	
13	1UY-14468-00	PLATE,ELEMENT FITTING	1	1	1	1	
14	1UY-14451-00	ELEMENT, AIR CLEANER	1	1	1	1	
15	1UY-14412-01	CAP, CLEANER CASE 1	1	1	1	1	
16	10M-14457-00	SEAL	1	1	1	1	
17	98507-05016	SCREW, PAN HEAD	5	5	5	5	
18	92907-05600	WASHER, PLATE	5	5	5	5	
19	59V-14457-00	SEAL	1	1	1	1	
20	90467-22080	CLIP	1	1	1	1	
21	4WV-14453-00	JOINT, AIR CLEANER 1	1	1	1	1	
22	4WV-14437-00	DUCT	1	1	1	1	
23	31A-14419-00	PIPE	1	1	1	1	
24	90460-75020	CLAMP, HOSE	1	1	1	1	
25	4WV-1442F-01	PROTECTOR	1	1	1	1	
26	90460-64065	CLAMP, HOSE	1	1	1	1	
27	90119-06063	BOLT, WITH WASHER	3	3	3	3	





FIG. 9 CARBURETOR


REF. NO.	PART NO.	DESCRIPTION	SGT6	SGT7	SGT9	SGT4	REMARKS
1	4VV-14901-00	CARBURETOR ASSY 1	1		1		
	4VV-14901-10	CARBURETOR ASSY 1		1	1		
2	4VV-24411-00	.DIAPHRAGM	1	1	1	1	
3	4VV-14933-00	.SPRING, DIAPHRAGM	1	1	1	1	
4	4VV-14272-00	.VALVE	1	1	1	1	
5	4VV-14147-20	.O-RING	1	1	1	1	
6	4VV-14918-00	.RING	1	1	1	1	
7	620-14231-29	.JET, MAIN (#145)	1		1		
	620-1423E-57	.JET, MAIN (#143.8)		1	1		
8	4VV-1490J-00	.NEEDLE SET	1		1		
	4VV-1490J-10	.NEEDLE SET		1	1		
9	4VV-14941-90	.NOZZLE, MAIN	1	1	1	1	
10	4VV-14985-00	.FLOAT	1	1	1	1	
11	4VV-14190-28	.NEEDLE VALVE ASSY	1	1	1	1	
12	98502-05008	.SCREW, PAN HEAD	2	2	2	2	
13	239-14172-07	.PILOT JET, AIR (0.7)	1	1	1	1	
14	4VV-14996-00	.PIPE	1	1	1	1	
15	4VV-14193-00	.PIPE	1	1	1	1	
16	98502-04006	.SCREW, PAN HEAD	3	3	3	3	
17	4VV-14147-10	.O-RING	1	1	1	1	
18	4VV-14105-01	.PILOT SCREW SET	1	1	1	1	
19	4HR-14142-42	.JET, PILOT (# 42.5)	1	1	1	1	
20	4VV-1410A-00	.STARTER SET	1	1	1	1	
21	12R-14191-00	.PLUG, DRAIN	1	1	1	1	
22	4VV-14197-00	.PIPE	1	1	1	1	
23	87M-14137-00	.CLIP	1	1	1	1	
24	98502-05014	.SCREW, PAN HEAD	2	2	2	2	



5GT1100-9100

FIG. 10 EXHAUST


REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-14611-00	PIPE, EXHAUST 1	1	1	1	1	
2	4WV-14628-00	PROTECTOR, EXHAUST PIPE	1	1	1	1	
3	4WV-1465R-01	PLATE, PROTECTOR	1	1	1	1	
4	95817-06010	BOLT, FLANGE	3	3	3	3	
5	90201-06071	WASHER, PLATE	3	3	3	3	
6	5GT-14711-00	MUFFLER 1	1	1	1	1	
7	95885-10014	.BOLT, FLANGE	1	1	1	1	
8	92990-10600	.WASHER, PLATE	1	1	1	1	
9	3YF-14755-00	GASKET, SILENCER	1	1	1	1	
10	4WV-14728-01	PROTECTOR, MUFFLER 2	1	1	1	1	
11	4WV-1465T-01	PLATE, PROTECTOR	1	1	1	1	
12	95817-06010	BOLT, FLANGE	3	3	3	3	
13	90201-06071	WASHER, PLATE	3	3	3	3	
14	5GT-14718-00	PROTECTOR, MUFFLER 1	1	1	1	1	
15	95817-06010	BOLT, FLANGE	3	3	3	3	
16	4WV-14752-00	PIPE, OUTLET	1	1	1	1	
17	97007-06008	BOLT	1	1	1	1	
18	95817-08045	BOLT, FLANGE	1	1	1	1	
19	90201-086J0	WASHER, PLATE	1	1	1	1	
20	95817-08020	BOLT, FLANGE	2	2	2	2	
21	90201-08326	WASHER, PLATE	2	2	2	2	
22	90179-06668	NUT	4	4	4	4	
23	3YF-14613-01	GASKET, EXHAUST PIPE	2	2	2	2	



5GT8100-0110

FIG. 11 CRANKCASE

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT10	REMARKS
1	4WV-15100-12	CRANKCASE ASSY	1	1	1	1	
2	99530-10014	.PIN, DOWEL	2	2	2	2	
3	2H7-15361-00	.GAUGE, LEVEL	1	1	1	1	
4	95027-06090	BOLT, FLANGE	1	1	1	1	
5	95027-06060	BOLT, FLANGE	2	2	2	2	
6	95027-06040	BOLT, FLANGE	5	5	5	5	
7	95027-06055	BOLT, FLANGE	6	6	6	6	
8	95027-06035	BOLT, FLANGE	1	1	1	1	
9	91317-08050	BOLT	4	4	4	4	
10	4WV-15327-00	SPACER, ENGINE MOUNT	1	1	1	1	
11	3F9-15362-00	PLUG, OIL LEVEL	1	1	1	1	
12	93210-27370	O-RING	1	1	1	1	
13	90340-14046	PLUG, STRAIGHT SCREW	1	1	1	1	
14	214-11198-01	GASKET	1	1	1	1	
15	4WV-15388-00	PLATE, BEARING COVER	1	1	1	1	
16	95027-06012	BOLT, FLANGE	2	2	2	2	
17	4WV-11166-00	PIPE, BREATHER 1	1	1	1	1	
18	4WV-24327-00	PROTECTOR, PIPE	1	1	1	1	
19	90467-14015	CLIP	1	1	1	1	
20	4WV-15163-00	HOUSING, BEARING 1	1	1	1	1	
21	5GT-15383-00	PLATE, BEARING COVER	1	1	1	1	
22	98707-06010	SCREW, FLAT HEAD	2	2	2	2	
23	95027-06020	BOLT, FLANGE	9	9	9	9	
24	99530-10014	PIN, DOWEL	2	2	2	2	
25	4WV-15463-00	GASKET 2	1	1	1	1	
26	93306-01002	BEARING	1	1	1	1	
27	93102-35463	OIL SEAL	1	1	1	1	

[illegible]




FIG. 12 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT1	REMARKS
1	4WV-15411-00	COVER, CRANKCASE 1	1	1	1	1	
2	4WV-15451-00	GASKET, CRANKCASE COVER 1	1	1	1	1	
3	99530-10014	PIN, DOWEL	2	2	2	2	
4	95027-06045	BOLT, FLANGE	10	10	10	10	
5	4WV-15113-00	PLATE	1	1	1	1	
6	91317-06012	BOLT	2	2	2	2	
7	93306-07801	BEARING	1	1	1	1	
8	93102-28476	OIL SEAL	1	1	1	1	
9	1UY-15719-00	WASHER, THRUST	1	1	1	1	
10	90151-05023	SCREW, COUNTERSUNK	3	3	3	3	
11	90340-14117	PLUG, STRAIGHT SCREW	1	1	1	1	
12	93210-14369	O-RING	1	1	1	1	
13	4WV-15431-02	COVER, CRANKCASE 3	1	1	1	1	
14	95827-08012	BOLT, FLANGE	1	1	1	1	
15	90430-08119	GASKET	1	1	1	1	
16	93306-20120	BEARING	1	1	1	1	
17	93101-12168	OIL SEAL	1	1	1	1	
18	4WV-15381-00	PLATE, BEARING COVER	1	1	1	1	
19	95027-06012	BOLT, FLANGE	1	1	1	1	
20	4WV-15462-00	GASKET, CRANKCASE COVER 3	1	1	1	1	
21	99530-10014	PIN, DOWEL	2	2	2	2	
22	95027-06040	BOLT, FLANGE	12	12	12	12	
23	4WV-15471-00	DUCT, AIR	1	1	1	1	
24	4WV-15496-00	SEAL, PROTECTOR 2	1	1	1	1	
25	4WV-15335-00	DAMPER 3	1	1	1	1	
26	4WV-15474-00	SEAL, AIR DUCT	1	1	1	1	
27	4WV-15495-00	SEAL, PROTECTOR 1	1	1	1	1	





FIG. 12 CRANKCASE COVER 1

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
28	4WV-15473-01	DUCT, AIR	1	1	1	1	
29	4WV-15494-01	SEAL, PROTECTOR	1	1	1	1	
30	4WV-15498-01	TAPE, DAMPER	1	1	1	1	
31	4WV-15475-02	DUCT, AIR	1	1	1	1	
32	5GT-15477-00	DUCT, AIR	1	1	1	1	
33	4WV-15472-00	SEAL, AIR DUCT	1	1	1	1	
34	90450-64089	HOSE CLAMP ASSY	7	7	7	7	
35	95807-06014	BOLT, FLANGE	1	1	1	1	
36	99530-14016	PIN, DOWEL	2	2	2	2	
37	90116-10506	BOLT, STUD	2	2	2	2	
38	90116-10263	BOLT, STUD	2	2	2	2	
39	99530-08016	PIN, DOWEL	1	1	1	1	
40	90430-08178	GASKET	1	1	1	1	
41	4WV-15499-00	PROTECTOR, COVER	1	1	1	1	
42	4WV-15326-00	DAMPER, ENGINE MOUNT 2	1	1	1	1	
43	98907-06014	SCREW, BIND	4	4	4	4	
44	90461-08113	CLAMP	1	1	1	1	
45	95027-06012	BOLT, FLANGE	1	1	1	1	
46	4WV-15491-00	PROTECTOR	1	1	1	1	
47	4WV-15316-00	DAMPER, ENGINE MOUNT 1	1	1	1	1	
48	98907-06014	SCREW, BIND	3	3	3	3	




5GT8100-0130

FIG. 13 STARTER

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	4WV-15650-02	IDLE GEAR ASSY	1	1	1	1	
2	90201-125L6	.WASHER, PLATE	1	1	1	1	
3	5GT-15710-00	STARTER ASSY	1	1	1	1	
4	21V-15741-00	.PAWL, DRIVE	1	1	1	1	
5	21V-15713-00	.SPRING, STARTER	1	1	1	1	
6	21V-15715-00	.SPRING, FRICTION	1	1	1	1	
7	21V-15767-00	.SPRING	1	1	1	1	
8	95702-06500	.NUT, FLANGE	1	1	1	1	
9	21V-15751-00	.WIRE, STARTER	1	1	1	1	
10	3X3-15755-00	.HANDLE, STARTER	1	1	1	1	
11	21V-15779-00	.COVER	1	1	1	1	
12	24W-15714-00	.DRUM, SHEAVE	1	1	1	1	
13	5GH-15443-00	.EMBLEM	1	1	1	1	
14	1UY-15716-00	.PLATE, DRIVE	1	1	1	1	
15	1UY-15723-00	PULLEY, STARTER	1	1	1	1	
16	90105-06553	BOLT, WASHER BASED	4	4	4	4	




FIG. 14 CLUTCH

REF. NO.	PART NO.	DESCRIPTION	SGT6	SGT7	SGT9	SGTA	REMARKS
1	5GT-16611-00	CLUTCH HOUSING COMP.	1	1	1	1	
2	5GT-16620-00	CLUTCH CARRIER ASSY	1	1	1	1	
3	4WV-16626-00	.SPRING, CLUTCH WEIGHT 1	5	5	5	5	
4	4SH-16664-00	BEARING, ONE WAY	1	1	1	1	
5	90387-2611Y	COLLAR	1	1	1	1	
6	93410-46079	CIRCLIP	1	1	1	1	
7	93306-20228	BEARING	1	1	1	1	
8	99009-35500	CIRCLIP	1	1	1	1	
9	90179-22640	NUT	1	1	1	1	
10	90387-2508C	COLLAR	1	1	1	1	
11	93210-25755	O-RING	1	1	1	1	
12	4WV-17620-10	PRIMARY SLIDING SHEAVE COMP.	1	1	1	1	
13	93101-31167	OIL SEAL	2	2	2	2	
14	4WV-17632-00	WEIGHT	8	8	8	8	
15	4WV-17623-00	CAM	1	1	1	1	
16	4WV-17653-00	SLIDER	4	4	4	4	
17	4WV-17654-01	SPACER 1	4	4	4	4	
18	93211-594A4	O-RING	1	1	1	1	
19	4WV-17639-10	STOPPER	1	1	1	1	
20	90157-04088	SCREW, PAN HEAD	8	8	8	8	
21	90201-047R9	WASHER, PLATE	8	8	8	8	
22	90387-1910N	COLLAR	1	1	1	1	
23	4WV-17641-00	V-BELT	1	1	1	1	
24	4WV-17611-00	SHEAVE, PRIMARY FIXED	1	1	1	1	
25	90201-190T7	WASHER, PLATE	1	1	1	1	
26	90179-16690	NUT	1	1	1	1	
27	4WV-17660-10	SECONDARY FIXED SHEAVE COMP.	1	1	1	1	





FIG. 15 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-17681-00	SHAFT, SECONDARY	1	1	1	1	
2	93306-20434	BEARING (B6204)	1	1	1	1	
3	93306-00612	BEARING	2	2	2	2	
4	90387-2611X	COLLAR	1	1	1	1	
5	93210-26741	O-RING	1	1	1	1	
6	93102-42322	OIL SEAL	1	1	1	1	
7	5GT-17421-00	AXLE, DRIVE	1	1	1	1	
8	5GT-17582-00	GEAR, MIDDLE DRIVE (25 T)	1	1	1	1	
9	93310-32590	BEARING	1	1	1	1	
10	5GT-17223-00	GEAR, HIGH WHEEL (30 T)	1	1	1	1	
11	90201-250R9	WASHER, PLATE	1	1	1	1	
12	93440-25084	CIRCLIP	1	1	1	1	
13	5GT-17285-00	CLUTCH, DOG	1	1	1	1	
14	90201-20278	WASHER, PLATE	1	1	1	1	
15	93310-420F2	BEARING	1	1	1	1	
16	5GT-17233-00	GEAR, LOW WHEEL (38 T)	1	1	1	1	
17	90201-20278	WASHER, PLATE	1	1	1	1	
18	93410-20038	CIRCLIP	1	1	1	1	
19	93310-32590	BEARING	1	1	1	1	
20	5GT-17253-00	GEAR, REVERSE WHEEL 2 (27 T)	1	1	1	1	
21	90201-250R9	WASHER, PLATE	1	1	1	1	
22	93440-25084	CIRCLIP	1	1	1	1	
23	5GT-17286-00	HOLDER	1	1	1	1	
24	90201-20278	WASHER, PLATE	1	1	1	1	
25	93306-30209	BEARING	1	1	1	1	
26	93306-30441	BEARING	1	1	1	1	
27	4WV-17432-00	AXLE, IDLE	1	1	1	1	



5GT1100-9150

FIG. 15 TRANSMISSION

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT A	REMARKS
28	4WV-17243-00	GEAR, REVERSE WHEEL 1	1	1	1	1	
29	93311-51554	BEARING	2	2	2	2	
30	90201-150U6	WASHER, PLATE	2	2	2	2	
31	99009-15400	CIRCLIP	2	2	2	2	
32	5GT-17523-00	SHAFT	1	1	1	1	
33	93440-25084	CIRCLIP	2	2	2	2	
34	5GT-17583-00	GEAR, MIDDLE DRIVEN (34 T)	1	1	1	1	
35	93603-14240	PIN, DOWEL	1	1	1	1	
36	93440-14155	CIRCLIP	1	1	1	1	
37	93311-42077	BEARING	1	1	1	1	
38	4WV-17811-00	HOUSING, TACHOMETER GEAR	1	1	1	1	
39	90381-08002	BUSH, SOLID	2	2	2	2	
40	4WV-17831-00	GEAR, DRIVE	1	1	1	1	
41	4WV-17841-00	GEAR, DRIVEN	1	1	1	1	
42	93210-24253	O-RING	1	1	1	1	
43	59V-17811-00	HOUSING, TACHOMETER GEAR	1	1	1	1	
44	98507-06016	SCREW, PAN HEAD	1	1	1	1	
45	93210-32172	O-RING	1	1	1	1	
46	90201-12163	WASHER, PLATE	1	1	1	1	
47	93102-08307	OIL SEAL	1	1	1	1	
48	95027-06020	BOLT, FLANGE	2	2	2	2	
49	98507-06030	SCREW, PAN HEAD	1	1	1	1	




FIG. 16 MIDDLE DRIVE GEAR

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	4WV-17521-01	HOUSING, BEARING	1	1	1	1	
2	93306-20622	BEARING	1	1	1	1	
3	11H-15383-01	PLATE, BEARING COVER	2	2	2	2	
4	90149-08152	SCREW	4	4	4	4	
5	52G-17531-01	SHIM, PINION (0.1T)	1	1	1	1	UR
	52G-17531-11	SHIM, PINION (0.15T)	1	1	1	1	UR
	52G-17531-21	SHIM, PINION (0.2T)	1	1	1	1	UR
	52G-17531-31	SHIM, PINION (0.3T)	1	1	1	1	UR
	52G-17531-41	SHIM, PINION (0.4T)	1	1	1	1	UR
	52G-17531-51	SHIM, PINION (0.5T)	1	1	1	1	UR
6	5GT-Y1754-00	MIDDLE GEAR COMP.	1	1	1	1	
7	90179-22526	NUT	1	1	1	1	
8	95817-08040	BOLT, FLANGE	6	6	6	6	
9	5GT-17551-00	HOUSING, BEARING	1	1	1	1	
10	93306-37206	BEARING	1	1	1	1	
11	90179-60699	NUT	1	1	1	1	
12	93306-20715	BEARING	1	1	1	1	
13	93101-30084	OIL SEAL	1	1	1	1	
14	5GT-17556-00	YOKE, JOINT	1	1	1	1	
15	90201-12191	WASHER, PLATE	1	1	1	1	
16	90179-12325	NUT	1	1	1	1	
17	93210-78544	O-RING	1	1	1	1	
18	97027-08030	BOLT	4	4	4	4	
19	92907-08600	WASHER, PLATE	4	4	4	4	
20	4KB-17531-00	SHIM, PINION (0.10T)	2	2	2	2	UR
	4KB-17531-10	SHIM, PINION (0.15T)	2	2	2	2	UR
	4KB-17531-20	SHIM, PINION (0.20T)	2	2	2	2	UR




FIG. 16 MIDDLE DRIVE GEAR

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
20	4KB-17531-30	SHIM, PINION (0.30T)	2	2	2	2	UR
	4KB-17531-40	SHIM, PINION (0.40T)	2	2	2	2	UR
	4KB-17531-50	SHIM, PINION (0.50T)	2	2	2	2	UR
	4KB-17531-60	SHIM, PINION (0.60T)	2	2	2	2	UR
21	90501-650L5	SPRING, COMPRESSION	1	1	1	1	
22	4VR-17527-00	CAM, DRIVEN	1	1	1	1	
23	4KB-46123-00	COUPLING, GEAR	1	1	1	1	
24	93306-00612	BEARING	1	1	1	1	
25	5GT-1755A-00	MIDDLE DRIVEN SHAFT ASSY	1	1	1	1	
26	93306-20517	BEARING (B6205)	1	1	1	1	
27	5GT-17576-00	YOKE, JOINT 2	1	1	1	1	
28	90201-14633	WASHER, PLATE	1	1	1	1	
29	90185-14070	NUT, SELF-LOCKING	1	1	1	1	
30	90179-55660	NUT	1	1	1	1	
31	93102-44454	OIL SEAL	1	1	1	1	






FIG. 18 SHIFT SHAFT

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT1	REMARKS
1	4SH-18198-00	LEVER	1	1	1	1	
2	90387-0613B	COLLAR	1	1	1	1	
3	90201-132G5	WASHER, PLATE	1	1	1	1	
4	90508-35764	SPRING, TORSION	1	1	1	1	
5	90201-06008	WASHER, PLATE	1	1	1	1	
6	95817-06035	BOLT, FLANGE	1	1	1	1	
7	4WV-18191-00	LEVER	1	1	1	1	
8	2H9-18154-00	.COVER, DUST	1	1	1	1	
9	4WV-18115-00	ROD, SHIFT	1	1	1	1	
10	90170-06289	NUT	1	1	1	1	
11	95307-06700	NUT	1	1	1	1	
12	5GT-18431-00	BRACKET, SHIFTER	1	1	1	1	
13	95817-06016	BOLT, FLANGE	3	3	3	3	
14	4WV-18300-02	SHIFTER ASSY	1	1	1	1	
15	4WV-18174-00	.KNOB, SHIFT LEVER	1	1	1	1	
16	90269-05055	.RIVET	1	1	1	1	
17	4WV-18131-00	.BOOT, SEALING	1	1	1	1	
18	4WV-18617-01	.STOPPER,RUBBER	1	1	1	1	
19	95807-08020	BOLT, FLANGE	3	3	3	3	
20	4WV-2637F-00	CABLE, CONTROL 2	1	1	1	1	




FIG. 19 FRAME

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-21110-00	FRAME COMP.	1	1	1	1	
2	4WV-21315-00	STAY, ENGINE 2	1	1	1	1	
3	95817-08012	BOLT, FLANGE	4	4	4	4	
4	95817-10080	BOLT, FLANGE	1	1	1	1	
5	5GT-21316-00	STAY, ENGINE 3	2	2	2	2	
6	95817-08014	BOLT, FLANGE	4	4	4	4	
7	90201-08730	WASHER, PLATE	4	4	4	4	
8	95817-10035	BOLT, FLANGE	2	2	2	2	
9	92907-10200	WASHER, PLAIN	2	2	2	2	
10	95817-10190	BOLT, FLANGE	2	2	2	2	
11	95817-10140	BOLT, FLANGE	1	1	1	1	
12	95607-10200	NUT, SELF-LOCKING	3	3	3	3	
13	5GT-2147A-20	GUARD, ENGINE 1	1	1			
	5GT-2147A-30	GUARD, ENGINE 1			1	1	
14	5GT-2147E-00	GUARD, ENGINE 2	1	1	1	1	
15	4N0-27114-00	STOPPER, MAIN STAND	1	1	1	1	
16	41R-21717-00	DAMPER	5	5	5	5	
17	90109-081F0	BOLT	4	4	4	4	
18	90201-08730	WASHER, PLATE	4	4	4	4	
19	90119-08212	BOLT, WITH WASHER	4	4	4	4	
20	4WV-2147J-00	COVER, SHAFT 1	1	1	1	1	
21	90119-06108	BOLT, WITH WASHER	3	3	3	3	
22	93306-20331	BEARING	1	1	1	1	
23	93102-25099	OIL SEAL	1	1	1	1	
24	93102-25081	OIL SEAL	1	1	1	1	
25	5GT-23872-00	HOLDER, BEARING	1	1	1	1	
26	4GY-24188-00	MOLD, FUEL TANK	1	1	1	1	





FIG. 20 FRONT FENDER


REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT1	REMARKS
1	4WV-W2151-01	FRONT FENDER COMP.	1	1			UR RTR
	4WV-W2151-11	FRONT FENDER COMP.	1	1	1	1	UR PDG
	4WV-W2151-21	FRONT FENDER COMP.	1	1			UR DNYS1
2	5GT-2175B-00	TUNING FORK MARK	1	1	1	1	
3	95817-06030	BOLT, FLANGE	2	2	2	2	
4	90201-06074	WASHER, PLATE	2	2	2	2	
5	90480-01400	GROMMET	2	2	2	2	
6	90387-06387	COLLAR	2	2	2	2	
7	95807-08020	BOLT, FLANGE	2	2	2	2	
8	90119-06056	BOLT, WITH WASHER	2	2	2	2	
9	90159-06059	SCREW, WITH WASHER	4	4	4	4	
10	4WV-2171L-00	MOLE, SIDE COVER 1	2	2	2	2	
11	4WV-21551-00	FENDER, OVER	1	1	1	1	
12	4WV-21555-00	FENDER, OVER 2	1	1	1	1	
13	4WV-21559-00	FENDER, OVER 3	1	1	1	1	
14	4WV-21560-00	FENDER, OVER 4	1	1	1	1	
15	90269-07076	RIVET	22	22	22	22	
16	90201-076J4	WASHER, PLATE	20	20	20	20	
17	90154-05052	SCREW, BINDING	6	6	6	6	
18	90201-05029	WASHER, PLATE	6	6	6	6	
19	95707-05300	NUT, FLANGE	6	6	6	6	
20	90119-06063	BOLT, WITH WASHER	4	4	4	4	
21	95707-06500	NUT, FLANGE	4	4	4	4	
22	4WV-21541-00	DAMPER 1	1	1	1	1	
23	4WV-21542-00	DAMPER 2	1	1	1	1	
24	4WV-21543-00	PLATE 1	2	2	2	2	
25	2HX-24181-00	DAMPER, LOCATING 1	1	1	1	1	



5GT1100-9210

FIG. 21 REAR FENDER

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	4WV-W2161-01	REAR FENDER COMP.	1	1			UR RTR
	4WV-W2161-11	REAR FENDER COMP.	1	1	1	1	UR PDG
	4WV-W2161-21	REAR FENDER COMP.	1	1			UR DNYS1
2	90109-065G4	BOLT	2	2	2	2	
3	90269-07076	RIVET	2	2	2	2	
4	26H-24145-00	DAMPER, SIDE COVER	2	2	2	2	
5	50W-82121-00	PAD, BATTERY	2	2	2	2	
6	4WV-21639-00	DAMPER 2	1	1	1	1	
7	4WV-21649-00	DAMPER	1	1	1	1	
8	90119-06056	BOLT, WITH WASHER	2	2	2	2	
9	90119-06205	BOLT, WITH WASHER	2	2	2	2	
10	5GT-21669-00	SEAL	1	1			UR FOR RTR
	5GT-21669-10	SEAL	1	1	1	1	UR FOR PDG
	5GT-21669-20	SEAL	1	1			UR FOR DNYS1
11	5GT-W2168-00	FLAP ASSY 1	1	1	1	1	
12	90269-07076	RIVET	2	2	2	2	
13	90201-076J4	WASHER, PLATE	2	2	2	2	
14	90154-05052	SCREW, BINDING	3	3	3	3	
15	90201-05029	WASHER, PLATE	3	3	3	3	
16	95707-05300	NUT, FLANGE	3	3	3	3	
17	90119-06063	BOLT, WITH WASHER	2	2	2	2	
18	95707-06500	NUT, FLANGE	2	2	2	2	
19	4WV-2162H-00	FLAP 3	1	1	1	1	
20	90269-07076	RIVET	7	7	7	7	
21	90201-076J4	WASHER, PLATE	7	7	7	7	
22	90119-06205	BOLT, WITH WASHER	1	1	1	1	
23	4WV-21691-00	FLAP	1	1	1	1	



5GT1100-9220

FIG. 22 REAR ARM

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-22110-00	REAR ARM COMP.	1	1	1	1	
2	93332-00080	BEARING	2	2	2	2	
3	93102-25017	OIL SEAL	2	2	2	2	
4	90387-1707V	COLLAR	2	2	2	2	
5	93210-17718	O-RING	2	2	2	2	
6	4WV-22141-00	SHAFT, PIVOT	1	1	1	1	
7	4WV-22143-00	NUT	1	1	1	1	
8	4KM-22141-00	SHAFT, PIVOT	1	1	1	1	
9	90338-34264	PLUG	2	2	2	2	
10	4KB-22189-00	BOOT, RUBBER	1	1	1	1	
11	90460-99289	CLAMP, HOSE	1	1	1	1	
12	4KB-22591-00	CLAMP, HOSE	1	1	1	1	
13	5GT-2219X-00	COVER	1	1	1	1	
14	4N0-27114-00	STOPPER, MAIN STAND	2	2	2	2	
15	95827-08012	BOLT, FLANGE	1	1	1	1	
16	95827-10016	BOLT, FLANGE	1	1	1	1	
17	1UJ-21638-00	DAMPER 1	1	1	1	1	
18	93101-35097	OIL SEAL	1	1	1	1	
19	93306-20531	BEARING	1	1	1	1	
20	95827-12025	BOLT, FLANGE	2	2	2	2	
21	95607-12200	NUT, SELF-LOCKING	2	2	2	2	




FIG. 23 DRIVE SHAFT

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-46101-00	REAR AXLE GEAR CASE ASSY	1	1	1	1	
2	4WV-46151-00	.HOUSING, DRIVE SHAFT	1	1	1	1	
3	90116-10593	.BOLT, STUD	4	4	4	4	
4	2H7-46102-00	.BEARING ASSY	1	1	1	1	
5	93101-52116	.OIL SEAL	1	1	1	1	
6	93317-85569	.BEARING	1	1	1	1	
7	5GT-Y4612-00	.RING GEAR SET	1	1	1	1	
8	1J7-17537-Y0-30	.SHIM, THRUST (0.30T)	1	1	1	1	UR
	1J7-17537-Y0-40	.SHIM, THRUST (0.40T)	1	1	1	1	UR
	1J7-17537-Y0-50	.SHIM, THRUST (0.50T)	1	1	1	1	UR
9	93306-30568	.BEARING	1	1	1	1	
10	90387-255H9	.COLLAR	1	1	1	1	
11	29U-46125-00	.RETAINER, BEARING	1	1	1	1	
12	93210-59531	.O-RING	1	1	1	1	
13	93101-38098	.OIL SEAL	1	1	1	1	
14	24W-46118-00-12	.WASHER, THRUST (1.2T)	1	1	1	1	UR
	24W-46118-00-14	.WASHER, THRUST (1.4T)	1	1	1	1	UR
	24W-46118-00-16	.WASHER, THRUST (1.6T)	1	1	1	1	UR
	24W-46118-00-18	.WASHER, THRUST (1.8T)	1	1	1	1	UR
	24W-46118-00-20	.WASHER, THRUST (2.0T)	1	1	1	1	UR
15	90340-14046	.PLUG, STRAIGHT SCREW	1	1	1	1	
16	214-11198-01	.GASKET	2	2	2	2	
17	2N4-15371-00	.BREATHER	1	1	1	1	
18	3HN-46152-01	.HOUSING, BEARING	1	1	1	1	
19	93102-65386	.OIL SEAL	1	1	1	1	
20	93316-01301	.BEARING	1	1	1	1	
21	93211-51749	.O-RING	1	1	1	1	




FIG. 23 DRIVE SHAFT

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT1A	REMARKS
22	24W-46117-00-25	.SHIM, RING GEAR (0.25T)	1	1	1	1	UR
	24W-46117-00-30	.SHIM, RING GEAR (0.30T)	1	1	1	1	UR
	24W-46117-00-40	.SHIM, RING GEAR (0.40T)	1	1	1	1	UR
	24W-46117-00-50	.SHIM, RING GEAR (0.50T)	1	1	1	1	UR
23	97027-08025	.BOLT	6	6	6	6	
24	92907-08600	.WASHER, PLATE	6	6	6	6	
25	95817-10025	.BOLT, FLANGE	2	2	2	2	
26	1FK-46156-00	.STOPPER, RING GEAR	1	1	1	1	
27	1FK-46157-00-15	.SHIM, STOPPER (T=0.15)	1	1	1	1	UR
	1FK-46157-00-20	.SHIM, STOPPER (T=0.20)	1	1	1	1	UR
28	90340-14029	.PLUG, STRAIGHT SCREW	1	1	1	1	
29	93210-65705	O-RING	1	1	1	1	
30	5GT-46123-00	COUPLING, GEAR	1	1	1	1	
31	90501-260L6	SPRING, COMPRESSION	1	1	1	1	
32	99009-25400	CIRCLIP	1	1	1	1	
33	90201-25289	WASHER, PLATE	1	1	1	1	
34	5GT-46172-00	SHAFT, DRIVE	1	1	1	1	
35	93410-22039	CIRCLIP	1	1	1	1	
36	4KD-46107-00	CROSS JOINT COMP. 2	1	1	1	1	
37	93399-99926	.BEARING	2	2	2	2	
38	93440-20088	.CIRCLIP	2	2	2	2	
39	2HR-46187-00	.SPIDER	1	1	1	1	
40	93399-99926	BEARING	2	2	2	2	
41	93440-20088	CIRCLIP	2	2	2	2	
42	93210-85706	O-RING	1	1	1	1	
43	90179-10394	NUT	4	4	4	4	
44	90201-10774	WASHER, PLATE	4	4	4	4	




FIG. 23 DRIVE SHAFT

[illegible]




FIG. 24 FRONT DIFFERENTIAL

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-46160-00	FRONT AXLE GEAR CASE COMP.	1	1	1	1	
2	4WV-46161-00	.HOUSING, SHAFT DRIVE 2	1	1	1	1	
3	4WV-46162-00	.HOUSING, BEARING 2	1	1	1	1	
4	4WV-46144-00	.HOUSING, PINION BEARING	1	1	1	1	
5	5GT-46146-00	.YOKE, JOINT 2	1	1	1	1	
6	90201-14633	.WASHER, PLATE	1	1	1	1	
7	5GT-46121-00	.GEAR, DRIVE PINION	1	1	1	1	
8	4WV-46145-00	.NUT 1	1	1	1	1	
9	93210-14359	.O-RING	1	1	1	1	
10	93210-69628	.O-RING	1	1	1	1	
11	4WV-46163-00	.SEAL,OIL 1	1	1	1	1	
12	4WV-46164-00	.BEARING 1	1	1	1	1	
13	4WV-46142-00	.RING,HOLE SNAP 1	1	1	1	1	
14	5GT-46141-00	.PINION, DRIVE 2	1	1	1	1	
15	4WV-46119-00	.SHIM, THRUST (0.1T)	1	1	1	1	UR
	4WV-46119-10	.SHIM, THRUST (0.2T)	1	1	1	1	UR
	4WV-46119-20	.SHIM, THRUST (0.3T)	1	1	1	1	UR
	4WV-46119-30	.SHIM, THRUST (0.4T)	1	1	1	1	UR
	4WV-46119-40	.SHIM, THRUST (0.5T)	1	1	1	1	UR
	4WV-46119-50	.SHIM, THRUST (1.0T)	1	1	1	1	UR
	4WV-46119-60	.SHIM, THRUST (1.5T)	1	1	1	1	UR
	4WV-46119-70	.SHIM, THRUST (2.0T)	1	1	1	1	UR
	4WV-46119-80	.SHIM, THRUST (2.5T)	1	1	1	1	UR
16	5GT-46131-00	.GEAR, RING 2	1	1	1	1	
17	4WV-46155-00	.BOLT 1	6	6	6	6	
18	5GT-46470-00	.LIMITED SLIP DIFF. ASSY	1	1	1	1	
19	91317-08020	.BOLT	3	3	3	3	





FIG. 24 FRONT DIFFERENTIAL

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
20	4WV-46158-00	.BOLT 2	4	4	4	4	
21	4WV-46159-00	.BOLT 3	6	6	6	6	
22	4WV-46143-00	.RING,HOLE SNAP 2	1	1	1	1	
23	4WV-18318-00	.SHAFT, SHIFTER	1	1	1	1	
24	4WV-4616A-00	.SERVO MOTOR COMP	1	1	1	1	
25	4WV-18514-00	.FORK, SHIFT 4	1	1	1	1	
26	4WV-46441-00	.CLUTCH,DRIVEN	1	1	1	1	
27	4WV-18319-00	.SHAFT 2	1	1	1	1	
28	4WV-46134-00	.O-RING 1	1	1	1	1	
29	4WV-46135-00	.O-RING 2	1	1	1	1	
30	93102-35380	.OIL SEAL	2	2	2	2	
31	4WV-46165-00	.BEARING 2	1	1	1	1	
32	4WV-46166-00	.BEARING 3	2	2	2	2	
33	4WV-46167-00	.BEARING 4	1	1	1	1	
34	3GD-82540-11	.NEUTRAL SWITCH ASSY	1	1	1	1	
35	4WV-46168-00	.PLUG, DRAIN 1	1	1	1	1	
36	4WV-46132-00	.GASKET 1	2	2	2	2	
37	93210-50768	.O-RING	1	1	1	1	
38	2N4-15371-00	.BREATHER	1	1	1	1	
39	90340-14029	PLUG, STRAIGHT SCREW	1	1	1	1	
40	214-11198-01	GASKET	1	1	1	1	
41	90445-072J3	HOSE (L890)	1	1	1	1	
42	90467-07029	CLIP	1	1	1	1	
43	5GT-46107-00	CROSS JOINT COMP. 2	1	1	1	1	
44	93399-99948	.BEARING	2	2	2	2	
45	93440-20088	.CIRCLIP	2	2	2	2	
46	5GT-46187-00	.SPIDER	1	1	1	1	



4WV1100-8260

FIG. 26 STEERING

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-23813-01	COLUMN, STEERING 2	1	1	1	1	
2	4WV-23816-00	ARM, PITMAN	1	1	1	1	
3	2HR-23442-00	HOLDER, HANDLE LOWER	2	2	2	2	
4	8K1-23814-00	HOLDER, HANDLE	2	2	2	2	
5	95827-08050	BOLT, FLANGE	4	4	4	4	
6	90336-28053	PLUG, TAPER	1	1	1	1	
7	1UY-23812-00	PLANE BEARING, STEERING	2	2	2	2	
8	93112-31011	OIL SEAL	2	2	2	2	
9	4KB-23868-01	BRACKET, STEERING LOWER	1	1	1	1	
10	97027-08060	BOLT	2	2	2	2	
11	1UY-23894-01	WASHER, LOCK 1	1	1	1	1	
12	90387-090R0	COLLAR	2	2	2	2	
13	90201-14222	WASHER, PLATE	1	1	1	1	
14	90185-14081	NUT, SELF-LOCKING	1	1	1	1	
15	90468-16191	CLIP	1	1	1	1	
16	4WV-23831-00	ROD, TIE	1	1	1	1	
17	1UY-23841-01	JOINT, UNIVERSAL 1	1	1	1	1	
18	1UY-23845-01	JOINT, UNIVERSAL 2	1	1	1	1	
19	95307-10700	NUT	1	1	1	1	
20	90170-10186	NUT	1	1	1	1	(L.H. THREAD)
21	4WV-23831-00	ROD, TIE	1	1	1	1	
22	1UY-23841-01	JOINT, UNIVERSAL 1	1	1	1	1	
23	1UY-23845-01	JOINT, UNIVERSAL 2	1	1	1	1	
24	95307-10700	NUT	1	1	1	1	
25	90170-10186	NUT	1	1	1	1	(L.H. THREAD)
26	90171-10046	NUT, CASTLE	4	4	4	4	
27	92990-10600	WASHER, PLATE	2	2	2	2	

FIG. 26 STEERING



4WV1100-8260

[illegible]




FIG. 27 FRONT SUSPENSION. WHEEL

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-23570-01	FRONT LOWER ARM COMP. (LEFT)	1	1	1	1	
2	5GT-23580-01	FRONT LOWER ARM COMP. (RIGHT)	1	1	1	1	
3	4WV-23526-00	BUSH	4	4	4	4	
4	90105-10253	BOLT, WASHER BASED	4	4	4	4	
5	90185-10060	NUT, SELF-LOCKING	4	4	4	4	
6	4WV-23350-00	SHOCK ABSORBER ASSY	2	2	2	2	
7	90179-35625	NUT	2	2	2	2	
8	93410-32075	CIRCLIP	2	2	2	2	
9	90105-10728	BOLT, WASHER BASED	2	2	2	2	
10	95337-10600	NUT	2	2	2	2	
11	91401-20020	PIN, COTTER	2	2	2	2	
12	90201-08759	WASHER, PLATE	2	2	2	2	
13	95817-12050	BOLT, FLANGE	4	4	4	4	
14	90201-122H1	WASHER, PLATE	4	4	4	4	
15	95617-12100	NUT, U	4	4	4	4	
16	4WV-2331M-00	COVER, RING	2	2	2	2	
17	90119-06228	BOLT, WITH WASHER	4	4	4	4	






FIG. 28 FUEL TANK



REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	4WV-24110-00	FUEL TANK COMP.	1	1	1	1	
2	1UY-24610-00	CAP ASSY	1	1	1	1	
3	5GT-24500-00	FUEL COCK ASSY 1	1	1	1	1	
4	3AJ-24523-00	.VALVE PACKING	1	1	1	1	
5	3AJ-24534-00	.SEAL, COCK	1	1	1	1	
6	97801-03008	.SCREW, PAN HEAD	2	2	2	2	
7	4X8-24512-00	.O-RING	1	1	1	1	
8	98606-04018	.SCREW, OVAL HEAD	1	1	1	1	
9	90202-05193	WASHER, PLATE	2	2	2	2	
10	90149-06011	SCREW	2	2	2	2	
11	90480-18290	GROMMET	2	2	2	2	
12	90387-066J1	COLLAR	2	2	2	2	
13	95807-06030	BOLT, FLANGE	2	2	2	2	
14	90480-01400	GROMMET	2	2	2	2	
15	90201-060L5	WASHER, PLATE	2	2	2	2	
16	90387-07598	COLLAR	2	2	2	2	
17	90119-06073	BOLT, WITH WASHER	2	2	2	2	
18	90445-10679	HOSE (L115)	1	1	1	1	
19	90467-09103	CLIP	2	2	2	2	
20	90445-083J5	HOSE (L600)	1	1	1	1	
21	4WV-2414H-00	DAMPER, PLATE 1	1		1		
	5GT-2414H-00	DAMPER, PLATE 1		1		1	
22	437-83936-11	BAND, SWITCH CORD	2	2	2	2	
23	90269-07076	RIVET	2	2	2	2	
24	1UA-82591-00	BAND	2	2	2	2	
25	4SH-24260-00	FUEL METER ASSY	1	1	1	1	
26	4SH-24261-00	HOUSING, FUEL METER	1	1	1	1	



5GT1100-9301

FIG. 30 FRONT WHEEL

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-25180-20	WHEEL COMP.	1	1			
	5GT-25180-30	WHEEL COMP.			1	1	
2	94108-1215F	TIRE (AT25 X 8 - 12)	1	1	1	1	DUNLOP-KT404A
3	93900-00022	VALVE, RIM	1	1	1	1	TAIHEIYO
4	95707-10500	NUT, FLANGE	4	4	4	4	
5	92907-10200	WASHER, PLAIN	4	4	4	4	
6	5GT-2512A-00	CAP, WHEEL	1	1	1	1	
7	5GT-2510F-00	BALL JOINT SET	1	1	1	1	
8	5GT-2510G-00	BOOT SET (BALL JOINT)	1	1	1	1	
9	5GT-2510H-00	BOOT SET (DOUBLE OFFSET JOINT)	1	1	1	1	
10	5GT-2510J-00	DOUBLE OFF SET JOINT	1	1	1	1	
11	4WV-2511G-00	BOOT BAND (BALL JOINT)	2	2	2	2	
12	4WV-2512G-00	BOOT BAND (SMALL)	2	2	2	2	
13	93450-22119	CIRCLIP	1	1	1	1	
14	5GT-23501-00	STEERING KNUCKLE ASSY (LEFT)	1	1	1	1	
15	93306-00615	.BEARING	2	2	2	2	
16	93102-38417	.OIL SEAL	2	2	2	2	
17	90560-30325	.SPACER	1	1	1	1	
18	5GT-25111-00	HUB, FRONT	1	1	1	1	
19	90114-10011	.BOLT, SERRATION	4	4	4	4	
20	93210-27666	O-RING	1	1	1	1	
21	90201-162L6	WASHER, PLATE	1	1	1	1	
22	90171-16048	NUT, CASTLE	1	1	1	1	
23	91401-30030	PIN, COTTER	1	1	1	1	
24	5GT-25180-20	WHEEL COMP.	1	1			
	5GT-25180-30	WHEEL COMP.			1	1	
25	94108-1215F	TIRE (AT25 X 8 - 12)	1	1	1	1	DUNLOP-KT404A



5GT1100-9301

FIG. 30 FRONT WHEEL

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT4	REMARKS
26	93900-00022	VALVE, RIM	1	1	1	1	TAIHEIYO
27	95707-10500	NUT, FLANGE	4	4	4	4	
28	92907-10200	WASHER, PLAIN	4	4	4	4	
29	5GT-2512A-00	CAP, WHEEL	1	1	1	1	
30	5GT-2510F-00	BALL JOINT SET	1	1	1	1	
31	5GT-2510G-00	BOOT SET (BALL JOINT)	1	1	1	1	
32	5GT-2510H-00	BOOT SET (DOUBLE OFFSET JOINT)	1	1	1	1	
33	5GT-2510J-00	DOUBLE OFF SET JOINT	1	1	1	1	
34	4WV-2511G-00	BOOT BAND (BALL JOINT)	2	2	2	2	
35	4WV-2512G-00	BOOT BAND (SMALL)	2	2	2	2	
36	93450-22119	CIRCLIP	1	1	1	1	
37	5GT-23502-00	STEERING KNUCKLE ASSY (RIGHT)	1	1	1	1	
38	93306-00615	.BEARING	2	2	2	2	
39	93102-38417	.OIL SEAL	2	2	2	2	
40	90560-30325	.SPACER	1	1	1	1	
41	5GT-25111-00	HUB, FRONT	1	1	1	1	
42	90114-10011	.BOLT, SERRATION	4	4	4	4	
43	93210-27666	O-RING	1	1	1	1	
44	90201-162L6	WASHER, PLATE	1	1	1	1	
45	90171-16048	NUT, CASTLE	1	1	1	1	
46	91401-30030	PIN, COTTER	1	1	1	1	





FIG. 31 FRONT BRAKE


REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	4WV-2582T-00	DISC, BRAKE	1	1	1	1	
2	90149-08268	SCREW	4	4	4	4	
3	4WV-2582T-00	DISC, BRAKE	1	1	1	1	
4	90149-08268	SCREW	4	4	4	4	
5	4WV-2580T-00	CALIPER ASSY (LEFT)	1	1	1	1	
6	3GD-W0057-00	.PISTON ASSY, CALIPER	1	1	1	1	
7	3GD-W0047-00	..CALIPER SEAL KIT	1	1	1	1	
8	1UY-W0048-50	.BLEED SCREW KIT	1	1	1	1	
9	4WV-W0045-00	.BRAKE PAD KIT	1	1	1	1	
10	3GD-25827-00	.SHIM, CALIPER	1	1	1	1	
11	3GD-25933-00	.PIN, PAD	2	2	2	2	
12	3GD-25916-00	.PLUG	1	1	1	1	
13	4WV-2580U-00	CALIPER ASSY (RIGHT)	1	1	1	1	
14	3GD-W0057-00	.PISTON ASSY, CALIPER	1	1	1	1	
15	3GD-W0047-00	..CALIPER SEAL KIT	1	1	1	1	
16	1UY-W0048-50	.BLEED SCREW KIT	1	1	1	1	
17	4WV-W0045-00	.BRAKE PAD KIT	1	1	1	1	
18	3GD-25828-00	.SHIM, CALIPER	1	1	1	1	
19	3GD-25933-00	.PIN, PAD	2	2	2	2	
20	3GD-25916-00	.PLUG	1	1	1	1	
21	90105-08538	BOLT, WASHER BASED	4	4	4	4	
22	4WV-2514A-01	RING, WHEEL 1 (LEFT)	2	2	2	2	
23	95827-06012	BOLT, FLANGE	6	6	6	6	



5GT1100-9320

FIG. 32 REAR WHEEL


REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-25383-00	COLLAR, WHEEL	1	1	1	1	
2	90114-10011	.BOLT, SERRATION	4	4	4	4	
3	5GT-25390-20	REAR WHEEL COMP.	1	1			
	5GT-25390-30	REAR WHEEL COMP.			1	1	
4	95707-10500	NUT, FLANGE	4	4	4	4	
5	94110-1215G	TIRE (AT20 X 10 - 12)	1	1	1	1	DUNLOP-KT405G
6	93900-00022	VALVE, RIM	1	1	1	1	TAIHEIYO
7	92907-10200	WASHER, PLAIN	4	4	4	4	
8	5GT-25390-20	REAR WHEEL COMP.	1	1			
	5GT-25390-30	REAR WHEEL COMP.			1	1	
9	94110-1215G	TIRE (AT20 X 10 - 12)	1	1	1	1	DUNLOP-KT405G
10	93900-00022	VALVE, RIM	1	1	1	1	TAIHEIYO
11	95707-10500	NUT, FLANGE	4	4	4	4	
12	92907-10200	WASHER, PLAIN	4	4	4	4	
13	5GT-46540-00	REAR AXLE HOUSING COMP.	1	1	1	1	
14	93306-00805	BEARING	1	1	1	1	
15	93106-47040	OIL SEAL	1	1	1	1	
16	4SH-25367-00	COVER, HUB DUST	1	1	1	1	
17	4GB-25321-00	PLATE, BRAKE SHOE	1	1	1	1	
18	3GH-25129-00	SEAL, PLATE DUST	1	1	1	1	
19	4WV-W2536-01	BRAKE SHOE SET	1	1	1	1	
20	90507-20002	SPRING, TENSION	2	2	2	2	
21	93210-14104	O-RING	2	2	2	2	
22	4WV-25351-00	CAMSHAFT	1	1	1	1	
23	148-25353-00	SHIM, CAMSHAFT	1	1	1	1	
24	3Y6-2533A-01	PLATE, INDICATOR	1	1	1	1	
25	4WV-25355-00	LEVER, CAMSHAFT	1	1	1	1	



5GT1100-9320

FIG. 32 REAR WHEEL


REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
26	90101-06278	BOLT	1	1	1	1	
27	95307-06600	NUT	1	1	1	1	
28	90201-10118	WASHER, PLATE	1	1	1	1	
29	95027-10016	BOLT, FLANGE	1	1	1	1	
30	90506-16482	SPRING, TENSION	1	1	1	1	
31	4GB-46513-00	RETAINER	1	1	1	1	
32	95817-08040	BOLT, FLANGE	4	4	4	4	
33	5GT-25381-00	AXLE, WHEEL	1	1	1	1	UR
	5GT-25381-10	AXLE, WHEEL	1	1	1	1	UR
34	90387-284T0	COLLAR	1	1	1	1	
35	93210-26606	O-RING	1	1	1	1	
36	5GT-2531E-00	DRUM, BRAKE	1	1	1	1	
37	90114-10003	.BOLT, SERRATION	4	4	4	4	
38	93210-12131	.O-RING	4	4	4	4	
39	5GT-25336-00	RING 2	1	1	1	1	
40	90201-162L6	WASHER, PLATE	2	2	2	2	
41	90171-16048	NUT, CASTLE	2	2	2	2	
42	91401-30030	PIN, COTTER	2	2	2	2	
43	5GT-2512A-00	CAP, WHEEL	2	2	2	2	
44	90445-080K8	HOSE (L1200)	1	1	1	1	
45	90467-08075	CLIP	1	1	1	1	
46	90105-10751	BOLT, WASHER BASED	4	4	4	4	
47	90201-101J1	WASHER, PLATE	4	4	4	4	
48	90105-10751	BOLT, WASHER BASED	4	4	4	4	
49	90201-101J1	WASHER, PLATE	4	4	4	4	



5GT1100-9330

FIG. 33 STEERING HANDLE. CABLE

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT10	REMARKS
1	2HR-26111-00	HANDLEBAR	1	1	1	1	
2	3GB-26241-00	GRIP (LEFT)	2	2	2	2	
3	4WV-26124-01	PROTECTOR, HANDLEBAR	1	1	1	1	
4	5FE-26232-00	EMBLEM 3D	1	1	1	1	
5	5GT-2836B-00	TUNING FORK MARK	1	1	1	1	
6	4WV-26311-00	CABLE, THROTTLE 1	1	1	1	1	
7	4WV-26341-00	CABLE, BRAKE	1	1	1	1	
8	20E-26343-00	NUT, ADJUSTING	1	1	1	1	
9	90501-10782	SPRING, COMPRESSION	1	1	1	1	
10	90249-12008	PIN	1	1	1	1	
11	4WV-26250-00	THROTTLE LEVER ASSY	1	1	1	1	
12	4KB-2628F-00	.CAP, GEAR	1	1	1	1	
13	4KB-2628G-00	.GASKET	1	1	1	1	
14	95607-05100	.NUT, U	1	1	1	1	
15	1NV-26398-00	.WASHER	1	1	1	1	
16	1NV-26304-00	.SPRING	1	1	1	1	
17	1NV-26259-01	.COLLAR	1	1	1	1	
18	1NV-2625K-00	.COLLAR	1	1	1	1	
19	93104-09025	.OIL SEAL	1	1	1	1	
20	1NV-26129-00	.WASHER	1	1	1	1	
21	1NV-2625G-01	.LEVER, THROTTLE	1	1	1	1	
22	90149-04278	.SCREW	3	3	3	3	
23	95307-05700	.NUT	1	1	1	1	
24	98507-05020	.SCREW, PAN HEAD	1	1	1	1	
25	97607-04210	.SCREW, PAN HEAD WITH WASHER	2	2	2	2	
26	4WV-83976-00	.SWITCH, HANDLE 1	1	1	1	1	
27	4V4-82913-00	HOLDER, LEVER LOWER 1	1	1	1	1	



4WV1100-8340

FIG. 34 FRONT MASTER CYLINDER

REF. NO.	PART NO.	DESCRIPTION	SGT6	SGT7	SGT9	SGTA	REMARKS
1	4WV-25870-00	MASTER CYLINDER SUB ASSY	1	1	1	1	
2	4K0-W0041-50	.CYLINDER KIT, MASTER	1	1	1	1	
3	4L0-25854-00	.DIAPHRAGM, RESERVOIR	1	1	1	1	
4	4H7-25852-00	.CAP, RESERVOIR	1	1	1	1	
5	98706-04012	.SCREW, FLAT HEAD	2	2	2	2	
6	56A-25867-00	BRACKET, MASTER CYLINDER	1	1	1	1	
7	97007-06025	BOLT	2	2	2	2	
8	92907-06600	WASHER, PLATE	2	2	2	2	
9	1UY-26259-00	COLLAR	1	1	1	1	
10	4WV-25872-00	HOSE, BRAKE 1	1	1	1	1	
11	4WV-25873-00	HOSE, BRAKE 2	2	2	2	2	
12	4WV-25871-00	PIPE, BRAKE	1	1	1	1	
13	4WV-25882-00	PIPE, BRAKE 2	1	1	1	1	
14	2GU-25866-00	CIRCLIP	2	2	2	2	
15	4GB-25875-00	HOLDER, BRAKE HOSE 1	1	1	1	1	
16	4GB-25876-00	HOLDER, BRAKE HOSE 2	1	1	1	1	
17	95827-06012	BOLT, FLANGE	4	4	4	4	
18	97027-08030	BOLT	2	2	2	2	
19	92907-08600	WASHER, PLATE	2	2	2	2	
20	90401-10159	BOLT, UNION	3	3	3	3	
21	90201-10118	WASHER, PLATE	6	6	6	6	
22	4WV-25875-00	HOLDER, BRAKE HOSE 1	1	1	1	1	
23	4WV-25876-00	HOLDER, BRAKE HOSE 2	1	1	1	1	
24	95827-06012	BOLT, FLANGE	4	4	4	4	





FIG. 35 STAND, FOOTREST

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-27411-00	FOOTREST 1	3	3	3	3	
2	5GT-27421-00	FOOTREST 2	1	1	1	1	
3	95817-10020	BOLT, FLANGE	8	8	8	8	
4	5GT-27211-00	PEDAL, BRAKE	1	1	1	1	
5	128-27114-00	STOPPER, MAIN STAND	1	1	1	1	
6	90506-18527	SPRING, TENSION	1	1	1	1	
7	93430-12008	CIRCLIP	1	1	1	1	
8	90201-15797	WASHER, PLATE	1	1	1	1	
9	5GT-26351-00	CABLE, BRAKE	1	1	1	1	
10	92907-06200	WASHER	1	1	1	1	
11	91401-20012	PIN, COTTER	1	1	1	1	
12	90240-06076	PIN, CLEVIS	1	1	1	1	
13	90249-12008	PIN	1	1	1	1	
14	90501-10782	SPRING, COMPRESSION	1	1	1	1	
15	20E-26343-00	NUT, ADJUSTING	1	1	1	1	
16	5GT-27481-00	BOARD, FOOTREST	1	1	1	1	
17	128-27114-00	STOPPER, MAIN STAND	1	1	1	1	
18	90119-06108	BOLT, WITH WASHER	4	4	4	4	
19	5GT-27488-00	BOARD, FOOTREST 2	1	1	1	1	
20	128-27114-00	STOPPER, MAIN STAND	1	1	1	1	
21	90119-06108	BOLT, WITH WASHER	4	4	4	4	
22	4WV-27453-00	COVER 1	1	1	1	1	
23	95807-06014	BOLT, FLANGE	3	3	3	3	
24	4WV-27486-00	COVER 1	1	1	1	1	
25	4WV-27496-00	MOLE 1	1	1	1	1	
26	90159-06033	SCREW, WITH WASHER	3	3	3	3	
27	4WV-27463-10	COVER 2	1	1	1	1	



5GT6100-0360

FIG. 36 GUARD

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT10	REMARKS
1	5GT-2845N-30	BAR, CARRY FRONT	1	1			
	5GT-2845N-50	BAR, CARRY FRONT			1	1	
2	95817-08016	BOLT, FLANGE	4	4	4	4	
3	2HR-28415-00	DAMPER 1	2	2	2	2	
4	5GT-2845R-00	BAR, CARRY REAR	1	1	1	1	
5	95817-08016	BOLT, FLANGE	3	3	3	3	
6	95817-08020	BOLT, FLANGE	2	2	2	2	
7	5GT-24841-00	CARRIER, FRONT	1	1			
	5GT-24841-20	CARRIER, FRONT			1	1	
8	95817-08016	BOLT, FLANGE	2	2	2	2	
9	5GT-24842-00	CARRIER, REAR	1	1			
	5GT-24842-10	CARRIER, REAR			1	1	
10	90560-06243	SPACER	2	2	2	2	
11	95827-06035	BOLT, FLANGE	2	2	2	2	
12	95607-06100	NUT, U	2	2	2	2	
13	24W-2483H-00	BAND	2	2	2	2	

[illegible]



REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GT8	REMARKS
1	4WV-83570-00	SPEEDOMETER ASSY	1	1	1	1	
2	4GB-83519-00	BRACKET, METER	1	1	1	1	
3	1M1-83526-00	DAMPER 2	2	2	2	2	
4	53Y-83524-00	WASHER, SPECIAL	2	2	2	2	
5	437-83525-00	CLIP	2	2	2	2	
6	4WV-83536-00	SOCKET, METER	1	1	1	1	
7	4R0-83517-00	BULB (12V-3.4W T10)	1	1	1	1	
8	5Y0-83513-00	DAMPER	1	1	1	1	
9	3GM-83517-00	BULB (12V-1.7W)	2	2	2	2	
10	4WV-83550-00	SPEEDOMETER CABLE ASSY	1	1	1	1	
11	95807-06010	BOLT, FLANGE	2	2	2	2	
12	93210-14104	O-RING	1	1	1	1	





FIG. 40 HEADLIGHT





5GT1100-9430

FIG. 42 HANDLE SWITCH. LEVER

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	1YW-82911-01	HOLDER, LEVER 1	1	1	1	1	
2	2HT-83912-00	LEVER 1	1	1			
	3FA-83912-00	LEVER 1			1	1	
3	1YW-83965-00	LEVER, LOCK	1	1	1	1	
4	2XJ-82913-00	HOLDER, LEVER LOWER 1	1	1	1	1	
5	90109-06576	BOLT	1	1	1	1	
6	95607-06100	NUT, U	1	1	1	1	
7	98507-06020	SCREW, PAN HEAD	2	2	2	2	
8	92907-06100	WASHER, SPRING	2	2	2	2	
9	1YW-83980-00	FRONT STOP SWITCH ASSY	1	1	1	1	
10	90123-08046	BOLT	1	1	1	1	
11	90179-08148	NUT	1	1	1	1	
12	1RX-83922-01	LEVER 2			1	1	
	38W-83922-00	LEVER 2	1	1			
13	90109-06577	BOLT	1	1	1	1	
14	95607-06100	NUT, U	1	1	1	1	
15	90149-06131	SCREW	1	1	1	1	
16	90170-06010	NUT	1	1	1	1	
17	90501-10312	SPRING, COMPRESSION	1	1	1	1	
18	4GB-83973-00	SWITCH, HANDLE 3	1	1	1	1	
19	437-83936-01	BAND, SWITCH CORD	4	4	4	4	






FIG. 44 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5GT-81960-00	RECTIFIER & REGULATOR ASSY	1	1	1	1	
2	95807-06020	BOLT, FLANGE	2	2	2	2	
3	4SH-82100-21	BATTERY ASSY (YTX20L-BS)	1	1	1	1	
4	4WV-82128-00	BRACKET, BATTERY	1	1	1	1	
5	4BD-21639-00	DAMPER 2	1	1	1	1	
6	278-27114-00	STOPPER, MAIN STAND	2	2	2	2	
7	4WV-82115-00	WIRE, PLUS LEAD	1	1	1	1	
8	4WV-82116-00	WIRE, MINUS LEAD	1	1	1	1	
9	4WV-82541-00	WIRE, LEAD	1	1	1	1	
10	5GT-81940-00	STARTER RELAY ASSY	1	1	1	1	
11	95027-06008	BOLT, FLANGE	2	2	2	2	
12	5GT-82150-00	FUSE HOLDER ASSY	1	1	1	1	
13	2GV-82151-00	.FUSE (20A-BL)	2	2	2	2	
14	42X-82151-00	.FUSE (10A-BL)	2	2	2	2	
15	4KL-82155-00	.BAND	2	2	2	2	
16	4GB-82510-10	MAIN SWITCH ASSY	1	1	1	1	
17	3HN-82579-00	.CAP, KEY	1	1	1	1	
18	2HR-83530-01	PILOT LIGHT ASSY	1	1	1	1	
19	123-83516-21	.BULB (12V-3.4W)	1	1	1	1	
20	24W-83530-01	PILOT LIGHT ASSY	1	1	1	1	GREEN
21	123-83516-21	.BULB (12V-3.4W)	1	1	1	1	
22	5GT-82590-00	WIRE HARNESS ASSY	1	1	1	1	
23	3WP-81980-00	.DIODE ASSY	1	1	1	1	
24	5GT-82180-00	.CIRCUIT BREAKER ASSY	1	1	1	1	
25	5GT-82560-00	.THERMO SWITCH ASSY	1	1	1	1	UR
26	29U-81950-93	RELAY ASSY	2	2	2	2	
27	2NL-81950-92	RELAY ASSY	1	1	1	1	




FIG. 44 ELECTRICAL 2

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
28	4SH-86510-00	MOTOR CONTROL UNIT ASSY	1	1	1	1	
29	98907-06016	SCREW, BIND	1	1	1	1	
30	1UA-82591-00	BAND	1	1			
	1UA-82591-00	BAND			4	4	
31	90464-13073	CLAMP	2	2	2	2	
32	90464-13073	CLAMP			1	1	
	90464-13073	CLAMP	2	2			
33	90464-12036	CLAMP	1	1	1	1	
34	1UA-82591-00	BAND	1	1	1	1	
35	90464-07209	CLAMP	1	1	1	1	
36	1UA-82591-00	BAND	1	1			
	1UA-82591-00	BAND			2	2	
37	90464-30040	CLAMP	1	1	1	1	
38	90464-13073	CLAMP			1	1	
	90464-13073	CLAMP	2	2			
39	90468-15139	CLIP	1	1	1	1	
40	90464-25098	CLAMP	1	1	1	1	
41	1UA-82591-00	BAND	1	1	1	1	
42	1UA-82591-00	BAND	1	1	1	1	
43	90464-10112	CLAMP	1	1	1	1	
44	90464-48174	CLAMP	1	1	1	1	
45	90464-20094	CLAMP	1	1	1	1	
46	90464-20159	CLAMP	2	2	2	2	
47	59V-81920-00	TERMINAL ASSY	1	1	1	1	
48	59V-81942-00	.COVER	1	1	1	1	
49	90159-05018	SCREW, WITH WASHER	1	1	1	1	
50	95707-05500	NUT, FLANGE	1	1	1	1	




FIG. 45 EMBLEM.LABEL 1

REF. NO.	PART NO.	DESCRIPTION	5GT6	5GT7	5GT9	5GTA	REMARKS
1	5FE-21568-01	LABEL, WARNING	1	1	1	1	
2	90267-32109	RIVET, BLIND	6	6	6	6	
3	90201-03313	WASHER, PLATE	6	6	6	6	
4	4WV-2151E-00	LABEL 2	1	1	1	1	
5	5FE-21697-01	LABEL, CAUTION 2	1	1	1	1	
6	90267-32109	RIVET, BLIND	4	4	4	4	
7	90201-03313	WASHER, PLATE	4	4	4	4	
8	5GT-21570-40	GRAPHIC SET, FRONT FENDER			1	1	UR FOR PDG
	5GT-21570-50	GRAPHIC SET, FRONT FENDER	1	1			UR FOR RTR
	5GT-21570-60	GRAPHIC SET, FRONT FENDER	1	1			UR FOR DNYS1
	5GT-21570-70	GRAPHIC SET, FRONT FENDER	1	1			
9	5FE-2151H-01	LABEL 5	1	1	1	1	
10	90267-32109	RIVET, BLIND	4	4	4	4	
11	90201-03313	WASHER, PLATE	4	4	4	4	
12	5GT-21696-00	LABEL, CAUTION	1	1	1	1	
13	90267-32109	RIVET, BLIND	4	4	4	4	
14	90201-03313	WASHER, PLATE	4	4	4	4	
15	5GH-2163G-00	EMBLEM 1	2	2	2	2	UR FOR PDG
	5GH-2163G-10	EMBLEM 1	2	2			UR FOR RTR
	5GH-2163G-20	EMBLEM 1	2	2			UR FOR DNYS1
16	5GT-2165G-00	GRAPHIC, REAR (L.H)	1	1	1	1	
17	5GT-2165H-00	GRAPHIC, REAR (R.H)	1	1	1	1	
18	3FA-2819R-00	TAG, WARNING	1	1	1	1	
19	3MX-24875-A0	LABEL 1	1	1	1	1	ENGLISH
20	3GC-24877-A0	LABEL, CAUTION	1	1	1	1	
21	3MX-24875-A0	LABEL 1	1	1	1	1	ENGLISH
22	4WV-24877-A0	LABEL, CAUTION	1	1	1	1	

NUMERICAL INDEX

PARTNO.	REF. NO.	PARTNO.	REF. NO.	PARTNO.	REF. NO.	PARTNO.	REF. NO.	PARTNO.	REF. NO.
95817-10025	23 - 25	99009-11400	7 - 7						
95817-10035	19 - 8	99009-15400	15 - 31						
95817-10080	19 - 4	99009-19400	24 - 54						
95817-10140	19 - 11	99009-25400	23 - 32						
95817-10190	19 - 10	99009-35500	14 - 8						
95817-12050	27 - 13	99530-08016	2 - 17						
95827-06012	31 - 23		7 - 43						
	34 - 17		12 - 39						
	34 - 24	99530-10014	11 - 2						
95827-06035	36 - 11		11 - 24						
95827-08012	12 - 14		12 - 3						
	22 - 15		12 - 21						
95827-08050	26 - 5	99530-10116	1 - 6						
95827-10016	22 - 16	99530-12016	2 - 13						
95827-12025	22 - 20	99530-14016	12 - 36						
95885-10014	10 - 7								
97007-06008	10 - 17								
97007-06020	43 - 8								
97007-06025	34 - 7								
97027-08025	23 - 23								
97027-08030	16 - 18								
	34 - 18								
97027-08060	26 - 10								
97602-04112	9 - 25								
97607-04210	33 - 25								
97707-50016	40 - 9								
97707-50025	40 - 10								
97801-03008	28 - 6								
98502-04006	9 - 16								
98502-05008	9 - 12								
98502-05010	9 - 30								
98502-05014	9 - 24								
98507-03540	40 - 4								
98507-05016	8 - 17								
98507-05020	33 - 24								
	33 - 28								
98507-06008	7 - 3								
98507-06016	15 - 44								
98507-06020	42 - 7								
98507-06030	15 - 49								
	37 - 3								
98606-04018	28 - 8								
98706-04012	34 - 5								
98707-06010	11 - 22								
98907-06014	12 - 43								
	12 - 48								
98907-08016	43 - 2								
	44 - 29								